






32.10d ... and press it into its recess ...




32.10e ... then secure the wiring with the clamp



32.11 Fit the rotor onto the shaft ...



32.12a ... then install the bolt ...



32.12b ... and tighten it to the specified torque

the wiring grommet, then install it into the cut-out in the crankcase (**see illustrations**). Secure the wiring with its clamp (**see illustration**).

**11** Clean the tapered end of the crankshaft and the corresponding mating surface on the inside of the rotor with a suitable solvent. Make sure that no metal objects have attached themselves to the magnet on the inside of the rotor, then install the rotor onto the shaft (**see illustration**).

**12** Install the rotor bolt and tighten it to the torque setting specified at the beginning of the Chapter, using the method employed on removal to prevent the rotor from turning (**see illustrations**).

**13** Install the alternator cover using a new gasket (**see illustration 32.6**). Tighten the cover bolts evenly in a criss-cross sequence.

**14** Reconnect the wiring at the connector and secure it with any clips or ties.

**15** Install the lower fairing (see Chapter 8).

out the following checks.

**3** Set the multimeter to the 0-20 dc volts setting. Connect the meter positive (+ve) probe to the Red/white terminal and the negative (-ve) probe to the green terminal on the wiring connector and check for voltage. Full battery voltage should be present. Switch the ignition switch 'OFF'.

**4** Switch the multimeter to the resistance (ohms) scale. Check for continuity between the Green terminal of the wiring connector and ground (earth). There should be continuity.

**5** Check the resistance between any two Yellow terminals of the wiring connector. A resistance reading of 0.1 to 1.0 ohms should be obtained between any two Yellow terminals of the wiring connector.

**6** If the above checks do not provide the expected results check the wiring between the battery, regulator/rectifier and alternator (**see the wiring diagrams** at the end of this book).

**7** If the wiring checks out, the regulator/rectifier unit is probably faulty. To check the unit, use a multimeter set to the appropriate resistance scale and check the



33.1 Disconnect the regulator/rectifier wiring connector


### 33 Regulator/rectifier – check and replacement

#### Check

**1** Remove the seat cowl (see Chapter 8). The regulator/rectifier is mounted on the left-hand side of the rear sub-frame. Disconnect the wiring connector (**see illustration**).

**2** Connect the negative (-ve) probe of the multimeter to a suitable ground (earth) point, then switch the ignition switch 'ON' and carry





|                               |        |                                  |        |
|-------------------------------|--------|----------------------------------|--------|
| Dimensions and Weights .....  | REF•1  | Fault Finding Equipment .....    | REF•35 |
| Tools and Workshop Tips ..... | REF•2  | Technical Terms Explained .....  | REF•39 |
| Conversion Factors .....      | REF•20 | VFR400Z and VFR400R (NC21, NC24) |        |
| MOT Test Checks .....         | REF•21 | specifications .....             | REF•43 |
| Storage .....                 | REF•25 | Index .....                      | REF•52 |
| Fault Finding .....           | REF•27 |                                  |        |

## Dimensions and Weights




### VFR400

|                        |         |
|------------------------|---------|
| Wheelbase .....        | 1345 mm |
| Overall length .....   | 1985 mm |
| Overall width .....    | 705 mm  |
| Overall height .....   | 1075 mm |
| Ground clearance ..... | 125 mm  |
| Weight (dry) .....     | 175 kg  |

### RVF400


|                        |               |
|------------------------|---------------|
| Wheelbase .....        | 1335 mm       |
| Overall length .....   | 1985 mm       |
| Overall width .....    | 685 mm        |
| Overall height .....   | 1065 mm       |
| Ground clearance ..... | 125 mm        |
| Weight (dry) .....     | Not available |

## Repair and overhaul tools



- |                                               |                                                          |                                    |                                               |                                     |
|-----------------------------------------------|----------------------------------------------------------|------------------------------------|-----------------------------------------------|-------------------------------------|
| 1 Torque wrench (small and mid-ranges)        | 4 Vernier gauge                                          | 7 Selection of pullers             | 10 Wire stripper and crimper tool             | 13 Hose clamp (wingnut type shown)  |
| 2 Conventional, plastic or soft-faced hammers | 5 Circlip pliers (internal and external, or combination) | 8 Breaker bars                     | 11 Multimeter (measures amps, volts and ohms) | 14 Clutch holding tool              |
| 3 Impact driver set                           | 6 Set of cold chisels and punches                        | 9 Chain breaking/riveting tool set | 12 Stroboscope (for dynamic timing checks)    | 15 One-man brake/clutch bleeder kit |

## Specialist tools



- |                               |                                             |                                              |                                              |                        |
|-------------------------------|---------------------------------------------|----------------------------------------------|----------------------------------------------|------------------------|
| 1 Micrometers (external type) | 4 Cylinder compression gauge                | 7 Plastigauge kit                            | 10 Piston ring removal and installation tool | 13 Stud extractor      |
| 2 Telescoping gauges          | 5 Vacuum gauges (left) or manometer (right) | 8 Valve spring compressor (4-stroke engines) | 11 Piston ring clamp                         | 14 Screw extractor set |
| 3 Dial gauge                  | 6 Oil pressure gauge                        | 9 Piston pin drawbolt tool                   | 12 Cylinder bore hone (stone type shown)     | 15 Bearing driver set  |

## 2 Fasteners - screws, bolts and nuts

### Fastener types and applications

#### Bolts and screws

● Fastener head types are either of hexagonal, Torx or splined design, with internal and external versions of each type (see illustrations 2.1 and 2.2); splined head fasteners are not in common use on motorcycles. The conventional slotted or Phillips head design is used for certain screws. Bolt or screw length is always measured from the underside of the head to the end of the item (see illustration 2.11).



2.1 Internal hexagon/Allen (A), Torx (B) and splined (C) fasteners, with corresponding bits




2.2 External Torx (A), splined (B) and hexagon (C) fasteners, with corresponding sockets

● Certain fasteners on the motorcycle have a tensile marking on their heads, the higher the marking the stronger the fastener. High tensile fasteners generally carry a 10 or higher marking. Never replace a high tensile fastener with one of a lower tensile strength.

#### Washers (see illustration 2.3)

● Plain washers are used between a fastener head and a component to prevent damage to the component or to spread the load when torque is applied. Plain washers can also be used as spacers or shims in certain assemblies. Copper or aluminium plain washers are often used as sealing washers on drain plugs.



2.3 Plain washer (A), penny washer (B), spring washer (C) and serrated washer (D)

● The split-ring spring washer works by applying axial tension between the fastener head and component. If flattened, it is fatigued and must be renewed. If a plain (flat) washer is used on the fastener, position the spring washer between the fastener and the plain washer.

● Serrated star type washers dig into the fastener and component faces, preventing loosening. They are often used on electrical earth (ground) connections to the frame.


● Cone type washers (sometimes called Belleville) are conical and when tightened apply axial tension between the fastener head and component. They must be installed with the dished side against the component and often carry an OUTSIDE marking on their outer face. If flattened, they are fatigued and must be renewed.

● Tab washers are used to lock plain nuts or bolts on a shaft. A portion of the tab washer is bent up hard against one flat of the nut or bolt to prevent it loosening. Due to the tab washer being deformed in use, a new tab washer should be used every time it is disturbed.

● Wave washers are used to take up endfloat on a shaft. They provide light springing and prevent excessive side-to-side play of a component. Can be found on rocker arm shafts.

#### Nuts and split pins

● Conventional plain nuts are usually six-sided (see illustration 2.4). They are sized by thread diameter and pitch. High tensile nuts carry a number on one end to denote their tensile strength.



2.4 Plain nut (A), shouldered locknut (B), nylon insert nut (C) and castellated nut (D)

● Self-locking nuts either have a nylon insert, or two spring metal tabs, or a shoulder which is staked into a groove in the shaft - their advantage over conventional plain nuts is a resistance to loosening due to vibration. The nylon insert type can be used a number of times, but must be renewed when the friction of the nylon insert is reduced, ie when the nut spins freely on the shaft. The spring tab type can be reused unless the tabs are damaged. The shouldered type must be renewed every time it is disturbed.

● Split pins (cotter pins) are used to lock a castellated nut to a shaft or to prevent slackening of a plain nut. Common applications are wheel axles and brake torque arms. Because the split pin arms are deformed to lock around the nut a new split pin must always be used on installation - always fit the correct size split pin which will fit snugly in the shaft hole. Make sure the split pin arms are correctly located around the nut (see illustrations 2.5 and 2.6).



2.5 Bend split pin (cotter pin) arms as shown (arrows) to secure a castellated nut



2.6 Bend split pin (cotter pin) arms as shown to secure a plain nut

**Caution:** If the castellated nut slots do not align with the shaft hole after tightening to the torque setting, tighten the nut until the next slot aligns with the hole - never slacken the nut to align its slot.

● R-pins (shaped like the letter R), or slip pins as they are sometimes called, are sprung and can be reused if they are otherwise in good condition. Always install R-pins with their closed end facing forwards (see illustration 2.7).

- If you are working on an engine internal component, corrosion will most likely not be a problem due to the well lubricated environment. However, components can be very tight and an impact driver is a useful tool in freeing them (see illustration 2.14).



**2.14 Using an impact driver to free a fastener**


- Where corrosion has occurred between dissimilar metals (eg steel and aluminium alloy), the application of heat to the fastener head will create a disproportionate expansion rate between the two metals and break the seizure caused by the corrosion. Whether heat can be applied depends on the location of the fastener - any surrounding components likely to be damaged must first be removed (see illustration 2.15). Heat can be applied using a paint stripper heat gun or clothes iron, or by immersing the component in boiling water - wear protective gloves to prevent scalding or burns to the hands.



**2.15 Using heat to free a seized fastener**

- As a last resort, it is possible to use a hammer and cold chisel to work the fastener head unscrewed (see illustration 2.16). This will damage the fastener, but more importantly extreme care must be taken not to damage the surrounding component.

**Caution:** Remember that the component being secured is generally of more value than the bolt, nut or screw - when the fastener is freed, do not unscrew it with force, instead work the fastener back and forth when resistance is felt to prevent thread damage.



**2.16 Using a hammer and chisel to free a seized fastener**

## Broken fasteners and damaged heads

- If the shank of a broken bolt or screw is accessible you can grip it with self-locking grips. The knurled wheel type stud extractor tool or self-gripping stud puller tool is particularly useful for removing the long studs which screw into the cylinder mouth surface of the crankcase or bolts and screws from which the head has broken off (see illustration 2.17). Studs can also be removed by locking two nuts together on the threaded end of the stud and using a spanner on the lower nut (see illustration 2.18).



**2.17 Using a stud extractor tool to remove a broken crankcase stud**



**2.18 Two nuts can be locked together to unscrew a stud from a component**

- A bolt or screw which has broken off below or level with the casing must be extracted using a screw extractor set. Centre punch the fastener to centralise the drill bit, then drill a hole in the fastener (see illustration 2.19). Select a drill bit which is approximately half to three-quarters the



**2.19 When using a screw extractor, first drill a hole in the fastener . . .**

diameter of the fastener and drill to a depth which will accommodate the extractor. Use the largest size extractor possible, but avoid leaving too small a wall thickness otherwise the extractor will merely force the fastener walls outwards wedging it in the casing thread.

- If a spiral type extractor is used, thread it anti-clockwise into the fastener. As it is screwed in, it will grip the fastener and unscrew it from the casing (see illustration 2.20).



**2.20 . . . then thread the extractor anti-clockwise into the fastener**

- If a taper type extractor is used, tap it into the fastener so that it is firmly wedged in place. Unscrew the extractor (anti-clockwise) to draw the fastener out.



**Warning:** Stud extractors are very hard and may break off in the fastener if care is not taken - ask an engineer about spark erosion if this happens.

- Alternatively, the broken bolt/screw can be drilled out and the hole retapped for an oversize bolt/screw or a diamond-section thread insert. It is essential that the drilling is carried out squarely and to the correct depth, otherwise the casing may be ruined - if in doubt, entrust the work to an engineer.

- Bolts and nuts with rounded corners cause the correct size spanner or socket to slip when force is applied. Of the types of spanner/socket available always use a six-point type rather than an eight or twelve-point type - better grip

### Thread locking and sealing compounds

● Locking compounds are used in locations where the fastener is prone to loosening due to vibration or on important safety-related items which might cause loss of control of the motorcycle if they fail. It is also used where important fasteners cannot be secured by other means such as lockwashers or split pins.

● Before applying locking compound, make sure that the threads (internal and external) are clean and dry with all old compound removed. Select a compound to suit the component being secured - a non-permanent general locking and sealing type is suitable for most applications, but a high strength type is needed for permanent fixing of studs in castings. Apply a drop or two of the compound to the first few threads of the fastener, then thread it into place and tighten to the specified torque. Do not apply excessive thread locking compound otherwise the thread may be damaged on subsequent removal.

● Certain fasteners are impregnated with a dry film type coating of locking compound on their threads. Always renew this type of fastener if disturbed.

● Anti-seize compounds, such as copper-based greases, can be applied to protect threads from seizure due to extreme heat and corrosion. A common instance is spark plug threads and exhaust system fasteners.

## 3 Measuring tools and gauges

### Feeler gauges

● Feeler gauges (or blades) are used for measuring small gaps and clearances (see illustration 3.1). They can also be used to measure endfloat (sideplay) of a component on a shaft where access is not possible with a dial gauge.

● Feeler gauge sets should be treated with care and not bent or damaged. They are etched with their size on one face. Keep them clean and very lightly oiled to prevent corrosion build-up.



3.1 Feeler gauges are used for measuring small gaps and clearances - thickness is marked on one face of gauge

● When measuring a clearance, select a gauge which is a tight sliding fit between the two components. You may need to use two gauges together to measure the clearance accurately.

### Micrometers

● A micrometer is a precision tool capable of measuring to 0.01 or 0.001 of a millimetre. It should always be stored in its case and not in the general toolbox. It must be kept clean and never dropped, otherwise its frame or measuring anvils could be distorted resulting in inaccurate readings.

● External micrometers are used for measuring outside diameters of components and have many more applications than internal micrometers. Micrometers are available in different size ranges, eg 0 to 25 mm, 25 to 50 mm, and upwards in 25 mm steps; some large micrometers have interchangeable anvils to allow a range of measurements to be taken. Generally the largest precision measurement you are likely to take on a motorcycle is the piston diameter.

● Internal micrometers (or bore micrometers) are used for measuring inside diameters, such as valve guides and cylinder bores. Telescoping gauges and small hole gauges are used in conjunction with an external micrometer, whereas the more expensive internal micrometers have their own measuring device.

### External micrometer

**Note:** The conventional analogue type instrument is described. Although much easier to read, digital micrometers are considerably more expensive.

● Always check the calibration of the micrometer before use. With the anvils closed (0 to 25 mm type) or set over a test gauge (for




3.2 Check micrometer calibration before use

the larger types) the scale should read zero (see illustration 3.2); make sure that the anvils (and test piece) are clean first. Any discrepancy can be adjusted by referring to the instructions supplied with the tool. Remember that the micrometer is a precision measuring tool - don't force the anvils closed, use the ratchet (4) on the end of the micrometer to close it. In this way, a measured force is always applied.


● To use, first make sure that the item being measured is clean. Place the anvil of the micrometer (1) against the item and use the thimble (2) to bring the spindle (3) lightly into contact with the other side of the item (see illustration 3.3). Don't tighten the thimble down because this will damage the micrometer - instead use the ratchet (4) on the end of the micrometer. The ratchet mechanism applies a measured force preventing damage to the instrument.

● The micrometer is read by referring to the linear scale on the sleeve and the annular scale on the thimble. Read off the sleeve first to obtain the base measurement, then add the fine measurement from the thimble to obtain the overall reading. The linear scale on the sleeve represents the measuring range of the micrometer (eg 0 to 25 mm). The annular scale



3.3 Micrometer component parts


- |           |           |                 |
|-----------|-----------|-----------------|
| 1 Anvil   | 3 Spindle | 5 Frame         |
| 2 Thimble | 4 Ratchet | 6 Locking lever |




**3.11 Vernier component parts (linear gauge)**

- |                 |                 |                 |               |
|-----------------|-----------------|-----------------|---------------|
| 1 Clamp screws  | 3 Internal jaws | 5 Sliding scale | 7 Depth gauge |
| 2 External jaws | 4 Thumbwheel    | 6 Main scale    |               |

In the example shown the item measures 55.92 mm (see illustration 3.12):



**3.12 Vernier gauge reading of 55.92 mm**



**3.13 Vernier component parts (dial gauge)**

- |                 |                 |
|-----------------|-----------------|
| 1 Clamp screw   | 5 Main scale    |
| 2 External jaws | 6 Sliding scale |
| 3 Internal jaws | 7 Dial gauge    |
| 4 Thumbwheel    |                 |

|                  |          |
|------------------|----------|
| Base measurement | 55.00 mm |
| Fine measurement | 00.92 mm |
| Total figure     | 55.92 mm |

Some vernier calipers are equipped with a dial gauge for fine measurement. Before use, check that the jaws are clean, then close them fully and check that the dial gauge reads zero. If necessary adjust the gauge ring accordingly. Slacken the vernier clamp screw (1) and set its jaws over (2), or inside (3), the item to be measured (see illustration 3.13). Slide the jaws into contact, using the thumbwheel (4) for fine movement. Read off the main scale (5) where the edge of the sliding scale (6) intersects it, taking the whole number to the left of the zero; this provides the base measurement. Read off the needle position on the dial gauge (7) scale to provide the fine measurement; each division represents 0.05 of a millimetre. Add this fine measurement to the base measurement to obtain the total reading.

In the example shown the item measures 55.95 mm (see illustration 3.14):

|                  |          |
|------------------|----------|
| Base measurement | 55.00 mm |
| Fine measurement | 00.95 mm |
| Total figure     | 55.95 mm |



**3.14 Vernier gauge reading of 55.95 mm**

## Plastigauge

Plastigauge is a plastic material which can be compressed between two surfaces to measure the oil clearance between them. The width of the compressed Plastigauge is measured against a calibrated scale to determine the clearance.

Common uses of Plastigauge are for measuring the clearance between crankshaft journal and main bearing inserts, between crankshaft journal and big-end bearing inserts, and between camshaft and bearing surfaces. The following example describes big-end oil clearance measurement.

Handle the Plastigauge material carefully to prevent distortion. Using a sharp knife, cut a length which corresponds with the width of the bearing being measured and place it carefully across the journal so that it is parallel with the shaft (see illustration 3.15). Carefully install both bearing shells and the connecting rod. Without rotating the rod on the journal tighten its bolts or nuts (as applicable) to the specified torque. The connecting rod and bearings are then disassembled and the crushed Plastigauge examined.



**3.15 Plastigauge placed across shaft journal**

Using the scale provided in the Plastigauge kit, measure the width of the material to determine the oil clearance (see illustration 3.16). Always remove all traces of Plastigauge after use using your fingernails.

**Caution:** Arriving at the correct clearance demands that the assembly is torqued correctly, according to the settings and sequence (where applicable) provided by the motorcycle manufacturer.



**3.16 Measuring the width of the crushed Plastigauge**

- Checking individual components for warpage, such as clutch plain (metal) plates, requires a perfectly flat plate or piece of plate glass and feeler gauges.

## 4 Torque and leverage

### What is torque?

- Torque describes the twisting force about a shaft. The amount of torque applied is determined by the distance from the centre of the shaft to the end of the lever and the amount of force being applied to the end of the lever; distance multiplied by force equals torque.
- The manufacturer applies a measured torque to a bolt or nut to ensure that it will not slacken in use and to hold two components securely together without movement in the joint. The actual torque setting depends on the thread size, bolt or nut material and the composition of the components being held.
- Too little torque may cause the fastener to loosen due to vibration, whereas too much torque will distort the joint faces of the component or cause the fastener to shear off. Always stick to the specified torque setting.

### Using a torque wrench

- Check the calibration of the torque wrench and make sure it has a suitable range for the job. Torque wrenches are available in Nm (Newton-metres), kgf m (kilograms-force metre), lbf ft (pounds-feet), lbf in (inch-pounds). Do not confuse lbf ft with lbf in.
- Adjust the tool to the desired torque on the scale (see illustration 4.1). If your torque wrench is not calibrated in the units specified, carefully convert the figure (see *Conversion Factors*). A manufacturer sometimes gives a torque setting as a range (8 to 10 Nm) rather than a single figure - in this case set the tool midway between the two settings. The same torque may be expressed as  $9 \text{ Nm} \pm 1 \text{ Nm}$ . Some torque wrenches have a method of locking the setting so that it isn't inadvertently altered during use.



4.1 Set the torque wrench index mark to the setting required, in this case 12 Nm


- Install the bolts/nuts in their correct location and secure them lightly. Their threads must be clean and free of any old locking compound. Unless specified the threads and flange should be dry - oiled threads are necessary in certain circumstances and the manufacturer will take this into account in the specified torque figure. Similarly, the manufacturer may also specify the application of thread-locking compound.
- Tighten the fasteners in the specified sequence until the torque wrench clicks, indicating that the torque setting has been reached. Apply the torque again to double-check the setting. Where different thread diameter fasteners secure the component, as a rule tighten the larger diameter ones first.
- When the torque wrench has been finished with, release the lock (where applicable) and fully back off its setting to zero - do not leave the torque wrench tensioned. Also, do not use a torque wrench for slackening a fastener.

### Angle-tightening

- Manufacturers often specify a figure in degrees for final tightening of a fastener. This usually follows tightening to a specific torque setting.
- A degree disc can be set and attached to the socket (see illustration 4.2) or a protractor can be used to mark the angle of movement on the bolt/nut head and the surrounding casting (see illustration 4.3).




4.2 Angle tightening can be accomplished with a torque-angle gauge ...



4.3 ... or by marking the angle on the surrounding component

### Loosening sequences


- Where more than one bolt/nut secures a component, loosen each fastener evenly a little at a time. In this way, not all the stress of the joint is held by one fastener and the components are not likely to distort.
- If a tightening sequence is provided, work in the REVERSE of this, but if not, work from the outside in, in a criss-cross sequence (see illustration 4.4).



4.4 When slackening, work from the outside inwards

### Tightening sequences


- If a component is held by more than one fastener it is important that the retaining bolts/nuts are tightened evenly to prevent uneven stress build-up and distortion of sealing faces. This is especially important on high-compression joints such as the cylinder head.
- A sequence is usually provided by the manufacturer, either in a diagram or actually marked in the casting. If not, always start in the centre and work outwards in a criss-cross pattern (see illustration 4.5). Start off by securing all bolts/nuts finger-tight, then set the torque wrench and tighten each fastener by a small amount in sequence until the final torque is reached. By following this practice,



4.5 When tightening, work from the inside outwards



5.6 Expand the bearing puller so that it locks behind the bearing . . .



5.7 . . . attach the slide hammer to the bearing puller

method is attempted, first prepare a work surface which will enable the casing to be tapped face down to help dislodge the bearing – a wood surface is ideal since it will not damage the casing's gasket surface. Wearing protective gloves, tap the heated casing several times against the work surface to dislodge the bearing under its own weight (see illustration 5.8).




5.8 Tapping a casing face down on wood blocks can often dislodge a bearing

- Bearings can be installed in blind holes using the driver or socket method described above.

#### Drawbolts

- Where a bearing or bush is set in the eye of a component, such as a suspension linkage arm or connecting rod small-end, removal by drift may damage the component. Furthermore, a rubber bushing in a shock absorber eye cannot successfully be driven out of position. If access is available to an engineering press, the task is straightforward. If not, a drawbolt can be fabricated to extract the bearing or bush.



5.9 Drawbolt component parts assembled on a suspension arm


- 1 Bolt or length of threaded bar
- 2 Nuts
- 3 Washer (external diameter greater than tubing internal diameter)
- 4 Tubing (internal diameter sufficient to accommodate bearing)
- 5 Suspension arm with bearing
- 6 Tubing (external diameter slightly smaller than bearing)
- 7 Washer (external diameter slightly smaller than bearing)



5.10 Drawing the bearing out of the suspension arm

- To extract the bearing/bush you will need a long bolt with nut (or piece of threaded bar with two nuts), a piece of tubing which has an internal diameter larger than the bearing/bush, another piece of tubing which has an external diameter slightly smaller than the bearing/bush, and a selection of washers (see illustrations 5.9 and 5.10). Note that the pieces of tubing must be of the same length, or longer, than the bearing/bush.

- The same kit (without the pieces of tubing) can be used to draw the new bearing/bush back into place (see illustration 5.11).



5.11 Installing a new bearing (1) in the suspension arm

#### Temperature change

- If the bearing's outer race is a tight fit in the casing, the aluminium casing can be heated to release its grip on the bearing. Aluminium will expand at a greater rate than the steel bearing outer race. There are several ways to do this, but avoid any localised extreme heat (such as a blow torch) – aluminium alloy has a low melting point.

- Approved methods of heating a casing are using a domestic oven (heated to 100°C) or immersing the casing in boiling water (see illustration 5.12). Low temperature range localised heat sources such as a paint stripper heat gun or clothes iron can also be used (see illustration 5.13). Alternatively, soak a rag in boiling water, wring it out and wrap it around the bearing housing.



**Warning:** All of these methods require care in use to prevent scalding and burns to the hands. Wear protective gloves when handling hot components.



5.12 A casing can be immersed in a sink of boiling water to aid bearing removal



5.13 Using a localised heat source to aid bearing removal

- If heating the whole casing note that plastic components, such as the neutral switch, may suffer – remove them beforehand.

- After heating, remove the bearing as described above. You may find that the expansion is sufficient for the bearing to fall out of the casing under its own weight or with a light tap on the driver or socket.

- If necessary, the casing can be heated to aid bearing installation, and this is sometimes the recommended procedure if the motorcycle manufacturer has designed the housing and bearing fit with this intention.

- Use a bearing driver or socket which bears only on the outer hard edge of the seal to install it in the casing - tapping on the inner edge will damage the sealing lip.

### Oil seal types and markings

- Oil seals are usually of the single-lipped type. Double-lipped seals are found where a liquid or gas is on both sides of the joint.
- Oil seals can harden and lose their sealing ability if the motorcycle has been in storage for a long period - renewal is the only solution.
- Oil seal manufacturers also conform to the ISO markings for seal size - these are moulded into the outer face of the seal (see illustration 6.2).



6.2 These oil seal markings indicate inside diameter, outside diameter and seal thickness

## 7 Gaskets and sealants

### Types of gasket and sealant

- Gaskets are used to seal the mating surfaces between components and keep lubricants, fluids, vacuum or pressure contained within the assembly. Aluminium gaskets are sometimes found at the cylinder joints, but most gaskets are paper-based. If the mating surfaces of the components being joined are undamaged the gasket can be installed dry, although a dab of sealant or grease will be useful to hold it in place during assembly.
- RTV (Room Temperature Vulcanising) silicone rubber sealants cure when exposed to moisture in the atmosphere. These sealants are good at filling pits or irregular gasket faces, but will tend to be forced out of the joint under very high torque. They can be used to replace a paper gasket, but first make sure that the width of the paper gasket is not essential to the shimming of internal components. RTV sealants should not be used on components containing petrol (gasoline).
- Non-hardening, semi-hardening and hard setting liquid gasket compounds can be used with a gasket or between a metal-to-metal joint. Select the sealant to suit the application: universal non-hardening sealant can be used on virtually all joints; semi-hardening on joint faces which are rough or damaged; hard setting sealant on joints which require a permanent bond and are subjected to high temperature and pressure. **Note:** Check first if the paper gasket has a bead of sealant

impregnated in its surface before applying additional sealant.

- When choosing a sealant, make sure it is suitable for the application, particularly if being applied in a high-temperature area or in the vicinity of fuel. Certain manufacturers produce sealants in either clear, silver or black colours to match the finish of the engine. This has a particular application on motorcycles where much of the engine is exposed.
- Do not over-apply sealant. That which is squeezed out on the outside of the joint can be wiped off, whereas an excess of sealant on the inside can break off and clog oilways.

### Breaking a sealed joint

- Age, heat, pressure and the use of hard setting sealant can cause two components to stick together so tightly that they are difficult to separate using finger pressure alone. Do not resort to using levers unless there is a pry point provided for this purpose (see illustration 7.1) or else the gasket surfaces will be damaged.
- Use a soft-faced hammer (see illustration 7.2) or a wood block and conventional hammer to strike the component near the mating surface. Avoid hammering against cast extremities since they may break off. If this method fails, try using a wood wedge between the two components.

**Caution:** If the joint will not separate, double-check that you have removed all the fasteners.



7.1 If a pry point is provided, apply gently pressure with a flat-bladed screwdriver



7.2 Tap around the joint with a soft-faced mallet if necessary - don't strike cooling fins

### Removal of old gasket and sealant

- Paper gaskets will most likely come away complete, leaving only a few traces stuck on




**HAYNES HINT**  
Most components have one or two hollow locating dowels between the two gasket faces. If a dowel cannot be removed, do not resort to gripping it with pliers - it will almost certainly be distorted. Install a close-fitting socket or Phillips screwdriver into the dowel and then grip the outer edge of the dowel to free it.

the sealing faces of the components. It is imperative that all traces are removed to ensure correct sealing of the new gasket.

- Very carefully scrape all traces of gasket away making sure that the sealing surfaces are not gouged or scored by the scraper (see illustrations 7.3, 7.4 and 7.5). Stubborn deposits can be removed by spraying with an aerosol gasket remover. Final preparation of




7.3 Paper gaskets can be scraped off with a gasket scraper tool ...




7.4 ... a knife blade ...



7.5 ... or a household scraper



**8.8 Assemble the chain riveting tool over one pin at a time and tighten it fully**



**8.9 Pin end correctly riveted (A), pin end unriveted (B)**

the rivet ends and two pieces of the wood between a G-clamp. Operate the clamp to press the sideplate over the pins.

● Assemble the joining tool over one pin (following the maker's instructions) and tighten the tool down to spread the pin end securely (see illustrations 8.8 and 8.9). Do the same on the other pin.

**Warning:** Check that the pin ends are secure and that there is no danger of the sideplate coming loose. If the pin ends are cracked the soft link must be renewed.


## Final drive chain sizing

● Chains are sized using a three digit number, followed by a suffix to denote the chain type (see illustration 8.10). Chain type is either standard or heavy duty (thicker sideplates), and also unsealed or O-ring/X-ring type.

● The first digit of the number relates to the pitch of the chain, ie the distance from the centre of one pin to the centre of the next pin (see illustration 8.11). Pitch is expressed in eighths of an inch, as follows:



**8.10 Typical chain size and type marking**



**8.11 Chain dimensions**

Sizes commencing with a 4 (eg 428) have a pitch of 1/2 inch (12.7 mm)

Sizes commencing with a 5 (eg 520) have a pitch of 5/8 inch (15.9 mm)

Sizes commencing with a 6 (eg 630) have a pitch of 3/4 inch (19.1 mm)

● The second and third digits of the chain size relate to the width of the rollers, again in imperial units, eg the 525 shown has 5/16 inch (7.94 mm) rollers (see illustration 8.11).


## 9 Hoses

### Clamping to prevent flow

● Small-bore flexible hoses can be clamped to prevent fluid flow whilst a component is worked on. Whichever method is used, ensure that the hose material is not permanently distorted or damaged by the clamp.

a) A brake hose clamp available from auto accessory shops (see illustration 9.1).

b) A wingnut type hose clamp (see illustration 9.2).




**9.1 Hoses can be clamped with an automotive brake hose clamp ...**



**9.2 ... a wingnut type hose clamp ...**

c) Two sockets placed each side of the hose and held with straight-jawed self-locking grips (see illustration 9.3).

d) Thick card each side of the hose held between straight-jawed self-locking grips (see illustration 9.4).



**9.3 ... two sockets and a pair of self-locking grips ...**



**9.4 ... or thick card and self-locking grips**

### Freeing and fitting hoses

● Always make sure the hose clamp is moved well clear of the hose end. Grip the hose with your hand and rotate it whilst pulling it off the union. If the hose has hardened due to age and will not move, slit it with a sharp knife and peel its ends off the union (see illustration 9.5).

● Resist the temptation to use grease or soap on the unions to aid installation; although it helps the hose slip over the union it will equally aid the escape of fluid from the joint. It is preferable to soften the hose ends in hot water and wet the inside surface of the hose with water or a fluid which will evaporate.



**9.5 Cutting a coolant hose free with a sharp knife**

## About the MOT Test

In the UK, all vehicles more than three years old are subject to an annual test to ensure that they meet minimum safety requirements. A current test certificate must be issued before a machine can be used on public roads, and is required before a road fund licence can be issued. Riding without a current test certificate will also invalidate your insurance.

For most owners, the MOT test is an annual cause for anxiety, and this is largely due to owners not being sure what needs to be checked prior to submitting the motorcycle for testing. The simple answer is that a fully roadworthy motorcycle will have no difficulty in passing the test.

This is a guide to getting your motorcycle through the MOT test. Obviously it will not be possible to examine the motorcycle to the same standard as the professional MOT

tester, particularly in view of the equipment required for some of the checks. However, working through the following procedures will enable you to identify any problem areas before submitting the motorcycle for the test.

It has only been possible to summarise the test requirements here, based on the regulations in force at the time of printing. Test standards are becoming increasingly stringent, although there are some exemptions for older vehicles. More information about the MOT test can be obtained from the HMSO publications, *How Safe is your Motorcycle* and *The MOT Inspection Manual for Motorcycle Testing*.

Many of the checks require that one of the wheels is raised off the ground. If the motorcycle doesn't have a centre stand, note that an auxiliary stand will be required. Additionally, the help of an assistant may prove useful.

Certain exceptions apply to machines under 50 cc, machines without a lighting system, and Classic bikes - if in doubt about any of the requirements listed below seek confirmation from an MOT tester prior to submitting the motorcycle for the test.

Check that the frame number is clearly visible.

**HAYNES  
HINT**

*If a component is in borderline condition, the tester has discretion in deciding whether to pass or fail it. If the motorcycle presented is clean and evidently well cared for, the tester may be more inclined to pass a borderline component than if the motorcycle is scruffy and apparently neglected.*

## Electrical System

### Lights, turn signals, horn and reflector

✓ With the ignition on, check the operation of the following electrical components. **Note:** The electrical components on certain small-capacity machines are powered by the generator, requiring that the engine is run for this check.

- a) **Headlight and tail light.** Check that both illuminate in the low and high beam switch positions.
  - b) **Position lights.** Check that the front position (or sidelight) and tail light illuminate in this switch position.
  - c) **Turn signals.** Check that all flash at the correct rate, and that the warning light(s) function correctly. Check that the turn signal switch works correctly.
  - c) **Hazard warning system (where fitted).** Check that all four turn signals flash in this switch position.
  - d) **Brake stop light.** Check that the light comes on when the front and rear brakes are independently applied. Models first used on or after 1st April 1986 must have a brake light switch on each brake.
  - e) **Horn.** Check that the sound is continuous and of reasonable volume.
- ✓ Check that there is a red reflector on the rear of the machine, either mounted separately or as part of the tail light lens.
- ✓ Check the condition of the headlight, tail light and turn signal lenses.

### Headlight beam height


✓ The MOT tester will perform a headlight beam height check using specialised beam setting equipment (see illustration 1). This equipment will not be available to the home mechanic, but if you suspect that the headlight is incorrectly set or may have been maladjusted in the past, you can perform a rough test as follows.

✓ Position the bike in a straight line facing a brick wall. The bike must be off its stand, upright and with a rider seated. Measure the height from the ground to the centre of the headlight and mark a horizontal line on the wall at this height. Position the motorcycle 3.8 metres from the wall and draw a vertical



**Headlight beam height checking equipment**

line up the wall central to the centreline of the motorcycle. Switch to dipped beam and check that the beam pattern falls slightly lower than the horizontal line and to the left of the vertical line (see illustration 2).



**Home workshop beam alignment check**



Checking for rear suspension linkage play

- ✓ Visually inspect the shock absorber(s) and check that there is no sign of oil leakage from its damper. This is somewhat restricted on certain single shock models due to the location of the shock absorber.
- ✓ With the rear wheel raised off the ground, grasp the wheel at the highest point



Worn suspension linkage pivots (arrows) are usually the cause of play in the rear suspension

and attempt to pull it up (see illustration 8). Any play in the swingarm pivot or suspension linkage bearings will be felt as movement. **Note:** Do not confuse play with actual suspension movement. Failure to lubricate suspension linkage bearings can lead to bearing failure (see illustration 9).



Grasp the swingarm at the ends to check for play in its pivot bearings

- ✓ With the rear wheel raised off the ground, grasp the swingarm ends and attempt to move the swingarm from side to side and forwards and backwards - any play indicates wear of the swingarm pivot bearings (see illustration 10).

## Brakes, Wheels and Tyres

### Brakes

- ✓ With the wheel raised off the ground, apply the brake then free it off, and check that the wheel is about to revolve freely without brake drag.
- ✓ On disc brakes, examine the disc itself. Check that it is securely mounted and not cracked.
- ✓ On disc brakes, view the pad material through the caliper mouth and check that the pads are not worn down beyond the limit (see illustration 11).
- ✓ On drum brakes, check that when the brake is applied the angle between the operating lever and cable or rod is not too great (see illustration 12). Check also that the operating lever doesn't foul any other components.

✓ On disc brakes, examine the flexible hoses from top to bottom. Have an assistant hold the brake on so that the fluid in the hose is under pressure, and check that there is no sign of fluid leakage, bulges or cracking. If there are any metal brake pipes or unions, check that these are free from corrosion and damage. Where a brake-linked anti-dive system is fitted, check the hoses to the anti-dive in a similar manner.

✓ Check that the rear brake torque arm is secure and that its fasteners are secured by self-locking nuts or castellated nuts with split-pins or R-pins (see illustration 13).


✓ On models with ABS, check that the self-check warning light in the instrument panel works.

✓ The MOT tester will perform a test of the motorcycle's braking efficiency based on a calculation of rider and motorcycle weight. Although this cannot be carried out at home, you can at least ensure that the braking

systems are properly maintained. For hydraulic disc brakes, check the fluid level, lever/pedal feel (bleed of air if its spongy) and pad material. For drum brakes, check adjustment, cable or rod operation and shoe lining thickness.

### Wheels and tyres

- ✓ Check the wheel condition. Cast wheels should be free from cracks and if of the built-up design, all fasteners should be secure. Spoked wheels should be checked for broken, corroded, loose or bent spokes.
- ✓ With the wheel raised off the ground, spin the wheel and visually check that the tyre and wheel run true. Check that the tyre does not foul the suspension or mudguards.



Brake pad wear can usually be viewed without removing the caliper. Most pads have wear indicator grooves (1) and some also have indicator tangs (2)



On drum brakes, check the angle of the operating lever with the brake fully applied. Most drum brakes have a wear indicator pointer and scale.



Brake torque arm must be properly secured at both ends

## Preparing for storage

### Before you start

If repairs or an overhaul is needed, see that this is carried out now rather than left until you want to ride the bike again.

Give the bike a good wash and scrub all dirt from its underside. Make sure the bike dries completely before preparing for storage.

### Engine

● Remove the spark plug(s) and lubricate the cylinder bores with approximately a teaspoon of motor oil using a spout-type oil can (see illustration 1). Reinstall the spark plug(s). Crank the engine over a couple of times to coat the piston rings and bores with oil. If the bike has a kickstart, use this to turn the engine over. If not, flick the kill switch to the OFF position and crank the engine over on the starter (see illustration 2). If the nature on the ignition system prevents the starter operating with the kill switch in the OFF position,



Squirt a drop of motor oil into each cylinder



Flick the kill switch to OFF . . .



. . . and ensure that the metal bodies of the plugs (arrows) are earthed against the cylinder head

remove the spark plugs and fit them back in their caps; ensure that the plugs are earthed (grounded) against the cylinder head when the starter is operated (see illustration 3).



**Warning:** It is important that the plugs are earthed (grounded) away from the spark plug holes otherwise there is a risk of atomised fuel from the cylinders igniting.



On a single cylinder four-stroke engine, you can seal the combustion chamber completely by positioning the piston at TDC on the compression stroke.



Connect a hose to the carburettor float chamber drain stub (arrow) and unscrew the drain screw

● Drain the carburettor(s) otherwise there is a risk of jets becoming blocked by gum deposits from the fuel (see illustration 4).

● If the bike is going into long-term storage, consider adding a fuel stabiliser to the fuel in the tank. If the tank is drained completely, corrosion of its internal surfaces may occur if left unprotected for a long period. The tank can be treated with a rust preventative especially for this purpose. Alternatively, remove the tank and pour half a litre of motor oil into it, install the filler cap and shake the tank to coat its internals with oil before draining off the excess. The same effect can also be achieved by spraying WD40 or a similar water-dispersant around the inside of the tank via its flexible nozzle.

● Make sure the cooling system contains the correct mix of antifreeze. Antifreeze also contains important corrosion inhibitors.


● The air intakes and exhaust can be sealed off by covering or plugging the openings. Ensure that you do not seal in any condensation; run the engine until it is hot, then switch off and allow to cool. Tape a piece of thick plastic over the silencer end(s) (see illustration 5). Note that some advocate pouring a tablespoon of motor oil into the silencer(s) before sealing them off.



Exhausts can be sealed off with a plastic bag

### Battery

● Remove it from the bike - in extreme cases of cold the battery may freeze and crack its case (see illustration 6).




Disconnect the negative lead (A) first, followed by the positive lead (B)

● Check the electrolyte level and top up if necessary (conventional refillable batteries). Clean the terminals.

● Store the battery off the motorcycle and away from any sources of fire. Position a wooden block under the battery if it is to sit on the ground.

● Give the battery a trickle charge for a few hours every month (see illustration 7).



Use a suitable battery charger - this kit also assess battery condition

This Section provides an easy reference-guide to the more common faults that are likely to afflict your machine. Obviously, the opportunities are almost limitless for faults to occur as a result of obscure failures, and to try and cover all eventualities would require a book. Indeed, a number have been written on the subject.

Successful troubleshooting is not a mysterious 'black art' but the application of a bit of knowledge combined with a systematic and logical approach to the problem. Approach any troubleshooting by first accurately identifying the symptom and then checking through the list

of possible causes, starting with the simplest or most obvious and progressing in stages to the most complex.

Take nothing for granted, but above all apply liberal quantities of common sense.

The main symptom of a fault is given in the text as a major heading below which are listed the various systems or areas which may contain the fault. Details of each possible cause for a fault and the remedial action to be taken are given, in brief, in the paragraphs below each heading. Further information should be sought in the relevant Chapter.

## 1 Engine doesn't start or is difficult to start

- ☐ Starter motor doesn't rotate
- ☐ Starter motor rotates but engine does not turn over
- ☐ Starter works but engine won't turn over (seized)
- ☐ No fuel flow
- ☐ Engine flooded
- ☐ No spark or weak spark
- ☐ Compression low
- ☐ Stalls after starting
- ☐ Rough idle

## 2 Poor running at low speed

- ☐ Spark weak
- ☐ Fuel/air mixture incorrect
- ☐ Compression low
- ☐ Poor acceleration

## 3 Poor running or no power at high speed

- ☐ Firing incorrect
- ☐ Fuel/air mixture incorrect
- ☐ Compression low
- ☐ Knocking or pinging
- ☐ Miscellaneous causes

## 4 Overheating

- ☐ Engine overheats
- ☐ Firing incorrect
- ☐ Fuel/air mixture incorrect
- ☐ Compression too high
- ☐ Engine load excessive
- ☐ Lubrication inadequate
- ☐ Miscellaneous causes

## 5 Clutch problems

- ☐ Clutch slipping
- ☐ Clutch not disengaging completely

## 6 Gearchange problems

- ☐ Doesn't go into gear, or lever doesn't return
- ☐ Jumps out of gear
- ☐ Overselects

## 7 Abnormal engine noise

- ☐ Knocking or pinking
- ☐ Piston slap or rattling
- ☐ Valve noise
- ☐ Other noise

## 8 Abnormal driveline noise

- ☐ Clutch noise
- ☐ Transmission noise
- ☐ Final drive noise

## 9 Abnormal frame and suspension noise

- ☐ Front end noise
- ☐ Shock absorber noise
- ☐ Brake noise

## 10 Oil pressure warning light comes on

- ☐ Engine lubrication system
- ☐ Electrical system

## 11 Excessive exhaust smoke

- ☐ White smoke
- ☐ Black smoke
- ☐ Brown smoke

## 12 Poor handling or stability

- ☐ Handlebar hard to turn
- ☐ Handlebar shakes or vibrates excessively
- ☐ Handlebar pulls to one side
- ☐ Poor shock absorbing qualities

## 13 Braking problems

- ☐ Brakes are spongy, don't hold
- ☐ Brake lever or pedal pulsates
- ☐ Brakes drag

## 14 Electrical problems

- ☐ Battery dead or weak
- ☐ Battery overcharged

## 4 Overheating

### Engine overheats

- ☐ Coolant level low. Check and add coolant (Chapter 1).
- ☐ Leak in cooling system. Check cooling system hoses and radiator for leaks and other damage. Repair or replace parts as necessary (Chapter 3).
- ☐ Thermostat sticking open or closed. Check and replace as described in Chapter 3.
- ☐ Faulty radiator cap. Remove the cap and have it pressure tested.
- ☐ Coolant passages clogged. Drain and flush the cooling system, then refill with fresh coolant (Chapter 1).
- ☐ Water pump defective. Remove the pump and check the components (Chapter 3).
- ☐ Clogged radiator fins. Clean them by blowing compressed air through the fins from the rear of the radiator.
- ☐ Cooling fan or fan switch fault (Chapter 3).

### Firing incorrect

- ☐ Spark plugs fouled, defective or worn out. See Chapter 1 for spark plug maintenance.
- ☐ Incorrect spark plugs.
- ☐ Ignition control unit defective. See Chapter 5.
- ☐ Faulty ignition HT coils (Chapter 5).

### Fuel/air mixture incorrect

- ☐ Main jet clogged. Dirt, water and other contaminants can clog the main jets. Clean the fuel tap filter, the float chamber area and the jets and carburettor orifices (Chapter 4).
- ☐ Main jet wrong size. The standard jetting is for sea level atmospheric pressure and oxygen content.
- ☐ Air filter clogged, poorly sealed or missing (Chapter 1).
- ☐ Air filter housing poorly sealed. Look for cracks, holes or loose clamps and replace or repair.
- ☐ Fuel level too low. Check float height (Chapter 4).
- ☐ Fuel tank breather hose obstructed.
- ☐ Carburettor inlet manifolds loose. Check for cracks, breaks, tears or loose clamps. Replace the rubber inlet manifold joints if split or perished.

### Compression too high

- ☐ Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder heads will have to be removed and decarbonised (Chapter 2).
- ☐ Improperly machined head surface or installation of incorrect gasket during engine assembly.

### Engine load excessive

- ☐ Clutch slipping. Can be caused by damaged, loose or worn clutch components. Refer to Chapter 2 for overhaul procedures.
- ☐ Engine oil level too high. The addition of too much oil will cause pressurisation of the crankcase and inefficient engine operation. Check Specifications and drain to proper level (Chapter 1).
- ☐ Engine oil viscosity too high. Using a heavier oil than the one recommended in Chapter 1 can damage the oil pump or lubrication system as well as cause drag on the engine.
- ☐ Brakes dragging. Usually caused by debris which has entered the brake piston seals, or from a warped disc or bent axle. Repair as necessary.

### Lubrication inadequate

- ☐ Engine oil level too low. Friction caused by intermittent lack of lubrication or from oil that is overworked can cause overheating. The oil provides a definite cooling function in the engine. Check the oil level (Chapter 1).
- ☐ Poor quality engine oil or incorrect viscosity or type. Oil is rated not only according to viscosity but also according to type. Some oils are not rated high enough for use in this engine. Check the Specifications section and change to the correct oil (Chapter 1).

### Miscellaneous causes

- ☐ Modification to exhaust system. Most aftermarket exhaust systems cause the engine to run leaner, which make them run hotter. When installing an accessory exhaust system, always reject the carburettors.

## 5 Clutch problems

### Clutch slipping

- ☐ Insufficient clutch cable freeplay. Check and adjust (Chapter 1).
- ☐ Friction plates worn or warped. Overhaul the clutch assembly (Chapter 2).
- ☐ Plain plates warped (Chapter 2).
- ☐ Clutch springs broken or weak. Old or heat-damaged (from slipping clutch) springs should be replaced with new ones (Chapter 2).
- ☐ Clutch release mechanism defective. Replace any defective parts (Chapter 2).
- ☐ Clutch centre or housing unevenly worn. This causes improper engagement of the plates. Replace the damaged or worn parts (Chapter 2).

### Clutch not disengaging completely

- ☐ Excessive clutch cable freeplay. Check and adjust (Chapter 1).
- ☐ Clutch plates warped or damaged. This will cause clutch drag, which in turn will cause the machine to creep. Overhaul the clutch assembly (Chapter 2).

- ☐ Engine oil deteriorated. Old, thin, worn out oil will not provide proper lubrication for the plates, causing the clutch to drag. Replace the oil and filter (Chapter 1).
- ☐ Engine oil viscosity too high. Using a heavier oil than recommended in Chapter 1 can cause the plates to stick together, putting a drag on the engine. Change to the correct weight oil (Chapter 1).
- ☐ Clutch housing guide seized on mainshaft. Lack of lubrication, severe wear or damage can cause the guide to seize on the shaft. Overhaul of the clutch, and perhaps transmission, may be necessary to repair the damage (Chapter 2).
- ☐ Clutch release mechanism defective. Overhaul the clutch cover components (Chapter 2).
- ☐ Loose clutch centre nut. Causes housing and centre misalignment putting a drag on the engine. Engagement adjustment continually varies. Overhaul the clutch assembly (Chapter 2).

## 9 Abnormal frame and suspension noise

### Front end noise

- ☐ Low fluid level or improper viscosity oil in forks. This can sound like spurting and is usually accompanied by irregular fork action (Chapter 6).
- ☐ Spring weak or broken. Makes a clicking or scraping sound. Fork oil, when drained, will have a lot of metal particles in it (Chapter 6).
- ☐ Steering head bearings loose or damaged. Clicks when braking. Check and adjust or replace as necessary (Chapters 1 and 6).
- ☐ Fork yokes loose. Make sure all clamp pinch bolts are tightened to the specified torque (Chapter 6).
- ☐ Fork tube bent. Good possibility if machine has been dropped. Replace tube with a new one (Chapter 6).
- ☐ Front axle bolt or axle clamp bolts loose. Tighten them to the specified torque (Chapter 7).
- ☐ Loose or worn wheel bearings. Check and replace as needed (Chapter 7).

### Shock absorber noise

- ☐ Fluid level incorrect. Indicates a leak caused by defective seal. Shock will be covered with oil. Replace shock or seek advice on repair from a Honda dealer (Chapter 6).
- ☐ Defective shock absorber with internal damage. This is in the body of the shock and can't be remedied. The shock must be replaced with a new one (Chapter 6).

- ☐ Bent or damaged shock body. Replace the shock with a new one (Chapter 6).
- ☐ Loose or worn suspension linkage components. Check and replace as necessary (Chapter 6).

### Brake noise

- ☐ Squeal caused by dust on brake pads. Usually found in combination with glazed pads. Clean using brake cleaning solvent (Chapter 7).
- ☐ Contamination of brake pads. Oil, brake fluid or dirt causing brake to chatter or squeal. Clean or replace pads (Chapter 7).
- ☐ Pads glazed. Caused by excessive heat from prolonged use or from contamination. Do not use sandpaper, emery cloth, carborundum cloth or any other abrasive to roughen the pad surfaces as abrasives will stay in the pad material and damage the disc. A very fine flat file can be used, but pad replacement is suggested as a cure (Chapter 7).
- ☐ Disc warped. Can cause a chattering, clicking or intermittent squeal. Usually accompanied by a pulsating lever and uneven braking. Replace the disc (Chapter 7).
- ☐ Loose or worn wheel bearings. Check and replace as needed (Chapter 7).

## 10 Oil pressure warning light comes on

### Engine lubrication system

- ☐ Engine oil pump defective, blocked oil strainer gauze or failed relief valve. Carry out oil pressure check (Chapter 2).
- ☐ Engine oil level low. Inspect for leak or other problem causing low oil level and add recommended oil (Chapter 1).
- ☐ Engine oil viscosity too low. Very old, thin oil or an improper weight of oil used in the engine. Change to correct oil (Chapter 1).
- ☐ Camshaft or journals worn. Excessive wear causing drop in oil pressure. Replace cam and/or cylinder head. Abnormal wear could be caused by oil starvation at high rpm from low oil level or improper weight or type of oil (Chapter 1).

- ☐ Crankshaft and/or bearings worn. Same problems as above. Check and replace crankshaft and/or bearings (Chapter 2).

### Electrical system

- ☐ Oil pressure switch defective. Check the switch according to the procedure in Chapter 9. Replace it if it is defective.
- ☐ Oil pressure warning light circuit defective. Check for pinched, shorted, disconnected or damaged wiring (Chapter 9).

## 11 Excessive exhaust smoke

### White smoke

- ☐ Piston oil ring worn. The ring may be broken or damaged, causing oil from the crankcase to be pulled past the piston into the combustion chamber. Replace the rings with new ones (Chapter 2).
- ☐ Cylinders worn, cracked, or scored. Caused by overheating or oil starvation. The crankcase/bore will have to be renewed, no oversizes are available.
- ☐ Valve oil seal damaged or worn. Replace oil seals with new ones (Chapter 2).
- ☐ Valve guide worn. Perform a complete valve job (Chapter 2).
- ☐ Engine oil level too high, which causes the oil to be forced past the rings. Drain oil to the proper level (Chapter 1).
- ☐ Head gasket broken between oil return and cylinder. Causes oil to be pulled into the combustion chamber. Replace the head gasket and check the head for warpage (Chapter 2).
- ☐ Abnormal crankcase pressurisation, which forces oil past the rings. Clogged breather is usually the cause.

### Black smoke

- ☐ Air filter clogged. Clean or replace the element (Chapter 1).

- ☐ Main jet too large or loose. Compare the jet size to the Specifications (Chapter 4).
- ☐ Choke cable or linkage shaft stuck, causing fuel to be pulled through choke circuit (Chapter 4).
- ☐ Fuel level too high. Check and adjust the float height(s) as necessary (Chapter 4).
- ☐ Float needle valve held off needle seat. Clean the float chambers and fuel line and replace the needles and seats if necessary (Chapter 4).

### Brown smoke

- ☐ Main jet too small or clogged. Lean condition caused by wrong size main jet or by a restricted orifice. Clean float chambers and jets and compare jet size to Specifications (Chapter 4).
- ☐ Fuel flow insufficient. Float needle valve stuck closed due to chemical reaction with old fuel. Float height incorrect. Restricted fuel line. Clean line and float chamber and adjust floats if necessary.
- ☐ Carburettor inlet manifold clamps loose (Chapter 4).
- ☐ Air filter poorly sealed or not installed (Chapter 1).

## 14 Electrical problems

### Battery dead or weak

- ☐ Battery faulty. Caused by sulphated plates which are shorted through sedimentation. Also, broken battery terminal making only occasional contact (Chapter 9).
- ☐ Battery cables making poor contact (Chapter 9).
- ☐ Load excessive. Caused by addition of high wattage lights or other electrical accessories.
- ☐ Ignition (main) switch defective. Switch either grounds (earths) internally or fails to shut off system. Replace the switch (Chapter 9).
- ☐ Regulator/rectifier defective (Chapter 9).

- ☐ Alternator stator coil open or shorted (Chapter 9).
- ☐ Wiring faulty. Wiring grounded (earthed) or connections loose in ignition, charging or lighting circuits (Chapter 9).

### Battery overcharged

- ☐ Regulator/rectifier defective. Overcharging is noticed when battery gets excessively warm (Chapter 9).
- ☐ Battery defective. Replace battery with a new one (Chapter 9).
- ☐ Battery amperage too low, wrong type or size. Install manufacturer's specified amp-hour battery to handle charging load (Chapter 9).

## Fault Finding Equipment

### Checking engine compression

- Low compression will result in exhaust smoke, heavy oil consumption, poor starting and poor performance. A compression test will provide useful information about an engine's condition and if performed regularly, can give warning of trouble before any other symptoms become apparent.
- A compression gauge will be required, along with an adapter to suit the spark plug hole thread size. Note that the screw-in type gauge/adapter set up is preferable to the rubber cone type.

- Before carrying out the test, first check the valve clearances as described in Chapter 1.
- 1 Run the engine until it reaches normal operating temperature, then stop it and remove the spark plug(s), taking care not to scald your hands on the hot components.
- 2 Install the gauge adapter and compression gauge in No. 1 cylinder spark plug hole (see illustration 1).
- 3 On kickstart-equipped motorcycles, make sure the ignition switch is OFF, then open the throttle fully and kick the engine over a couple of times until the gauge reading stabilises.
- 4 On motorcycles with electric start only, the procedure will differ depending on the nature of the ignition system. Flick the engine kill switch (engine stop switch) to OFF and turn



**Screw the compression gauge adapter into the spark plug hole, then screw the gauge into the adapter**

## A

**ABS (Anti-lock braking system)** A system, usually electronically controlled, that senses incipient wheel lockup during braking and relieves hydraulic pressure at wheel which is about to skid.

**Aftermarket** Components suitable for the motorcycle, but not produced by the motorcycle manufacturer.

**Allen key** A hexagonal wrench which fits into a recessed hexagonal hole.

**Alternating current (ac)** Current produced by an alternator. Requires converting to direct current by a rectifier for charging purposes.

**Alternator** Converts mechanical energy from the engine into electrical energy to charge the battery and power the electrical system.

**Ampere (amp)** A unit of measurement for the flow of electrical current.  $\text{Current} = \text{Volts} \div \text{Ohms}$ .

**Ampere-hour (Ah)** Measure of battery capacity.

**Angle-tightening** A torque expressed in degrees. Often follows a conventional tightening torque for cylinder head or main bearing fasteners (see illustration).



Angle-tightening cylinder head bolts

**Antifreeze** A substance (usually ethylene glycol) mixed with water, and added to the cooling system, to prevent freezing of the coolant in winter. Antifreeze also contains chemicals to inhibit corrosion and the formation of rust and other deposits that would tend to clog the radiator and coolant passages and reduce cooling efficiency.

**Anti-dive** System attached to the fork lower leg (slider) to prevent fork dive when braking hard.

**Anti-seize compound** A coating that reduces the risk of seizing on fasteners that are subjected to high temperatures, such as exhaust clamp bolts and nuts.

**API** American Petroleum Institute. A quality standard for 4-stroke motor oils.

**Asbestos** A natural fibrous mineral with great heat resistance, commonly used in the composition of brake friction materials. Asbestos is a health hazard and the dust created by brake systems should never be inhaled or ingested.

**ATF** Automatic Transmission Fluid. Often used in front forks.

**ATU** Automatic Timing Unit. Mechanical device for advancing the ignition timing on early engines.

**ATV** All Terrain Vehicle. Often called a Quad.

**Axial play** Side-to-side movement.

**Axle** A shaft on which a wheel revolves. Also known as a spindle.


## B

**Backlash** The amount of movement between meshed components when one component is held still. Usually applies to gear teeth.

**Ball bearing** A bearing consisting of a hardened inner and outer race with hardened steel balls between the two races.

**Bearings** Used between two working surfaces to prevent wear of the components and a build-up of heat. Four types of bearing are commonly used on motorcycles: plain shell bearings, ball bearings, tapered roller bearings and needle roller bearings.

**Bevel gears** Used to turn the drive through 90°. Typical applications are shaft final drive and camshaft drive (see illustration).



Bevel gears are used to turn the drive through 90°

**BHP** Brake Horsepower. The British measurement for engine power output. Power output is now usually expressed in kilowatts (kW).

**Bias-belted tyre** Similar construction to radial tyre, but with outer belt running at an angle to the wheel rim.

**Big-end bearing** The bearing in the end of the connecting rod that's attached to the crankshaft.

**Bleeding** The process of removing air from an hydraulic system via a bleed nipple or bleed screw.

**Bottom-end** A description of an engine's crankcase components and all components contained there-in.

**BTDC** Before Top Dead Centre in terms of piston position. Ignition timing is often expressed in terms of degrees or millimetres BTDC.

**Bush** A cylindrical metal or rubber component used between two moving parts.

**Burr** Rough edge left on a component after machining or as a result of excessive wear.

## C

**Cam chain** The chain which takes drive from the crankshaft to the camshaft(s).

**Canister** The main component in an evaporative emission control system (California market only); contains activated charcoal granules to trap vapours from the fuel system rather than allowing them to vent to the atmosphere.

**Castellated** Resembling the parapets along the top of a castle wall. For example, a castellated wheel axle or spindle nut.

**Catalytic converter** A device in the exhaust system of some machines which converts certain

pollutants in the exhaust gases into less harmful substances.

**Charging system** Description of the components which charge the battery, ie the alternator, rectifier and regulator.

**Circlip** A ring-shaped clip used to prevent endwise movement of cylindrical parts and shafts. An internal circlip is installed in a groove in a housing; an external circlip fits into a groove on the outside of a cylindrical piece such as a shaft. Also known as a snap-ring.

**Clearance** The amount of space between two parts. For example, between a piston and a cylinder, between a bearing and a journal, etc.

**Coil spring** A spiral of elastic steel found in various sizes throughout a vehicle, for example as a springing medium in the suspension and in the valve train.

**Compression** Reduction in volume, and increase in pressure and temperature, of a gas, caused by squeezing it into a smaller space.

**Compression damping** Controls the speed the suspension compresses when hitting a bump.

**Compression ratio** The relationship between cylinder volume when the piston is at top dead centre and cylinder volume when the piston is at bottom dead centre.

**Continuity** The uninterrupted path in the flow of electricity. Little or no measurable resistance.

**Continuity tester** Self-powered beeper or test light which indicates continuity.

**Cp** Candlepower. Bulb rating common found on US motorcycles.

**Crossply tyre** Tyre plies arranged in a criss-cross pattern. Usually four or six plies used, hence 4PR or 6PR in tyre size codes.

**Cush drive** Rubber damper segments fitted between the rear wheel and final drive sprocket to absorb transmission shocks (see illustration).



Cush drive rubbers dampen out transmission shocks

## D

**Degree disc** Calibrated disc for measuring piston position. Expressed in degrees.

**Dial gauge** Clock-type gauge with adapters for measuring runout and piston position. Expressed in mm or inches.

**Diaphragm** The rubber membrane in a master cylinder or carburettor which seals the upper chamber.

**Diaphragm spring** A single sprung plate often used in clutches.

**Direct current (dc)** Current produced by a dc generator.

## Specifications

The following specifications apply to the NC21 and NC24 models only. Identification details are as follows:

| Model          | Year | Code   | Engine no.               | Frame no.               | Carb ID |
|----------------|------|--------|--------------------------|-------------------------|---------|
| VFR400Z (NC21) | 1986 | ZG     | NC13E-1030098 to 1045640 | NC21-1000077 to 1015556 | VDA0A A |
| VFR400Z (NC21) | 1987 | ZH     | NC13E-1050034 to 1076150 | NC21-1020013 to 1021407 | VDE2A A |
| VFR400R (NC21) | 1986 | RG     | NC13E-1030017 to 1045836 | NC21-1000011 to 1015756 | VDA0A A |
| VFR400R (NC21) | 1986 | RG-YA  | NC13E-1030065 to 1042932 | NC21-1000074 to 1012861 | VDA0A A |
| VFR400R (NC24) | 1987 | RH     | NC13E-1050019 to 1075630 | NC24-1000010 to 1017050 | VDE2C A |
| VFR400R (NC24) | 1987 | RH-II  | NC13E-1059737 to 1069166 | NC24-1009051 to 1016630 | VDE2C A |
| VFR400R (NC24) | 1988 | RJ-III | NC13E-1070023 to 1082667 | NC24-1020011 to 1032667 | VDE2C E |

**Note:** Procedures for these models are not included in this manual – all preceding pages of this manual apply only to the NC30 and NC35 models.

## Engine, clutch and transmission

### General

|                      |                                  |
|----------------------|----------------------------------|
| Type                 | Four-stroke 90° V-four           |
| Capacity             | 399 cc                           |
| Bore                 | 55.0 mm                          |
| Stroke               | 42.0 mm                          |
| Compression ratio    |                                  |
| VFR400 RG and ZG     | 11.0 to 1                        |
| VFR400 RH, RJ and ZH | 11.3 to 1                        |
| Cylinder compression | 142 to 200 psi (9.8 to 13.8 Bar) |
| Firing order         | 1-3-2-4                          |
| Cylinder numbering   |                                  |
| Rear left            | 1                                |
| Front left           | 2                                |
| Rear right           | 3                                |
| Front right          | 4                                |
| Clutch               | Wet multi-plate                  |
| Transmission         | Six-speed constant mesh          |
| Final drive          | Chain                            |

### Camshafts

|                         |                     |
|-------------------------|---------------------|
| Inlet lobe height       |                     |
| Standard                | 31.05 to 31.21 mm   |
| Service limit (min)     | 31.01 mm            |
| Exhaust lobe height     |                     |
| Standard                | 31.11 to 31.27 mm   |
| Service limit (min)     | 31.07 mm            |
| Journal diameter        |                     |
| Standard                | 27.929 to 27.950 mm |
| Service limit (min)     | 27.925 mm           |
| Journal holder diameter |                     |
| Standard                | 28.000 to 28.021 mm |
| Service limit (max)     | 28.025 mm           |
| Journal oil clearance   |                     |
| Standard                | 0.050 to 0.092 mm   |
| Service limit (max)     | 0.096 mm            |
| Runout (max)            | 0.03 mm             |

### Cylinder head

|               |         |
|---------------|---------|
| Warping (max) | 0.10 mm |
|---------------|---------|

# VFR400Z and VFR400R (NC21, NC24) specifications REF•45

|                                        |                     |
|----------------------------------------|---------------------|
| Clutch housing ID at guide bore        |                     |
| Standard                               | 29.000 to 29.021 mm |
| Service limit (max)                    | 29.06 mm            |
| Clutch housing guide OD                |                     |
| Standard                               | 28.967 to 28.980 mm |
| Service limit (min)                    | 28.93 mm            |
| Clutch housing guide ID                |                     |
| Standard                               | 21.995 to 22.015 mm |
| Service limit (max)                    | 22.05 mm            |
| Master cylinder bore diameter          |                     |
| Standard                               | 14.000 to 14.043 mm |
| Service limit (max)                    | 14.055 mm           |
| Master cylinder piston diameter        |                     |
| Standard                               | 13.957 to 13.984 mm |
| Service limit (min)                    | 13.945 mm           |
| Release (slave) cylinder bore diameter |                     |
| Standard                               | 35.700 to 35.762 mm |
| Service limit (max)                    | 35.78 mm            |
| Master cylinder piston diameter        |                     |
| Standard                               | 35.650 to 35.675 mm |
| Service limit (min)                    | 35.62 mm            |

## Lubrication system

|                                                    |                                           |
|----------------------------------------------------|-------------------------------------------|
| Oil type                                           | API grade SE, SF or SG motor oil          |
| Oil viscosity                                      | SAE 10W40                                 |
| Oil capacity                                       |                                           |
| At oil change                                      | 2.4 litres                                |
| At oil and filter change                           | 2.6 litres                                |
| Following engine overhaul – dry engine, new filter |                                           |
| VFR400 R                                           | 3.1 litres                                |
| VFR400 Z                                           | 3.0 litres                                |
| Oil pressure (with engine warm)                    |                                           |
| VFR400 RG and ZG                                   | 76 psi (5.3 Bar) at 5000 rpm, oil at 80°C |
| VFR400 RH, RJ and ZH                               | 62 psi (4.3 Bar) at 5000 rpm, oil at 80°C |
| Oil pump                                           |                                           |
| Inner rotor tip-to-outer rotor clearance           |                                           |
| Standard                                           | 0.15 mm                                   |
| Service limit (max)                                | 0.20 mm                                   |
| Outer rotor-to-body clearance                      |                                           |
| Standard                                           | 0.15 to 0.21 mm                           |
| Service limit (max)                                | 0.35 mm                                   |
| Rotor endfloat                                     |                                           |
| Standard                                           | 0.04 to 0.09 mm                           |
| Service limit (max)                                | 0.12 mm                                   |
| Oil pump drive sprocket ID                         |                                           |
| Standard                                           | 29.025 to 29.075 mm                       |
| Service limit (max)                                | 29.11 mm                                  |

## Cylinder block

|                              |                     |
|------------------------------|---------------------|
| Bore                         |                     |
| Standard                     | 55.000 to 55.015 mm |
| Service limit (max)          | 55.10 mm            |
| Warpage (max)                | 0.10 mm             |
| Ovality (out-of-round) (max) | 0.10 mm             |
| Taper (max)                  | 0.10 mm             |

## Connecting rods

|                                   |                     |
|-----------------------------------|---------------------|
| Small-end internal diameter       |                     |
| Standard                          | 14.016 to 14.034 mm |
| Service limit (max)               | 14.05 mm            |
| Small-end-to-piston pin clearance |                     |
| Standard                          | 0.016 to 0.040 mm   |
| Service limit (max)               | 0.06 mm             |
| Big-end side clearance            |                     |
| Standard                          | 0.1 to 0.3 mm       |
| Service limit (max)               | 0.4 mm              |
| Big-end oil clearance             |                     |
| Standard                          | 0.028 to 0.052 mm   |
| Service limit (max)               | 0.07 mm             |

# VFR400Z and VFR400R (NC21, NC24) specifications REF•47

|                                                                   |                     |
|-------------------------------------------------------------------|---------------------|
| <b>Input shaft OD at 5th gear bush point</b>                      |                     |
| Standard .....                                                    | 21.959 to 21.980 mm |
| Service limit (min) .....                                         | 21.92 mm            |
| <b>Input shaft-to-bush clearance at 5th gear bush point</b>       |                     |
| Standard .....                                                    | 0.005 to 0.047 mm   |
| Service limit (max) .....                                         | 0.10 mm             |
| <b>Output shaft 2nd, 3rd and 4th gears ID</b>                     |                     |
| Standard .....                                                    | 28.000 to 28.021 mm |
| Service limit (max) .....                                         | 28.05 mm            |
| <b>Output shaft 2nd, 3rd and 4th gears bush OD</b>                |                     |
| Standard .....                                                    | 27.959 to 27.980 mm |
| Service limit (min) .....                                         | 27.92 mm            |
| <b>Output shaft 2nd, 3rd and 4th gears gear-to-bush clearance</b> |                     |
| Standard .....                                                    | 0.020 to 0.062 mm   |
| Service limit (max) .....                                         | 0.10 mm             |
| <b>Output shaft 2nd gear bush ID</b>                              |                     |
| Standard .....                                                    | 25.030 to 25.051 mm |
| Service limit (max) .....                                         | 25.051 mm           |
| <b>Output shaft OD at 2nd gear bush point</b>                     |                     |
| Standard .....                                                    | 25.002 to 25.015 mm |
| Service limit (min) .....                                         | 24.97 mm            |
| <b>Output shaft-to-bush clearance at 2nd gear bush point</b>      |                     |
| Standard .....                                                    | 0.015 to 0.049 mm   |
| Service limit (max) .....                                         | 0.081 mm            |

## Selector drum and forks

|                                    |                     |
|------------------------------------|---------------------|
| <b>Selector fork end thickness</b> |                     |
| Standard .....                     | 5.93 to 6.00 mm     |
| Service limit (min) .....          | 5.60 mm             |
| <b>Selector fork bore ID</b>       |                     |
| Standard .....                     | 12.000 to 12.021 mm |
| Service limit (max) .....          | 12.04 mm            |
| <b>Selector fork shaft OD</b>      |                     |
| Standard .....                     | 11.969 to 11.980 mm |
| Service limit (min) .....          | 11.90 mm            |

## Cooling system

### Coolant

|                           |                                                                          |
|---------------------------|--------------------------------------------------------------------------|
| Coolant type .....        | 50% distilled water, 50% corrosion inhibited ethylene glycol anti-freeze |
| <b>Coolant capacity</b>   |                                                                          |
| Radiator and engine ..... | 1.7 litres                                                               |
| Reservoir .....           | 0.25 litre                                                               |

### Radiator

|                                   |                                   |
|-----------------------------------|-----------------------------------|
| <b>Cap valve opening pressure</b> |                                   |
| VFR400 RG and ZG .....            | 10 to 15 psi (0.7 to 1.0 Bar)     |
| VFR400 RH, RJ and ZH .....        | 13.5 to 17.8 psi (0.9 to 1.2 Bar) |

### Fan switch

|                                      |             |
|--------------------------------------|-------------|
| Cooling fan cut-in temperature ..... | 95 to 105°C |
|--------------------------------------|-------------|

### Coolant temperature sensor

|                   |                   |
|-------------------|-------------------|
| <b>Resistance</b> |                   |
| @ 60°C .....      | 94 to 117 ohms    |
| @ 118°C .....     | 16 to 19 ohms     |
| @ 122°C .....     | 14.4 to 17.3 ohms |

### Thermostat

|                           |                   |
|---------------------------|-------------------|
| Opening temperature ..... | 80 to 84°C        |
| Valve lift .....          | 8 mm (min) @ 95°C |

## Suspension and final drive

### Front forks

|                                     |              |
|-------------------------------------|--------------|
| Fork oil type .....                 | 10W fork oil |
| Fork oil capacity .....             |              |
| VFR400 RG and ZG .....              |              |
| Right fork .....                    | 340 cc       |
| Left fork .....                     | 345 cc       |
| VFR400 RH, RJ and ZH .....          |              |
| Right fork .....                    | 389 cc       |
| Left fork .....                     | 392 cc       |
| Fork oil level* .....               |              |
| VFR400 RG and ZG .....              | 151 mm       |
| VFR400 RH, RJ and ZH .....          | 90 mm        |
| Fork spring free length (min) ..... |              |
| VFR400 RG and ZG .....              |              |
| Standard .....                      | 379.0 mm     |
| Service limit .....                 | 371.4 mm     |
| VFR400 RH, RJ and ZH .....          |              |
| Standard .....                      | 396.8 mm     |
| Service limit .....                 | 388.9 mm     |
| Fork tube runout limit .....        | 0.2 mm       |

\*Oil level is measured from the top of the tube with the fork spring removed and the leg fully compressed.

### Rear suspension

|                                         |          |
|-----------------------------------------|----------|
| Shock absorber spring free length ..... |          |
| Standard .....                          | 153.1 mm |
| Service limit .....                     | 150.0 mm |

### Final drive

|                               |                                                                              |
|-------------------------------|------------------------------------------------------------------------------|
| Drive chain slack .....       | 15 to 25 mm                                                                  |
| Drive chain lubricant .....   | SAE 80 or 90 gear oil, or aerosol chain lubricant suitable for O-ring chains |
| Drive chain size .....        | 525, 106 links                                                               |
| Sprocket sizes .....          |                                                                              |
| Front (engine) sprocket ..... | 15T                                                                          |
| Rear (wheel) sprocket .....   | 45T                                                                          |

## Brakes, wheels and tyres

### Brakes

|                                                        |                     |
|--------------------------------------------------------|---------------------|
| Brake fluid .....                                      | DOT 4               |
| Front caliper bore ID .....                            |                     |
| Standard .....                                         | 27.000 to 27.050 mm |
| Service limit .....                                    | 27.060 mm           |
| Front caliper piston OD .....                          |                     |
| Standard .....                                         | 26.918 to 26.968 mm |
| Service limit .....                                    | 26.910 mm           |
| Front disc minimum thickness .....                     |                     |
| VFR400 RG and ZG .....                                 |                     |
| Standard .....                                         | 3.8 to 4.2 mm       |
| Service limit .....                                    | 3.5 mm              |
| VFR400 RH, RJ and ZH .....                             |                     |
| Standard .....                                         | 4.3 to 4.7 mm       |
| Service limit .....                                    | 4.0 mm              |
| Disc maximum runout (front and rear, all models) ..... | 0.3 mm              |
| Front master cylinder bore ID .....                    |                     |
| Standard .....                                         | 14.000 to 14.043 mm |
| Service limit (max) .....                              | 14.055 mm           |
| Front master cylinder piston OD .....                  |                     |
| Standard .....                                         | 13.957 to 13.984 mm |
| Service limit (min) .....                              | 13.945 mm           |
| Rear caliper bore ID .....                             |                     |
| VFR400 RG and ZG .....                                 |                     |
| Standard .....                                         | 27.000 to 27.050 mm |
| Service limit (max) .....                              | 27.060 mm           |
| VFR400 RH, RJ and ZH .....                             |                     |
| Standard .....                                         | 38.180 to 38.230 mm |
| Service limit (max) .....                              | 38.240 mm           |

## Torque settings

### Specific components

|                                                             |         |
|-------------------------------------------------------------|---------|
| Oil drain plug                                              | 35 Nm   |
| Oil filter                                                  | 15 Nm   |
| Timing inspection cover                                     | 17.5 Nm |
| Engine mountings                                            |         |
| Adjuster bolt                                               | 11 Nm   |
| Adjuster bolt locknut                                       | 55 Nm   |
| Adjuster bolt nut                                           | 55 Nm   |
| Valve cover bolts                                           | 10 Nm   |
| Camshaft holder bolts                                       | 12 Nm   |
| Camshaft drive gear assemblies                              |         |
| Mounting bolts                                              | 32 Nm   |
| Crankcase bolt                                              | 12 Nm   |
| Cylinder head 6 mm bolts                                    | 12 Nm   |
| Cylinder head 8 mm bolts                                    | 32 Nm   |
| Starter clutch bolt                                         | 85 Nm   |
| Starter clutch cover bolts                                  | 28 Nm   |
| Clutch nut                                                  | 65 Nm   |
| Oil pump cover bolts                                        | 12 Nm   |
| Oil pump mounting bolts                                     | 12 Nm   |
| Crankcase 6 mm bolts                                        | 12 Nm   |
| Crankcase 8 mm bolts                                        | 23 Nm   |
| Crankcase 10 mm bolt                                        | 40 Nm   |
| Connecting rod cap nuts                                     | 24 Nm   |
| Handlebar holder clamp bolts                                | 27.5 Nm |
| Top yoke fork clamp bolts                                   | 11 Nm   |
| Bottom yoke fork clamp bolts                                | 35 Nm   |
| Steering stem nut                                           | 105 Nm  |
| Fork damper rod bolt                                        | 30 Nm   |
| Fork top bolt                                               | 22 Nm   |
| Shock absorber mounting bolt nuts                           | 45 Nm   |
| Shock absorber linkage pivot bolt nuts                      | 45 Nm   |
| Shock absorber linkage arm bolt nuts                        | 45 Nm   |
| Swingarm pivot left-hand bolt                               | 95 Nm   |
| Swingarm pivot right-hand bolt                              | 60 Nm   |
| Front sprocket bolts                                        | 12 Nm   |
| Rear sprocket nuts                                          |         |
| VFR400 RG and ZG                                            | 65 Nm   |
| VFR400 RH, RJ and ZH                                        | 42.5 Nm |
| Oil pressure switch                                         | 12 Nm   |
| Neutral switch                                              | 12 Nm   |
| Alternator rotor bolt                                       | 85 Nm   |
| Front brake disc bolts                                      | 40 Nm   |
| Rear brake disc bolts – VFR400 RG and ZG                    | 40 Nm   |
| Rear brake disc nuts – VFR400 RH, RJ and ZH                 | 35 Nm   |
| Brake hose banjo bolts                                      | 30 Nm   |
| Brake caliper bleed valves                                  | 6 Nm    |
| Front axle bolt                                             | 60 Nm   |
| Front axle clamp bolts                                      | 22 Nm   |
| Rear axle nut – VFR400 RG and ZG                            | 90 Nm   |
| Rear hub assembly nut – VFR400 RH, RJ and ZH                | 165 Nm  |
| Rear wheel nuts – VFR400 RH, RJ and ZH                      | 110 Nm  |
| Rear wheel bearing holder pinch bolt – VFR400 RH, RJ and ZH | 27 Nm   |

### Non-specified components

**Note:** Where a specific setting is not given for a particular bolt/nut, these general settings apply. The dimension given applies to the diameter of the thread, not the head.

|                                      |       |
|--------------------------------------|-------|
| 5 mm bolt/nut                        | 5 Nm  |
| 6 mm bolt/nut                        | 10 Nm |
| 8 mm bolt/nut                        | 22 Nm |
| 10 mm bolt/nut                       | 35 Nm |
| 12 mm bolt/nut                       | 55 Nm |
| 6 mm flange bolt with 8 mm head      | 9 Nm  |
| 6 mm flange bolt/nut with 10 mm head | 12 Nm |
| 8 mm flange bolt/nut                 | 27 Nm |
| 10 mm flange bolt/nut                | 40 Nm |

**E**

**Earth** - REF•38  
**Electrical problems** - REF•35  
**Electrical system - 9•1 et seq**  
   fault finding - 9•3  
**Engine - 2•1 et seq**  
   camshaft drive gear assemblies - 2•18  
   camshafts - 2•13  
   compression - REF•35  
   connecting rods and bearings - 2•45  
   crankcase halves - 2•42, 2•44  
   crankshaft - 2•51  
   cylinder bores - 2•44  
   cylinder compression - 1•22  
   cylinder heads - 2•19, 2•21  
   disassembly and reassembly - 2•11  
   doesn't start - REF•28  
   fault finding - REF•28  
   main bearings - 2•45, 2•51  
   noise - REF•32  
   oil - 0•11, 1•2, 1•10, REF•45  
   oil cooler and pipes - 2•11  
   oil filter - 1•10  
   oil pump - 2•35  
   oil strainer - 2•34  
   oil sump - 2•34  
   oil pressure check - 1•22  
   oil pressure relief valve - 2•34  
   piston rings - 2•50  
   pistons - 2•48  
   removal and installation - 2•7  
   rocker arms and shafts - 2•17  
   serial number - 0•8  
   valve covers - 2•12  
   valves, seats and guides - 2•20, 2•21  
**Excessive exhaust smoke** - REF•33  
**Exhaust system - 4•1 et seq**  
   fault finding - REF•33  
   removal and installation - 4•16

**F**

**Fairing panels** - 8•3  
**Fasteners** - REF•5  
**Fault finding - REF•27 et seq**  
   electrical system - 9•3  
   equipment - REF•35  
**Final drive - 6•1 et seq**  
**Fluids** - 1•2, REF•45, REF•48, REF•50  
**Flushing the cooling system** - 1•21  
**Footrests** - 6•3  
**Forks** - 1•23, 6•6, 6•7  
**Frame - 6•1 et seq**  
   noise - REF•33  
**Frame serial number** - 0•8  
**Front wheel removal** - 7•15  
**Fuel** - 4•1  
**Fuel hoses** - 1•23  
**Fuel system - 4•1 et seq**  
   check - 1•11  
**Fuel tank** - 4•2, 4•4  
**Fuel tap** - 4•2  
**Fuses** - 9•4

**G**

**Gaskets** - REF•17  
**Gauges** - REF•9  
**Gearbox - see Transmission**  
**Gearchange**  
   lever - 6•3  
   mechanism - 2•39  
   problems - REF•32  
**Getting back on the road** - REF•26  
**Grey imports** - 0•9

**H**

**Handlebars and levers** - 6•4  
   switches - 9•15, 9•16  
**Headlight**  
   aim - 1•14  
   assembly - 9•6  
   bulb - 9•6  
**Horn** - 9•18  
**Hoses** - REF•19  
**Hydraulic fluid** - 0•12, 1•2, 1•19, REF•50

**I**

**Identification numbers** - 0•8  
**Idle fuel/air mixture adjustment** - 4•4  
**Idle speed** - 1•7  
**Ignition - 5•1 et seq**  
   control unit - 5•5  
   HT coils - 5•3  
   switch - 9•15  
   timing - 5•5  
**Initial start-up after overhaul** - 2•62  
**Instruments** - 9•10, 9•11  
   light bulb - 9•14  
**Introduction** - 0•4

**L**

**Legal checks** - 0•11  
**Lever pivot lubrication** - 1•10  
**Leverage** - REF•13  
**Lighting system** - 9•5  
**Lubricants** - 1•2, REF•45, REF•48, REF•50

**M**

**Main bearings** - 2•45, 2•51  
**Maintenance schedule** - 1•3  
**Master cylinder** - 7•6, 7•12  
   seals - 1•23  
**Measuring tools** - REF•9  
**Mirrors** - 8•3  
**MOT - REF•21 et seq**  
**Mudguard** - 8•5

**N**

**Neutral switch** - 9•16  
**Nut tightness** - 1•18

# Haynes Motorcycle Manuals – The Complete List

| Title                                                                | Book No | Title                                                                            | Book No | Title                                                       | Book No |
|----------------------------------------------------------------------|---------|----------------------------------------------------------------------------------|---------|-------------------------------------------------------------|---------|
| APRILIA RS50 (99 - 06) & RS125 (93 - 06)                             | 4298    | Honda Gold Wing 1200 (USA) (84 - 87)                                             | 2199    | Yamaha RS/RXS100 & 125 Singles (74 - 95)                    | 0331    |
| Aprilia RSV1000 Mile (98 - 03)                                       | 4255    | Honda Gold Wing 1500 (USA) (88 - 00)                                             | 2225    | Yamaha RD & DT125LC (82 - 87)                               | 0887    |
| BMW 2-valve Twins (70 - 96)                                          | 0249    | <b>KAWASAKI</b> AE/AR 50 & 80 (81 - 95)                                          | 1007    | Yamaha TZR125 (87 - 93) & DT125R (88 - 02)                  | 1655    |
| BMW K100 & 75 2-valve Models (83 - 96)                               | 1373    | Kawasaki KC, KE & KH100 (75 - 99)                                                | 1371    | Yamaha TY50, 80, 125 & 175 (74 - 84)                        | 0464    |
| BMW R850, 1100 & 1150 4-valve Twins (93 - 04)                        | 3466    | Kawasaki KMX125 & 200 (86 - 02)                                                  | 3046    | Yamaha XT & SR125 (82 - 03)                                 | 1021    |
| BMW R1200 (04 - 06)                                                  | 4598    | Kawasaki 250, 350 & 400 Triples (72 - 79)                                        | 0134    | Yamaha Trail Bikes (81 - 00)                                | 2350    |
| BSA Bantam (48 - 71)                                                 | 0117    | Kawasaki 400 & 440 Twins (74 - 81)                                               | 0261    | Yamaha 2-stroke Motocross Bikes 1986 - 2006                 | 2662    |
| BSA Unit Singles (58 - 72)                                           | 0127    | Kawasaki 400, 500 & 550 Fours (79 - 91)                                          | 0910    | Yamaha ZF600R Thundercat & FZS600 Fazer (96 - 03)           | 2669    |
| BSA Pre-unit Singles (54 - 61)                                       | 0326    | Kawasaki EN450 & 500 Twins (Ltd/Vulcan) (85 - 04)                                | 2053    | Yamaha 250 & 350 Twins (70 - 79)                            | 0040    |
| BSA A7 & A10 Twins (47 - 62)                                         | 0121    | Kawasaki EX500 (GPZ500S) & ER500 (ER-5) (87 - 05)                                | 2052    | Yamaha XS250, 360 & 400 sohc Twins (75 - 84)                | 0378    |
| BSA A50 & A65 Twins (62 - 73)                                        | 0155    | Kawasaki ZX600 (ZZ-R600 & Ninja ZX-6) (90 - 06)                                  | 2146    | Yamaha RD250 & 350LC Twins (80 - 82)                        | 0803    |
| <b>DUCATI</b> 600, 620, 750 and 900 2-valve V-Twins (91 - 05)        | 3290    | Kawasaki ZX-6R Ninja Fours (95 - 02)                                             | 3541    | Yamaha RD350 YPVS Twins (83 - 95)                           | 1158    |
| Ducati MK III & Desmo Singles (69 - 76)                              | 0445    | Kawasaki ZX-6R (03 - 06)                                                         | 4742    | Yamaha RD400 Twin (75 - 79)                                 | 0333    |
| Ducati 748, 916 & 996 4-valve V-Twins (94 - 01)                      | 3756    | Kawasaki ZX600 (GPZ600R, GPX600R, Ninja 600R & RX) & ZX750 (GPX750R, Ninja 750R) | 1780    | Yamaha XT, TT & SR500 Singles (75 - 83)                     | 0342    |
| <b>GILERA</b> Runner, DNA, Ice & SKP/Stalker (97 - 07)               | 4163    | Kawasaki 650 Four (76 - 78)                                                      | 0373    | Yamaha XZ550 Vision V-Twins (82 - 85)                       | 0821    |
| <b>HARLEY-DAVIDSON</b> Sportsters (70 - 03)                          | 2534    | Kawasaki Vulcan 700/750 & 800 (85 - 04)                                          | 2457    | Yamaha FJ, FZ, XJ & YX600 Radian (84 - 92)                  | 2100    |
| Harley-Davidson Shovelhead and Evolution Big Twins (70 - 99)         | 2536    | Kawasaki 750 Air-cooled Fours (80 - 91)                                          | 0574    | Yamaha XJ600S (Diversión, Soca II) & XJ600N Fours (92 - 03) | 2145    |
| Harley-Davidson Twin Cam 88 (99 - 03)                                | 2478    | Kawasaki ZR550 & 750 Zephyr Fours (90 - 97)                                      | 3382    | Yamaha YZF600R Thundercat & FZS600 Fazer (96 - 03)          | 3702    |
| <b>HONDA</b> NB, ND, NP & NS50 Melody (81 - 85)                      | 0622    | Kawasaki Z750 & Z1000 (03 - 08)                                                  | 4762    | Yamaha FZ-6 Fazer (04 - 07)                                 | 4751    |
| Honda NE/NS50 Vision & SA50 Vision Met-in (85 - 95)                  | 1278    | Kawasaki ZX750 (Ninja ZX-7 & ZXR750) Fours (89 - 96)                             | 2054    | Yamaha YZF-R6 (99 - 02)                                     | 3900    |
| Honda MB, MBX, MT & MTX50 (80 - 93)                                  | 0731    | Kawasaki Ninja ZX-7R & ZX-9R (94 - 04)                                           | 3721    | Yamaha YZF-R6 (03 - 05)                                     | 4601    |
| Honda C50, C70 & C90 (67 - 03)                                       | 0324    | Kawasaki 900 & 1000 Fours (73 - 77)                                              | 0222    | Yamaha 650 Twins (70 - 83)                                  | 0341    |
| Honda XR80/100R & CRF80/100F (85 - 04)                               | 2218    | Kawasaki ZX900, 1000 & 1100 Liquid-cooled Fours (83 - 97)                        | 1681    | Yamaha XJ650 & 750 Fours (80 - 84)                          | 0738    |
| Honda XL/XR 80, 100, 125, 185 & 200 2-valve Models (78 - 87)         | 0566    | <b>KTM</b> EXC Enduro & SX Motocross (00 - 07)                                   | 4629    | Yamaha XS750 & 850 Triples (76 - 85)                        | 0340    |
| Honda H100 & H100S Singles (80 - 92)                                 | 0734    | <b>MOTO GUZZI</b> 750, 850 & 1000 V-Twins (74 - 78)                              | 0339    | Yamaha TDM850, TRX850 & XTZ750 (89 - 99)                    | 3540    |
| Honda CB/CD125T & CM125C Twins (77 - 88)                             | 0571    | <b>MZ</b> ETZ Models (81 - 95)                                                   | 1680    | Yamaha YZF750R & YZF1000R Thunderace (93 - 00)              | 3720    |
| Honda CG125 (76 - 07)                                                | 0433    | <b>NORTON</b> 500, 600, 650 & 750 Twins (57 - 70)                                | 0187    | Yamaha FZR600, 750 & 1000 Fours (87 - 96)                   | 2056    |
| Honda NS125 (86 - 93)                                                | 3956    | Norton Commando (68 - 77)                                                        | 0125    | Yamaha XV (Virago) V-Twins (81 - 03)                        | 0802    |
| Honda CBR125R (04 - 07)                                              | 4620    | <b>PEUGEOT</b> Speedlight, Trekker & Vhacity Scooters (96 - 05)                  | 3920    | Yamaha XV650 & 1100 Drag Star/V-Star (97 - 05)              | 4195    |
| Honda MBX/MTX125 & MTX200 (83 - 83)                                  | 1132    | <b>PIAGGIO</b> (Vespa) Scooters (91 - 06)                                        | 3492    | Yamaha XJ900F Fours (83 - 94)                               | 3239    |
| Honda CG/CM185 200T & CM250C 2-valve Twins (77 - 85)                 | 0572    | <b>SUZUKI</b> GT, ZR & TS50 (77 - 90)                                            | 0799    | Yamaha XJ900S Diversión (94 - 01)                           | 3739    |
| Honda XL/XR 250 & 500 (78 - 84)                                      | 0567    | Suzuki TS50X (84 - 00)                                                           | 1599    | Yamaha YZF-R1 (98 - 03)                                     | 3754    |
| Honda XR250L, XR250R & XR400R (86 - 03)                              | 2219    | Suzuki 100, 125, 185 & 250 Air-cooled Trail bikes (79 - 89)                      | 0797    | Yamaha YZF-R1 (04 - 06)                                     | 4605    |
| Honda CB250 & CB400N Super Dreams (78 - 84)                          | 0540    | Suzuki GP100 & 125 Singles (78 - 93)                                             | 0576    | Yamaha FZS1000 Fazer (01 - 05)                              | 4287    |
| Honda CR Motocross Bikes (86 - 01)                                   | 2222    | Suzuki GS, GN, GZ & DR125 Singles (82 - 05)                                      | 0888    | Yamaha FJ1100 & 1200 Fours (84 - 96)                        | 2057    |
| Honda CRF250 & CRF450 (02 - 06)                                      | 2630    | Suzuki 250 & 350 Twins (68 - 78)                                                 | 0120    | Yamaha XJR1200 & 1300 (95 - 06)                             | 3981    |
| Honda CBR400RR Fours (88 - 99)                                       | 3552    | Suzuki GT250X7, GT200X5 & SB200 Twins (78 - 83)                                  | 0469    | Yamaha V-Max (85 - 03)                                      | 4072    |
| Honda VFR400 (NC30) & RVF400 (NC35) V-Fours (89 - 98)                | 3496    | Suzuki GS/GSX250, 400 & 450 Twins (79 - 85)                                      | 0736    | <b>ATVs</b>                                                 |         |
| Honda CB500 (93 - 01)                                                | 3753    | Suzuki GS500 Twin (89 - 06)                                                      | 3238    | Honda ATC70, 90, 110, 185 & 200 (71 - 85)                   | 0565    |
| Honda CB400 & CB550 Fours (73 - 77)                                  | 0262    | Suzuki GS550 (77 - 82) & GS750 Fours (76 - 79)                                   | 0363    | Honda Rancher, Recon & TRX250EX ATVs                        | 2553    |
| Honda CX/GL500 & 650 V-Twins (78 - 86)                               | 0442    | Suzuki GS/GSX550 4-valve Fours (83 - 88)                                         | 1133    | Honda TRX300 Shaft Drive ATVs (88 - 00)                     | 2125    |
| Honda CBX550 Four (82 - 86)                                          | 0940    | Suzuki SV650 & SV650S (99 - 05)                                                  | 3912    | Honda TRX300EX, TRX400EX & TRX450R/ER ATVs (93 - 06)        | 2318    |
| Honda XL600R & XR600R (83 - 00)                                      | 2183    | Suzuki GSX-R600 & 750 (96 - 00)                                                  | 3553    | Kawasaki Bayou 220/250/300 & Prairie 300 ATVs (86 - 03)     | 2351    |
| Honda XL600/650V Transalp & XR750 Africa Twin (87 to 07)             | 3919    | Suzuki GSX-R600 (01 - 03), GSX-R750 (00 - 03) & GSX-R1000 (01 - 02)              | 3986    | Polaris ATVs (85 - 97)                                      | 2302    |
| Honda CBR600F1 & 1000F Fours (87 - 96)                               | 1730    | Suzuki GSX-R600/750 (04 - 05) & GSX-R1000 (03 - 06)                              | 4382    | Polaris ATVs (98 - 06)                                      | 2508    |
| Honda CBR600F2 & F3 Fours (91 - 98)                                  | 2070    | Suzuki GSX-R600/750 (04 - 05) & GSX-R1000 (03 - 06)                              | 4382    | Yamaha YFS200 Blaster ATV (88 - 02)                         | 2317    |
| Honda CBR600F4 (99 - 06)                                             | 3911    | Suzuki GSF600, 650 & 1200 Bandit Fours (95 - 06)                                 | 3367    | Yamaha YFB250 Timberwolf ATVs (92 - 00)                     | 2217    |
| Honda CB600F Hornet & CB600 (98 - 06)                                | 3915    | Suzuki Intruder, Marauder, Volusia & Boulevard (85 - 06)                         | 2618    | Yamaha YFM350 & YFM400 (ER and Big Bear) ATVs (87 - 03)     | 2126    |
| Honda CBR600RR (03 - 06)                                             | 4590    | Suzuki GS850 Fours (78 - 88)                                                     | 0536    | Yamaha Banshee and Warrior ATVs (87 - 03)                   | 2314    |
| Honda CB850 sohc Fours (78 - 84)                                     | 0665    | Suzuki GS1000 Four (77 - 79)                                                     | 0484    | Yamaha Kodiak and Grizzly ATVs (93 - 05)                    | 2587    |
| Honda NTV600 Reverse, NTV650 and NT650V Deauville (88 - 05)          | 3243    | Suzuki GSX-R750, GSX-R1100 (85 - 92), GSX600F, GSX750F, GSX1100F (Katana) Fours  | 2055    | <b>ATV Basics</b>                                           | 10450   |
| Honda Shadow VT600 & 750 (USA) (88 - 03)                             | 2312    | Suzuki GSX800/750F & GSX750 (98 - 02)                                            | 3987    | <b>TECHBOOK SERIES</b>                                      |         |
| Honda CB750 sohc Four (69 - 79)                                      | 0131    | Suzuki GS/GSX1000, 1100 & 1150 4-valve Fours (79 - 88)                           | 0737    | Twist and Go (automatic transmission) Scooters              |         |
| Honda V45/65 Sabre & Magna (82 - 88)                                 | 0820    | Suzuki TL1000S/R & DL1000 V-Strom (97 - 04)                                      | 4083    | Service and Repair Manual                                   | 4082    |
| Honda VFR750 & 700 V-Fours (86 - 97)                                 | 2101    | Suzuki GSX1300R Hayabusa (99 - 04)                                               | 4184    | Motorcycle Basics TechBook (2nd Edition)                    | 3515    |
| Honda VFR800 V-Fours (97 - 01)                                       | 3703    | Suzuki GSX1400 (02 - 07)                                                         | 4758    | Motorcycle Electrical TechBook (3rd Edition)                | 3471    |
| Honda VFR800 V-Tec V-Fours (02 - 05)                                 | 4196    | <b>TRIUMPH</b> Tiger Cub & Terrier (52 - 68)                                     | 0414    | Motorcycle Fuel Systems TechBook                            | 3514    |
| Honda CB750 & CB900 dohc Fours (78 - 84)                             | 0535    | Triumph 350 & 500 Unit Twins (58 - 73)                                           | 0137    | Motorcycle Maintenance TechBook                             | 4071    |
| Honda VTR1000 (FireStorm, Super Hawk) & XL1000V (Varadero) (97 - 00) | 3744    | Triumph Pre-Unit Twins (47 - 62)                                                 | 0251    | Motorcycle Modifying                                        | 4272    |
| Honda CBR900RR FireBlade (92 - 99)                                   | 2161    | Triumph 650 & 750 2-valve Unit Twins (63 - 83)                                   | 0122    | Motorcycle Workshop Practice TechBook (2nd Edition)         | 3470    |
| Honda CBR900RR FireBlade (00 - 03)                                   | 4060    | Triumph Trident & BSA Rocket 3 (69 - 75)                                         | 0136    |                                                             |         |
| Honda CBR1000RR Fireblade (04 - 07)                                  | 4604    | Triumph Bonneville (01 - 07)                                                     | 4364    |                                                             |         |
| Honda CBR1100XX Super Blackbird (97 - 07)                            | 3901    | Triumph Daytona, Speed Triple, Sprint & Tiger (97 - 05)                          | 3755    |                                                             |         |
| Honda ST1100 Pan European V-Fours (90 - 02)                          | 3384    | Triumph Triples and Fours (carburettor engines) (91 - 04)                        | 2162    |                                                             |         |
| Honda Shadow VT1100 (USA) (85 - 98)                                  | 2313    | <b>VESPA</b> P/PX125, 150 & 200 Scooters (78 - 06)                               | 0787    |                                                             |         |
| Honda GL1000 Gold Wing (75 - 79)                                     | 0309    | Vespa Scooters (59 - 78)                                                         | 0126    |                                                             |         |
| Honda GL1100 Gold Wing (79 - 81)                                     | 0669    | <b>YAMAHA</b> DT50 & 80 Trail Bikes (78 - 95)                                    | 0800    |                                                             |         |
|                                                                      |         | Yamaha T50 & 80 Townmate (83 - 95)                                               | 1247    |                                                             |         |
|                                                                      |         | Yamaha YB100 Singles (73 - 91)                                                   | 0474    |                                                             |         |

◇ = not available in the USA    ◆ = Superbike

The manuals on this page are available through good motorcycle dealers and accessory shops.  
In case of difficulty, contact: **Haynes Publishing**  
(UK) +44 1963 442630 (USA) +1 805 498 6703  
(SV) +46 18 124016  
(Australia/New Zealand) +61 3 9763 8100

MCLES 12/07

# Spark Plugs Condition Chart



**Electrode gap check** – use a wire type gauge for best results.



**Electrode gap adjustment** – bend the side electrode using the correct tool.



**Normal condition** – A brown, tan or grey firing end indicates that the engine is in good condition and that the plug type is correct.



**Ash deposits** – Light brown deposits encrusted on the electrodes and insulator, leading to misfire and hesitation. Caused by excessive amounts of oil in the combustion chamber or poor quality fuel/oil.



**Carbon fouling** – Dry, black sooty deposits leading to misfire and weak spark. Caused by an over-rich fuel/air mixture, faulty choke operation or blocked air filter.




**Oil fouling** – Wet oily deposits leading to misfire and weak spark. Caused by oil leakage past piston rings or valve guides (4-stroke engine), or excess lubricant (2-stroke engine).




**Overheating** – A blistered white insulator and glazed electrodes. Caused by ignition system fault, incorrect fuel, or cooling system fault.




**Worn plug** – Worn electrodes will cause poor starting in damp or cold conditions and will also waste fuel.



29.20d ... then install the cover, aligning the marks (arrowed)



29.21a Install the long bolts ...



29.21b ... locating the flat of each washer against the raised edge (arrow)

### 30 Charging system testing – general information and precautions

1 If the performance of the charging system is suspect, the system as a whole should be checked first, followed by testing of the individual components. **Note:** Before beginning the checks, make sure the battery is fully charged and that all system connections are clean and tight.

2 Checking the output of the charging system and the performance of the various components within the charging system requires the use of a multimeter (with voltage, current and resistance checking facilities).

3 When making the checks, follow the procedures carefully to prevent incorrect connections or short circuits, as irreparable damage to electrical system components may result if short circuits occur.

4 If a multimeter is not available, the job of checking the charging system should be left to a Honda dealer.

### 31 Charging system – leakage and output test

1 If the charging system of the machine is thought to be faulty, remove the seat cowling (see Chapter 8) and perform the following checks.

#### Leakage test

**Caution:** Always connect an ammeter in series, never in parallel with the battery, otherwise it will be damaged. Do not turn the ignition ON or operate the starter motor when the ammeter is connected – a sudden surge in current will blow the meter's fuse.

2 Turn the ignition switch OFF and disconnect the lead from the battery negative (–ve) terminal.

3 Set the multimeter to the Amps function and connect its negative (–ve) probe to the battery negative (–ve) terminal, and positive (+ve) probe to the disconnected negative (–ve) lead (see illustration). Always set the meter

to a high amps range initially and then bring it down to the mA (milli Amps) range; if there is a high current flow in the circuit it may blow the meter's fuse.

4 If the current leakage indicated exceeds the amount specified at the beginning of the Chapter, there is probably a short circuit in the wiring. Disconnect the meter and connect the negative (–ve) lead to the battery, tightening it securely.


5 If leakage is indicated, use the wiring diagrams at the end of this book to systematically disconnect individual electrical components and repeat the test until the source is identified.

#### Output test

6 Start the engine and warm it up to normal operating temperature. Remove the seat cowling (see Chapter 8).

7 To check the voltage output, allow the engine to idle and connect a multimeter set to the 0-20 volts DC scale (voltmeter) across the terminals of the battery (positive (+ve) lead to battery positive (+ve) terminal, negative (–ve) lead to battery negative (–ve) terminal). Slowly increase the engine speed to 5000 rpm and note the reading obtained. The regulated voltage should be as specified at the beginning of the Chapter. If the voltage is outside these limits, check the alternator and the regulator (see Sections 32 and 33).

8 To check the current output, disconnect the starter relay wiring connector and remove the main fuse, then reconnect the connector.



31.3 Checking the charging system leakage rate – connect the meter as shown

Connect a multimeter set to the 0-20 amps DC scale (ammeter) between the terminals of the main fuse (positive (+ve) lead to the left-hand (rear) terminal, negative (–ve) lead to right-hand (front) terminal), inserting the probes into the base of the fuse sockets. Allow the engine to idle, then slowly increase the engine speed to 5000 rpm and note the reading obtained. The regulated current should be as specified at the beginning of the Chapter. If the current is outside these limits, check the alternator and the regulator (see Sections 32 and 33).



**Clues to a faulty regulator are constantly blowing bulbs, with brightness varying considerably with engine speed, and battery overheating.**

### 32 Alternator – check, removal and installation

#### Check

1 Remove the lower fairing (see Chapter 8).  
2 Trace the wiring back from the top of the alternator cover on the left-hand side of the engine and disconnect it at the white connector containing the yellow wires below the right-hand side of the frame (see illustration).



32.2 Alternator wiring connector (arrowed) – RVF model shown



29.17c ... then fit the O-ring ...




29.17d ... the insulating washers ...



29.17e ... the plain washer and the nut




29.18a Fit the shims ...



29.18b ... then insert the armature into the rear cover, making sure the brush ends (arrowed) locate correctly



29.19a Fit a new O-ring ...



29.19b ... then install the main housing, aligning the marks (arrowed)



29.20a Fit a new O-ring onto the main housing ...



29.20b ... and locate the tabbed washer in the front cover



29.20c Fit the shims onto the shaft ...

the standard washer and the nut (see illustrations).

18 Slide the shims onto the rear end of the armature shaft, then lubricate the shaft with a drop of oil (see illustrations). Insert the armature into the rear cover, locating the brushes on the commutator bars as you do, taking care not to damage them (see illustration). Check that each brush is securely pressed against the commutator by its spring and is free to move easily in its holder.

19 Fit a new O-ring onto the main housing, then fit the housing over the armature and onto the rear cover, aligning the marks made on removal (see illustrations).

20 Apply a smear of grease to the lips of the front cover oil seal and fit a new O-ring onto the front of the main housing (see illustration). Fit the tabbed washer onto the cover, making sure the tabs locate correctly (see illustration). Slide the shims onto the front of the armature shaft, then install the cover, aligning the marks made on removal (see illustrations). Remove the protective tape from the shaft end.

21 Slide a new O-ring onto each of the long bolts. Check the marks made on removal are correctly aligned, then install the long bolts and tighten them securely, making sure the flat edge on each washer is against the raised section on the front cover (see illustrations).

22 Install the starter motor (see Section 29).



32.3 Test the alternator as described



32.6 Remove the alternator cover and discard the gasket



32.7 Hold the rotor using a suitable tool and unscrew the bolt (arrowed)

3 Using a multimeter set to the ohms x 1 (ohmmeter) scale measure the resistance between each of the yellow wires on the alternator side of the connector, taking a total of three readings, then check for continuity between each terminal and ground (earth) (see illustration). If the stator coil windings are in good condition the three readings should be within the range shown in the Specifications at the start of this Chapter and there should be no continuity (infinite resistance) between any of the terminals and ground (earth). If not, the alternator stator coil assembly is at fault and should be replaced.  
**Note:** Before condemning the stator coils, check the fault is not due to damaged wiring between the connector and coils.

### Removal


4 Remove the lower fairing (see Chapter 8).  
5 Trace the wiring back from the top of the alternator cover on the left-hand side of the engine and disconnect it at the connector below the right-hand side of the frame (see illustration 32.2). Free the wiring from any clips or guides and feed it through to the alternator cover.  
6 Working in a criss-cross pattern, evenly slacken the alternator cover retaining bolts (see illustration). Lift the cover away from the engine, being prepared to catch any residual oil which may be released as the cover is removed. Remove the gasket and discard it.

7 To remove the rotor bolt it is necessary to stop the rotor from turning. If a rotor holding strap or tool is not available, place the transmission in gear and have an assistant apply the rear brake, then unscrew the bolt (see illustration).

**TOOL TIP** A rotor holding tool can easily be made using two strips of steel bolted together in the middle, and with a bolt through each end which locate into the recessed bores in the rotor.



32.8 Draw the rotor off the end of the crankshaft using a rotor puller



32.9 Unscrew the stator bolts (A) and the wiring clamp bolt (B)

8 To remove the rotor from the shaft it is necessary to use a rotor puller. Thread the rotor puller into the centre of the rotor and turn it until the rotor is displaced from the shaft (see illustration).

9 To remove the stator from the crankcase, unscrew the four bolts securing the stator, and the bolt securing the wiring clamp, then remove the assembly, noting how the rubber wiring grommet fits (see illustration).

### Installation

10 Install the stator onto the crankcase, aligning the rubber wiring grommet with the groove in the case (see illustration). Apply a suitable non-permanent thread locking compound to the stator bolt threads, then install the bolts and tighten them securely (see illustration). Apply a suitable sealant to



32.10a Fit the stator ...



32.10b ... then apply threadlock and install the bolts



32.10c Apply sealant to the wiring grommet ...

## 9•26 Electrical system

resistance between the various terminals on the regulator/rectifier (**see illustration**). If the readings do not compare closely with those shown in the accompanying table the regulator/rectifier unit can be considered faulty. **Note:** The use of certain multimeters could lead to false readings being obtained, as could a low battery in the meter and contact between the meter probes and your fingers. If the above check shows the regulator/rectifier unit to be faulty, take the unit to a Honda dealer for confirmation of its condition before replacing it.

### Replacement

**8** Remove the seat cowling (see Chapter 8).

**9** The regulator/rectifier is mounted on the left-hand side of the rear sub-frame. Disconnect the wiring connector (**see illustration 33.1**).


| K ohms             |               |          |          |          |          |
|--------------------|---------------|----------|----------|----------|----------|
| ⊕ probe<br>⊖ probe | Red/<br>white | Yellow   | Yellow   | Yellow   | Green    |
| Red/white          |               | ∞        | ∞        | ∞        | ∞        |
| Yellow             | 0.5 – 10      |          | 30 – 500 | 30 – 500 | 10 – 200 |
| Yellow             | 0.5 – 10      | 30 – 500 |          | 30 – 500 | 10 – 200 |
| Yellow             | 0.5 – 10      | 30 – 500 | 30 – 500 |          | 10 – 200 |
| Green              | 1 – 20        | 0.5 – 10 | 0.5 – 10 | 0.5 – 10 |          |

33.7 Regulator/rectifier test connections and data

**10** Unscrew the two nuts securing the regulator/rectifier and remove it. Note the wiring clip secured by the rear nut on VFR models.

**11** Install the new unit and tighten its nuts securely, not forgetting the wiring clip on VFR models. Connect the wiring connector.

**12** Install the seat cowling (see Chapter 8).



VFR400 (NC30)

C. J. TURK  
H29759

## REF•2 Tools and Workshop Tips

### Buying tools

A toolkit is a fundamental requirement for servicing and repairing a motorcycle. Although there will be an initial expense in building up enough tools for servicing, this will soon be offset by the savings made by doing the job yourself. As experience and confidence grow, additional tools can be added to enable the repair and overhaul of the motorcycle. Many of the specialist tools are expensive and not often used so it may be preferable to hire them, or for a group of friends or motorcycle club to join in the purchase.

As a rule, it is better to buy more expensive, good quality tools. Cheaper tools are likely to wear out faster and need to be renewed more often, nullifying the original saving.



**Warning:** To avoid the risk of a poor quality tool breaking in use, causing injury or damage to the component being worked on, always aim to purchase tools which meet the relevant national safety standards.

The following lists of tools do not represent the manufacturer's service tools, but serve as a guide to help the owner decide which tools are needed for this level of work. In addition, items such as an electric drill, hacksaw, files, soldering iron and a workbench equipped with a vice, may be needed. Although not classed as tools, a selection of bolts, screws, nuts, washers and pieces of tubing always come in useful.


For more information about tools, refer to the Haynes *Motorcycle Workshop Practice TechBook* (Bk. No. 3470).

### Manufacturer's service tools

Inevitably certain tasks require the use of a service tool. Where possible an alternative tool or method of approach is recommended, but sometimes there is no option if personal injury or damage to the component is to be avoided. Where required, service tools are referred to in the relevant procedure.

Service tools can usually only be purchased from a motorcycle dealer and are identified by a part number. Some of the commonly-used tools, such as rotor pullers, are available in aftermarket form from mail-order motorcycle tool and accessory suppliers.

## Maintenance and minor repair tools



- 1 Set of flat-bladed screwdrivers
- 2 Set of Phillips head screwdrivers
- 3 Combination open-end and ring spanners
- 4 Socket set (3/8 inch or 1/2 inch drive)
- 5 Set of Allen keys or bits

- 6 Set of Torx keys or bits
- 7 Pliers, cutters and self-locking grips (Mole grips)
- 8 Adjustable spanners
- 9 C-spanners
- 10 Tread depth gauge and tyre pressure gauge

- 11 Cable oiler clamp
- 12 Feeler gauges
- 13 Spark plug gap measuring tool
- 14 Spark plug spanner or deep plug sockets
- 15 Wire brush and emery paper

- 16 Calibrated syringe, measuring vessel and funnel
- 17 Oil filter adapters
- 18 Oil drainer can or tray
- 19 Pump type oil can
- 20 Grease gun

- 21 Straight-edge and steel rule
- 22 Continuity tester
- 23 Battery charger
- 24 Hydrometer (for battery specific gravity check)
- 25 Anti-freeze tester (for liquid-cooled engines)

## REF•4 Tools and Workshop Tips

### 1 Workshop equipment and facilities

#### The workbench

● Work is made much easier by raising the bike up on a ramp - components are much more accessible if raised to waist level. The hydraulic or pneumatic types seen in the dealer's workshop are a sound investment if you undertake a lot of repairs or overhauls (see illustration 1.1).



1.1 Hydraulic motorcycle ramp

● If raised off ground level, the bike must be supported on the ramp to avoid it falling. Most ramps incorporate a front wheel locating clamp which can be adjusted to suit different diameter wheels. When tightening the clamp, take care not to mark the wheel rim or damage the tyre - use wood blocks on each side to prevent this.

● Secure the bike to the ramp using tie-downs (see illustration 1.2). If the bike has only a sidestand, and hence leans at a dangerous angle when raised, support the bike on an auxiliary stand.



1.2 Tie-downs are used around the passenger footrests to secure the bike

● Auxiliary (paddock) stands are widely available from mail order companies or motorcycle dealers and attach either to the wheel axle or swingarm pivot (see illustration 1.3). If the motorcycle has a centrestand, you can support it under the crankcase to prevent it toppling whilst either wheel is removed (see illustration 1.4).



1.3 This auxiliary stand attaches to the swingarm pivot



1.4 Always use a block of wood between the engine and jack head when supporting the engine in this way

#### Fumes and fire

● Refer to the Safety first! page at the beginning of the manual for full details. Make sure your workshop is equipped with a fire extinguisher suitable for fuel-related fires (Class B fire - flammable liquids) - it is not sufficient to have a water-filled extinguisher.

● Always ensure adequate ventilation is available. Unless an exhaust gas extraction system is available for use, ensure that the engine is run outside of the workshop.

● If working on the fuel system, make sure the workshop is ventilated to avoid a build-up of fumes. This applies equally to fume build-up when charging a battery. Do not smoke or allow anyone else to smoke in the workshop.

#### Fluids

● If you need to drain fuel from the tank, store it in an approved container marked as suitable for the storage of petrol (gasoline) (see illustration 1.5). Do not store fuel in glass jars or bottles.



1.5 Use an approved can only for storing petrol (gasoline)

● Use proprietary engine degreasers or solvents which have a high flash-point, such as paraffin (kerosene), for cleaning off oil, grease and dirt - never use petrol (gasoline) for cleaning. Wear rubber gloves when handling solvent and engine degreaser. The fumes from certain solvents can be dangerous - always work in a well-ventilated area.

#### Dust, eye and hand protection

● Protect your lungs from inhalation of dust particles by wearing a filtering mask over the nose and mouth. Many frictional materials still contain asbestos which is dangerous to your health. Protect your eyes from spouts of liquid and sprung components by wearing a pair of protective goggles (see illustration 1.6).



1.6 A fire extinguisher, goggles, mask and protective gloves should be at hand in the workshop

● Protect your hands from contact with solvents, fuel and oils by wearing rubber gloves. Alternatively apply a barrier cream to your hands before starting work. If handling hot components or fluids, wear suitable gloves to protect your hands from scalding and burns.

#### What to do with old fluids

● Old cleaning solvent, fuel, coolant and oils should not be poured down domestic drains or onto the ground. Package the fluid up in old oil containers, label it accordingly, and take it to a garage or disposal facility. Contact your local authority for location of such sites or ring the oil care hotline.



**Note: It is antisocial and illegal to dump oil down the drain. To find the location of your local oil recycling bank, call this number free.**

**In the USA, note that any oil supplier must accept used oil for recycling.**


## REF•6 Tools and Workshop Tips



2.7 Correct fitting of R-pin.  
Arrow indicates forward direction


### Circlips (see illustration 2.8)

● Circlips (sometimes called snap-rings) are used to retain components on a shaft or in a housing and have corresponding external or internal ears to permit removal. Parallel-sided (machined) circlips can be installed either way round in their groove, whereas stamped circlips (which have a chamfered edge on one face) must be installed with the chamfer facing away from the direction of thrust load (see illustration 2.9).




2.8 External stamped circlip (A), internal stamped circlip (B), machined circlip (C) and wire circlip (D)

● Always use circlip pliers to remove and install circlips; expand or compress them just enough to remove them. After installation, rotate the circlip in its groove to ensure it is securely seated. If installing a circlip on a splined shaft, always align its opening with a shaft channel to ensure the circlip ends are well supported and unlikely to catch (see illustration 2.10).



2.9 Correct fitting of a stamped circlip



2.10 Align circlip opening with shaft channel

● Circlips can wear due to the thrust of components and become loose in their grooves, with the subsequent danger of becoming dislodged in operation. For this reason, renewal is advised every time a circlip is disturbed.


● Wire circlips are commonly used as piston pin retaining clips. If a removal tang is provided, long-nosed pliers can be used to dislodge them, otherwise careful use of a small flat-bladed screwdriver is necessary. Wire circlips should be renewed every time they are disturbed.

### Thread diameter and pitch

● Diameter of a male thread (screw, bolt or stud) is the outside diameter of the threaded portion (see illustration 2.11). Most motorcycle manufacturers use the ISO (International Standards Organisation) metric system expressed in millimetres, eg M6 refers to a 6 mm diameter thread. Sizing is the same for nuts, except that the thread diameter is measured across the valleys of the nut.

● Pitch is the distance between the peaks of the thread (see illustration 2.11). It is expressed in millimetres, thus a common bolt size may be expressed as 6.0 x 1.0 mm (6 mm thread diameter and 1 mm pitch). Generally pitch increases in proportion to thread diameter, although there are always exceptions.

● Thread diameter and pitch are related for conventional fastener applications and the accompanying table can be used as a guide. Additionally, the AF (Across Flats), spanner or socket size dimension of the bolt or nut (see illustration 2.11) is linked to thread and pitch specification. Thread pitch can be measured with a thread gauge (see illustration 2.12).



2.11 Fastener length (L), thread diameter (D), thread pitch (P) and head size (AF)



2.12 Using a thread gauge to measure pitch

| AF size | Thread diameter x pitch (mm) |
|---------|------------------------------|
| 8 mm    | M5 x 0.8                     |
| 8 mm    | M6 x 1.0                     |
| 10 mm   | M6 x 1.0                     |
| 12 mm   | M8 x 1.25                    |
| 14 mm   | M10 x 1.25                   |
| 17 mm   | M12 x 1.25                   |

● The threads of most fasteners are of the right-hand type, ie they are turned clockwise to tighten and anti-clockwise to loosen. The reverse situation applies to left-hand thread fasteners, which are turned anti-clockwise to tighten and clockwise to loosen. Left-hand threads are used where rotation of a component might loosen a conventional right-hand thread fastener.

### Seized fasteners

● Corrosion of external fasteners due to water or reaction between two dissimilar metals can occur over a period of time. It will build up sooner in wet conditions or in countries where salt is used on the roads during the winter. If a fastener is severely corroded it is likely that normal methods of removal will fail and result in its head being ruined. When you attempt removal, the fastener thread should be heard to crack free and unscrew easily - if it doesn't, stop there before damaging something.

● A smart tap on the head of the fastener will often succeed in breaking free corrosion which has occurred in the threads (see illustration 2.13).

● An aerosol penetrating fluid (such as WD-40) applied the night beforehand may work its way down into the thread and ease removal. Depending on the location, you may be able to make up a Plasticine well around the fastener head and fill it with penetrating fluid.



2.13 A sharp tap on the head of a fastener will often break free a corroded thread



**2.21 Comparison of surface drive ring spanner (left) with 12-point type (right)**

is obtained. Surface drive spanners grip the middle of the hex flats, rather than the corners, and are thus good in cases of damaged heads (see illustration 2.21).

● Slotted-head or Phillips-head screws are often damaged by the use of the wrong size screwdriver. Allen-head and Torx-head screws are much less likely to sustain damage. If enough of the screw head is exposed you can use a hacksaw to cut a slot in its head and then use a conventional flat-bladed screwdriver to remove it. Alternatively use a hammer and cold chisel to tap the head of the fastener around to slacken it. Always replace damaged fasteners with new ones, preferably Torx or Allen-head type.



**A dab of valve grinding compound between the screw head and screwdriver tip will often give a good grip.**

### Thread repair

● Threads (particularly those in aluminium alloy components) can be damaged by overtightening, being assembled with dirt in the threads, or from a component working loose and vibrating. Eventually the thread will fail completely, and it will be impossible to tighten the fastener.

● If a thread is damaged or clogged with old locking compound it can be renovated with a thread repair tool (thread chaser) (see illustrations 2.22 and 2.23); special thread




**2.22 A thread repair tool being used to correct an internal thread**



**2.23 A thread repair tool being used to correct an external thread**

chasers are available for spark plug hole threads. The tool will not cut a new thread, but clean and true the original thread. Make sure that you use the correct diameter and pitch tool. Similarly, external threads can be cleaned up with a die or a thread restorer file (see illustration 2.24).



**2.24 Using a thread restorer file**

● It is possible to drill out the old thread and retap the component to the next thread size. This will work where there is enough surrounding material and a new bolt or screw can be obtained. Sometimes, however, this is not possible - such as where the bolt/screw passes through another component which must also be suitably modified, also in cases where a spark plug or oil drain plug cannot be obtained in a larger diameter thread size.

● The diamond-section thread insert (often known by its popular trade name of Heli-Coil) is a simple and effective method of renewing the thread and retaining the original size. A kit can be purchased which contains the tap, insert and installing tool (see illustration 2.25). Drill out the damaged thread with the size drill specified (see illustration 2.26). Carefully retap the thread (see illustration 2.27). Install the



**2.25 Obtain a thread insert kit to suit the thread diameter and pitch required**



**2.26 To install a thread insert, first drill out the original thread ...**



**2.27 ... tap a new thread ...**



**2.28 ... fit insert on the installing tool ...**



**2.29 ... and thread into the component ...**



**2.30 ... break off the tang when complete**

insert on the installing tool and thread it slowly into place using a light downward pressure (see illustrations 2.28 and 2.29). When positioned between a 1/4 and 1/2 turn below the surface withdraw the installing tool and use the break-off tool to press down on the tang, breaking it off (see illustration 2.30).


● There are epoxy thread repair kits on the market which can rebuild stripped internal threads, although this repair should not be used on high load-bearing components.

## REF•10 Tools and Workshop Tips

on the thimble will be in graduations of 0.01 mm (or as marked on the frame) - one full revolution of the thimble will move 0.5 mm on the linear scale. Take the reading where the datum line on the sleeve intersects the thimble's scale. Always position the eye directly above the scale otherwise an inaccurate reading will result.

In the example shown the item measures 2.95 mm (see illustration 3.4):

|               |         |
|---------------|---------|
| Linear scale  | 2.00 mm |
| Linear scale  | 0.50 mm |
| Annular scale | 0.45 mm |
| Total figure  | 2.95 mm |



3.4 Micrometer reading of 2.95 mm

Most micrometers have a locking lever (6) on the frame to hold the setting in place, allowing the item to be removed from the micrometer.


Some micrometers have a vernier scale on their sleeve, providing an even finer measurement to be taken, in 0.001 increments of a millimetre. Take the sleeve and thimble measurement as described above, then check which graduation on the vernier scale aligns with that of the annular scale on the thimble **Note:** The eye must be perpendicular to the scale when taking the vernier reading - if necessary rotate the body of the micrometer to ensure this. Multiply the vernier scale figure by 0.001 and add it to the base and fine measurement figures.

In the example shown the item measures 46.994 mm (see illustrations 3.5 and 3.6).


|                      |           |
|----------------------|-----------|
| Linear scale (base)  | 46.000 mm |
| Linear scale (base)  | 00.500 mm |
| Annular scale (fine) | 00.490 mm |
| Vernier scale        | 00.004 mm |
| Total figure         | 46.994 mm |

### Internal micrometer

- Internal micrometers are available for measuring bore diameters, but are expensive and unlikely to be available for home use. It is suggested that a set of telescoping gauges and small hole gauges, both of which must be used with an external micrometer, will suffice for taking internal measurements on a motorcycle.
- Telescoping gauges can be used to



3.5 Micrometer reading of 46.99 mm on linear and annular scales ...



3.6 ... and 0.004 mm on vernier scale


measure internal diameters of components. Select a gauge with the correct size range, make sure its ends are clean and insert it into the bore. Expand the gauge, then lock its position and withdraw it from the bore (see illustration 3.7). Measure across the gauge ends with a micrometer (see illustration 3.8).

Very small diameter bores (such as valve guides) are measured with a small hole gauge. Once adjusted to a slip-fit inside the component, its position is locked and the gauge withdrawn for measurement with a micrometer (see illustrations 3.9 and 3.10).

### Vernier caliper

**Note:** The conventional linear and dial gauge type instruments are described. Digital types are easier to read, but are far more expensive.

- The vernier caliper does not provide the precision of a micrometer, but is versatile in being able to measure internal and external diameters. Some types also incorporate a depth gauge. It is ideal for measuring clutch plate friction material and spring free lengths.
- To use the conventional linear scale vernier, slacken off the vernier clamp screws (1) and set its jaws over (2), or inside (3), the item to be measured (see illustration 3.11). Slide the jaw into contact, using the thumb-wheel (4) for fine movement of the sliding scale (5) then tighten the clamp screws (1). Read off the main scale (6) where the zero on the sliding scale (5) intersects it, taking the whole number to the left of the zero; this provides the base measurement. View along the sliding scale and select the division which



3.7 Expand the telescoping gauge in the bore, lock its position ...



3.8 ... then measure the gauge with a micrometer



3.9 Expand the small hole gauge in the bore, lock its position ...



3.10 ... then measure the gauge with a micrometer

lines up exactly with any of the divisions on the main scale, noting that the divisions usually represents 0.02 of a millimetre. Add this fine measurement to the base measurement to obtain the total reading.

## REF•12 Tools and Workshop Tips

### Dial gauge or DTI (Dial Test Indicator)

- A dial gauge can be used to accurately measure small amounts of movement. Typical uses are measuring shaft runout or shaft endfloat (sideplay) and setting piston position for ignition timing on two-strokes. A dial gauge set usually comes with a range of different probes and adapters and mounting equipment.
- The gauge needle must point to zero when at rest. Rotate the ring around its periphery to zero the gauge.
- Check that the gauge is capable of reading the extent of movement in the work. Most gauges have a small dial set in the face which records whole millimetres of movement as well as the fine scale around the face periphery which is calibrated in 0.01 mm divisions. Read off the small dial first to obtain the base measurement, then add the measurement from the fine scale to obtain the total reading.


In the example shown the gauge reads 1.48 mm (see illustration 3.17):

|                  |         |
|------------------|---------|
| Base measurement | 1.00 mm |
| Fine measurement | 0.48 mm |
| Total figure     | 1.48 mm |



3.17 Dial gauge reading of 1.48 mm


- If measuring shaft runout, the shaft must be supported in vee-blocks and the gauge mounted on a stand perpendicular to the shaft. Rest the tip of the gauge against the centre of the shaft and rotate the shaft slowly whilst watching the gauge reading (see illustration 3.18). Take several measurements along the length of the shaft and record the



3.18 Using a dial gauge to measure shaft runout

maximum gauge reading as the amount of runout in the shaft. **Note:** The reading obtained will be total runout at that point - some manufacturers specify that the runout figure is halved to compare with their specified runout limit.

- Endfloat (sideplay) measurement requires that the gauge is mounted securely to the surrounding component with its probe touching the end of the shaft. Using hand pressure, push and pull on the shaft noting the maximum endfloat recorded on the gauge (see illustration 3.19).



3.19 Using a dial gauge to measure shaft endfloat

- A dial gauge with suitable adapters can be used to determine piston position BTDC on two-stroke engines for the purposes of ignition timing. The gauge, adapter and suitable length probe are installed in the place of the spark plug and the gauge zeroed at TDC. If the piston position is specified as 1.14 mm BTDC, rotate the engine back to 2.00 mm BTDC, then slowly forwards to 1.14 mm BTDC.

### Cylinder compression gauges

- A compression gauge is used for measuring cylinder compression. Either the rubber-cone type or the threaded adapter type can be used. The latter is preferred to ensure a perfect seal against the cylinder head. A 0 to 300 psi (0 to 20 Bar) type gauge (for petrol/gasoline engines) will be suitable for motorcycles.
- The spark plug is removed and the gauge either held hard against the cylinder head (cone type) or the gauge adapter screwed into the cylinder head (threaded type) (see illustration 3.20). Cylinder compression is measured with the engine turning over, but not running - carry out the compression test as described in



3.20 Using a rubber-cone type cylinder compression gauge

**Fault Finding Equipment.** The gauge will hold the reading until manually released.

### Oil pressure gauge

- An oil pressure gauge is used for measuring engine oil pressure. Most gauges come with a set of adapters to fit the thread of the take-off point (see illustration 3.21). If the take-off point specified by the motorcycle manufacturer is an external oil pipe union, make sure that the specified replacement union is used to prevent oil starvation.



3.21 Oil pressure gauge and take-off point adapter (arrow)

- Oil pressure is measured with the engine running (at a specific rpm) and often the manufacturer will specify pressure limits for a cold and hot engine.

### Straight-edge and surface plate

- If checking the gasket face of a component for warpage, place a steel rule or precision straight-edge across the gasket face and measure any gap between the straight-edge and component with feeler gauges (see illustration 3.22). Check diagonally across the component and between mounting holes (see illustration 3.23).



3.22 Use a straight-edge and feeler gauges to check for warpage



3.23 Check for warpage in these directions

## REF•14 Tools and Workshop Tips

the joint will be held evenly and will not be distorted. Important joints, such as the cylinder head and big-end fasteners often have two- or three-stage torque settings.

### Applying leverage

- Use tools at the correct angle. Position a socket wrench or spanner on the bolt/nut so that you pull it towards you when loosening. If this can't be done, push the spanner without curling your fingers around it (see illustration 4.6) - the spanner may slip or the fastener loosen suddenly, resulting in your fingers being crushed against a component.



4.6 If you can't pull on the spanner to loosen a fastener, push with your hand open

- Additional leverage is gained by extending the length of the lever. The best way to do this is to use a breaker bar instead of the regular length tool, or to slip a length of tubing over the end of the spanner or socket wrench.
- If additional leverage will not work, the fastener head is either damaged or firmly corroded in place (see *Fasteners*).

## 5 Bearings

### Bearing removal and installation

#### Drivers and sockets

- Before removing a bearing, always inspect the casing to see which way it must be driven out - some casings will have retaining plates or a cast step. Also check for any identifying markings on the bearing and if installed to a certain depth, measure this at this stage. Some roller bearings are sealed on one side - take note of the original fitted position.

- Bearings can be driven out of a casing using a bearing driver tool (with the correct size head) or a socket of the correct diameter. Select the driver head or socket so that it contacts the outer race of the bearing, not the balls/rollers or inner race. Always support the casing around the bearing housing with wood blocks, otherwise there is a risk of fracture. The bearing is driven out with a few blows on the driver or socket from a heavy mallet. Unless access is severely restricted (as with wheel bearings), a pin-punch is not recommended unless it is moved around the bearing to keep it square in its housing.

- The same equipment can be used to install bearings. Make sure the bearing housing is supported on wood blocks and line up the bearing in its housing. Fit the bearing as noted on removal - generally they are installed with their marked side facing outwards. Tap the bearing squarely into its housing using a driver or socket which bears only on the bearing's outer race - contact with the bearing balls/rollers or inner race will destroy it (see illustrations 5.1 and 5.2).

- Check that the bearing inner race and balls/rollers rotate freely.




5.1 Using a bearing driver against the bearing's outer race



5.2 Using a large socket against the bearing's outer race

#### Pullers and slide-hammers


- Where a bearing is pressed on a shaft a puller will be required to extract it (see illustration 5.3). Make sure that the puller clamp or legs fit securely behind the bearing and are unlikely to slip out. If pulling a bearing



5.3 This bearing puller clamps behind the bearing and pressure is applied to the shaft end to draw the bearing off

off a gear shaft for example, you may have to locate the puller behind a gear pinion if there is no access to the race and draw the gear pinion off the shaft as well (see illustration 5.4).


**Caution:** Ensure that the puller's centre bolt locates securely against the end of the shaft and will not slip when pressure is applied. Also ensure that puller does not damage the shaft end.



5.4 Where no access is available to the rear of the bearing, it is sometimes possible to draw off the adjacent component

- Operate the puller so that its centre bolt exerts pressure on the shaft end and draws the bearing off the shaft.

- When installing the bearing on the shaft, tap only on the bearing's inner race - contact with the balls/rollers or outer race will destroy the bearing. Use a socket or length of tubing as a drift which fits over the shaft end (see illustration 5.5).



5.5 When installing a bearing on a shaft use a piece of tubing which bears only on the bearing's inner race

- Where a bearing locates in a blind hole in a casing, it cannot be driven or pulled out as described above. A slide-hammer with knife-edged bearing puller attachment will be required. The puller attachment passes through the bearing and when tightened expands to fit firmly behind the bearing (see illustration 5.6). By operating the slide-hammer part of the tool the bearing is jarred out of its housing (see illustration 5.7).


- It is possible, if the bearing is of reasonable weight, for it to drop out of its housing if the casing is heated as described opposite. If this

## REF•16 Tools and Workshop Tips


● Installation of bearings can be eased by placing them in a freezer the night before installation. The steel bearing will contract slightly, allowing easy insertion in its housing. This is often useful when installing steering head outer races in the frame.

### Bearing types and markings

● Plain shell bearings, ball bearings, needle roller bearings and tapered roller bearings will all be found on motorcycles (see illustrations 5.14 and 5.15). The ball and roller types are usually caged between an inner and outer race, but uncaged variations may be found.



5.14 Shell bearings are either plain or grooved. They are usually identified by colour code (arrow)



5.15 Tapered roller bearing (A), needle roller bearing (B) and ball journal bearing (C)

● Shell bearings (often called inserts) are usually found at the crankshaft main and connecting rod big-end where they are good at coping with high loads. They are made of a phosphor-bronze material and are impregnated with self-lubricating properties.

● Ball bearings and needle roller bearings consist of a steel inner and outer race with the balls or rollers between the races. They require constant lubrication by oil or grease and are good at coping with axial loads. Taper roller bearings consist of rollers set in a tapered cage set on the inner race; the outer race is separate. They are good at coping with axial loads and prevent movement along the shaft - a typical application is in the steering head.

● Bearing manufacturers produce bearings to ISO size standards and stamp one face of the bearing to indicate its internal and external diameter, load capacity and type (see illustration 5.16).

● Metal bushes are usually of phosphor-bronze material. Rubber bushes are used in suspension mounting eyes. Fibre bushes have also been used in suspension pivots.



5.16 Typical bearing marking



5.18 Example of ball journal bearing with damaged balls and cages

### Bearing fault finding


● If a bearing outer race has spun in its housing, the housing material will be damaged. You can use a bearing locking compound to bond the outer race in place if damage is not too severe.

● Shell bearings will fail due to damage of their working surface, as a result of lack of lubrication, corrosion or abrasive particles in the oil (see illustration 5.17). Small particles of dirt in the oil may embed in the bearing material whereas larger particles will score the bearing and shaft journal. If a number of short journeys are made, insufficient heat will be generated to drive off condensation which has built up on the bearings.



5.19 Hold outer race and listen to inner race when spun

race with the other hand (see illustration 5.19). The bearing should be almost silent when spun; if it grates or rattles it is worn.



5.17 Typical bearing failures

● Ball and roller bearings will fail due to lack of lubrication or damage to the balls or rollers. Tapered-roller bearings can be damaged by overloading them. Unless the bearing is sealed on both sides, wash it in paraffin (kerosene) to remove all old grease then allow it to dry. Make a visual inspection looking to dented balls or rollers, damaged cages and worn or pitted races (see illustration 5.18).

● A ball bearing can be checked for wear by listening to it when spun. Apply a film of light oil to the bearing and hold it close to the ear - hold the outer race with one hand and spin the inner

## 6 Oil seals

### Oil seal removal and installation

● Oil seals should be renewed every time a component is dismantled. This is because the seal lips will become set to the sealing surface and will not necessarily reseal.

● Oil seals can be prised out of position using a large flat-bladed screwdriver (see illustration 6.1). In the case of crankcase seals, check first that the seal is not lipped on the inside, preventing its removal with the crankcases joined.



6.1 Prise out oil seals with a large flat-bladed screwdriver

● New seals are usually installed with their marked face (containing the seal reference code) outwards and the spring side towards the fluid being retained. In certain cases, such as a two-stroke engine crankshaft seal, a double lipped seal may be used due to there being fluid or gas on each side of the joint.

## REF•18 Tools and Workshop Tips



7.6 Fine abrasive paper is wrapped around a flat file to clean up the gasket face



7.7 A kitchen scourer can be used on stubborn deposits

the gasket surface can be made with very fine abrasive paper or a plastic kitchen scourer (see illustrations 7.6 and 7.7).

● Old sealant can be scraped or peeled off components, depending on the type originally used. Note that gasket removal compounds are available to avoid scraping the components clean; make sure the gasket remover suits the type of sealant used.

### 8 Chains


#### Breaking and joining final drive chains

● Drive chains for all but small bikes are continuous and do not have a clip-type connecting link. The chain must be broken using a chain breaker tool and the new chain securely riveted together using a new soft rivet-type link. Never use a clip-type connecting link instead of a rivet-type link, except in an emergency. Various chain breaking and riveting tools are available, either as separate tools or combined as illustrated in the accompanying photographs - read the instructions supplied with the tool carefully.



**Warning:** The need to rivet the new link pins correctly cannot be overstressed - loss of control of the motorcycle is very likely to result if the chain breaks in use.

● Rotate the chain and look for the soft link. The soft link pins look like they have been



8.1 Tighten the chain breaker to push the pin out of the link . . .



8.2 . . . withdraw the pin, remove the tool . . .



8.3 . . . and separate the chain link

deeply centre-punched instead of peened over like all the other pins (see illustration 8.9) and its sideplate may be a different colour. Position the soft link midway between the sprockets and assemble the chain breaker tool over one of the soft link pins (see illustration 8.1). Operate the tool to push the pin out through the chain (see illustration 8.2). On an O-ring chain, remove the O-rings (see illustration 8.3). Carry out the same procedure on the other soft link pin.

**Caution:** Certain soft link pins (particularly on the larger chains) may require their ends to be filed or ground off before they can be pressed out using the tool.

● Check that you have the correct size and strength (standard or heavy duty) new soft link - do not reuse the old link. Look for the size marking on the chain sideplates (see illustration 8.10).

● Position the chain ends so that they are engaged over the rear sprocket. On an O-ring



8.4 Insert the new soft link, with O-rings, through the chain ends . . .



8.5 . . . install the O-rings over the pin ends . . .



8.6 . . . followed by the sideplate

chain, install a new O-ring over each pin of the link and insert the link through the two chain ends (see illustration 8.4). Install a new O-ring over the end of each pin, followed by the sideplate (with the chain manufacturer's marking facing outwards) (see illustrations 8.5 and 8.6). On an unsealed chain, insert the link through the two chain ends, then install the sideplate with the chain manufacturer's marking facing outwards.

● Note that it may not be possible to install the sideplate using finger pressure alone. If using a joining tool, assemble it so that the plates of the tool clamp the link and press the sideplate over the pins (see illustration 8.7). Otherwise, use two small sockets placed over



8.7 Push the sideplate into position using a clamp

# REF•20 Conversion Factors

## Length (distance)

|             |                           |                        |
|-------------|---------------------------|------------------------|
| Inches (in) | x 25.4 = Millimetres (mm) | x 0.0394 = Inches (in) |
| Feet (ft)   | x 0.305 = Metres (m)      | x 3.281 = Feet (ft)    |
| Miles       | x 1.609 = Kilometres (km) | x 0.621 = Miles        |

## Volume (capacity)

|                                        |                                                     |                                                  |
|----------------------------------------|-----------------------------------------------------|--------------------------------------------------|
| Cubic inches (cu in; in <sup>3</sup> ) | x 16.387 = Cubic centimetres (cc; cm <sup>3</sup> ) | x 0.061 = Cubic inches (cu in; in <sup>3</sup> ) |
| Imperial pints (Imp pt)                | x 0.568 = Litres (l)                                | x 1.76 = Imperial pints (Imp pt)                 |
| Imperial quarts (Imp qt)               | x 1.137 = Litres (l)                                | x 0.88 = Imperial quarts (Imp qt)                |
| US quarts (US qt)                      | x 1.201 = US quarts (US qt)                         | x 0.833 = Imperial quarts (Imp qt)               |
| Imperial gallons (Imp gal)             | x 0.946 = Litres (l)                                | x 1.057 = US quarts (US qt)                      |
| Imperial gallons (Imp gal)             | x 4.546 = Litres (l)                                | x 0.22 = Imperial gallons (Imp gal)              |
| US gallons (US gal)                    | x 1.201 = US gallons (US gal)                       | x 0.833 = Imperial gallons (Imp gal)             |
|                                        | x 3.785 = Litres (l)                                | x 0.264 = US gallons (US gal)                    |

## Mass (weight)

|             |                          |                       |
|-------------|--------------------------|-----------------------|
| Ounces (oz) | x 28.35 = Grams (g)      | x 0.035 = Ounces (oz) |
| Pounds (lb) | x 0.454 = Kilograms (kg) | x 2.205 = Pounds (lb) |

## Force

|                        |                                   |                                  |
|------------------------|-----------------------------------|----------------------------------|
| Ounces-force (ozf; oz) | x 0.278 = Newtons (N)             | x 3.6 = Ounces-force (ozf; oz)   |
| Pounds-force (lbf; lb) | x 4.448 = Newtons (N)             | x 0.225 = Pounds-force (lbf; lb) |
| Newton (N)             | x 0.1 = Kilograms-force (kgf; kg) | x 9.81 = Newtons (N)             |

## Pressure

|                                                                               |                                                                                             |                                                                                          |
|-------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> ) | x 0.070 = Kilograms-force per square centimetre (kgf/cm <sup>2</sup> ; kg/cm <sup>2</sup> ) | x 14.223 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> ) |
| Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> ) | x 0.068 = Atmospheres (atm)                                                                 | x 14.696 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> ) |
| Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> ) | x 0.069 = Bars                                                                              | x 14.5 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )   |
| Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> ) | x 6.895 = Kilopascals (kPa)                                                                 | x 0.145 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )  |
| Kilopascals (kPa)                                                             | x 0.01 = Kilograms-force per square centimetre (kgf/cm <sup>2</sup> ; kg/cm <sup>2</sup> )  | x 98.1 = Kilopascals (kPa)                                                               |
| Millibar (mbar)                                                               | x 100 = Pascals (Pa)                                                                        | x 0.01 = Millibar (mbar)                                                                 |
| Millibar (mbar)                                                               | x 0.0145 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )    | x 68.947 = Millibar (mbar)                                                               |
| Millibar (mbar)                                                               | x 0.75 = Millimetres of mercury (mmHg)                                                      | x 1.333 = Millibar (mbar)                                                                |
| Millibar (mbar)                                                               | x 0.401 = Inches of water (inH <sub>2</sub> O)                                              | x 2.491 = Millibar (mbar)                                                                |
| Millimetres of mercury (mmHg)                                                 | x 0.535 = Inches of water (inH <sub>2</sub> O)                                              | x 1.868 = Millimetres of mercury (mmHg)                                                  |
| Inches of water (inH <sub>2</sub> O)                                          | x 0.036 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )     | x 27.68 = Inches of water (inH <sub>2</sub> O)                                           |

## Torque (moment of force)

|                                     |                                                      |                                               |
|-------------------------------------|------------------------------------------------------|-----------------------------------------------|
| Pounds-force inches (lbf in; lb in) | x 1.152 = Kilograms-force centimetre (kgf cm; kg cm) | x 0.868 = Pounds-force inches (lbf in; lb in) |
| Pounds-force inches (lbf in; lb in) | x 0.113 = Newton metres (Nm)                         | x 8.85 = Pounds-force inches (lbf in; lb in)  |
| Pounds-force inches (lbf in; lb in) | x 0.083 = Pounds-force feet (lbf ft; lb ft)          | x 12 = Pounds-force inches (lbf in; lb in)    |
| Pounds-force feet (lbf ft; lb ft)   | x 0.138 = Kilograms-force metres (kgf m; kg m)       | x 7.233 = Pounds-force feet (lbf ft; lb ft)   |
| Pounds-force feet (lbf ft; lb ft)   | x 1.356 = Newton metres (Nm)                         | x 0.738 = Pounds-force feet (lbf ft; lb ft)   |
| Newton metres (Nm)                  | x 0.102 = Kilograms-force metres (kgf m; kg m)       | x 9.804 = Newton metres (Nm)                  |

## Power

|                 |                     |                            |
|-----------------|---------------------|----------------------------|
| Horsepower (hp) | x 745.7 = Watts (W) | x 0.0013 = Horsepower (hp) |
|-----------------|---------------------|----------------------------|

## Velocity (speed)

|                                |                                            |                                          |
|--------------------------------|--------------------------------------------|------------------------------------------|
| Miles per hour (miles/hr; mph) | x 1.609 = Kilometres per hour (km/hr; kph) | x 0.621 = Miles per hour (miles/hr; mph) |
|--------------------------------|--------------------------------------------|------------------------------------------|

## Fuel consumption\*

|                        |                                       |                                  |
|------------------------|---------------------------------------|----------------------------------|
| Miles per gallon (mpg) | x 0.354 = Kilometres per litre (km/l) | x 2.825 = Miles per gallon (mpg) |
|------------------------|---------------------------------------|----------------------------------|

## Temperature

|                                      |                                                             |
|--------------------------------------|-------------------------------------------------------------|
| Degrees Fahrenheit = (°C x 1.8) + 32 | Degrees Celsius (Degrees Centigrade; °C) = (°F - 32) x 0.56 |
|--------------------------------------|-------------------------------------------------------------|

\* It is common practice to convert from miles per gallon (mpg) to litres/100 kilometres (l/100km), where mpg x l/100 km = 282

## Exhaust System and Final Drive

### Exhaust

- ✓ Check that the exhaust mountings are secure and that the system does not foul any of the rear suspension components.
- ✓ Start the motorcycle. When the revs are increased, check that the exhaust is neither holed nor leaking from any of its joints. On a linked system, check that the collector box is not leaking due to corrosion.

✓ Note that the exhaust decibel level ("loudness" of the exhaust) is assessed at the discretion of the tester. If the motorcycle was first used on or after 1st January 1985 the silencer must carry the BSAU 193 stamp, or a marking relating to its make and model, or be of OE (original equipment) manufacture. If the silencer is marked NOT FOR ROAD USE, RACING USE ONLY or similar, it will fail the MOT.

### Final drive

- ✓ On chain or belt drive machines, check that the chain/belt is in good condition and does not have excessive slack. Also check that the sprocket is securely mounted on the rear wheel hub. Check that the chain/belt guard is in place.
- ✓ On shaft drive bikes, check for oil leaking from the drive unit and fouling the rear tyre.


## Steering and Suspension

### Steering

- ✓ With the front wheel raised off the ground, rotate the steering from lock to lock. The handlebar or switches must not contact the fuel tank or be close enough to trap the rider's hand. Problems can be caused by damaged lock stops on the lower yoke and frame, or by the fitting of non-standard handlebars.
- ✓ When performing the lock to lock check, also ensure that the steering moves freely without drag or notchiness. Steering movement can be impaired by poorly routed cables, or by overtight head bearings or worn bearings. The

tester will perform a check of the steering head bearing lower race by mounting the front wheel on a surface plate, then performing a lock to lock check with the weight of the machine on the lower bearing (see illustration 3).


- ✓ Grasp the fork sliders (lower legs) and attempt to push and pull on the forks (see illustration 4). Any play in the steering head bearings will be felt. Note that in extreme cases, wear of the front fork bushes can be misinterpreted for head bearing play.
- ✓ Check that the handlebars are securely mounted.
- ✓ Check that the handlebar grip rubbers are secure. They should be bonded to the bar left end and to the throttle cable pulley on the right end.



Front wheel mounted on a surface plate for steering head bearing lower race check



Checking the steering head bearings for freeplay



Hold the front brake on and pump the front forks up and down to check operation



Inspect the area around the fork dust seal for oil leakage (arrow)

### Front suspension

- ✓ With the motorcycle off the stand, hold the front brake on and pump the front forks up and down (see illustration 5). Check that they are adequately damped.
- ✓ Inspect the area above and around the front fork oil seals (see illustration 6). There should be no sign of oil on the fork tube (stanchion) nor leaking down the slider (lower leg). On models so equipped, check that there is no oil leaking from the anti-dive units.
- ✓ On models with swingarm front suspension, check that there is no freeplay in the linkage when moved from side to side.

### Rear suspension

- ✓ With the motorcycle off the stand and an assistant supporting the motorcycle by its handlebars, bounce the rear suspension (see illustration 7). Check that the suspension components do not foul on any of the cycle parts and check that the shock absorber(s) provide adequate damping.



Bounce the rear of the motorcycle to check rear suspension operation



Check for wheel bearing play by trying to move the wheel about the axle (spindle)



Checking the tyre tread depth



Tyre direction of rotation arrow can be found on tyre sidewall



Castellated type wheel axle (spindle) nut must be secured by a split pin or R-pin



Two straightedges are used to check wheel alignment

- ✓ With the wheel raised off the ground, grasp the wheel and attempt to move it about the axle (spindle) (see illustration 14). Any play felt here indicates wheel bearing failure.
- ✓ Check the tyre tread depth, tread

condition and sidewall condition (see illustration 15).

- ✓ Check the tyre type. Front and rear tyre types must be compatible and be suitable for road use. Tyres marked NOT FOR ROAD

USE, COMPETITION USE ONLY or similar, will fail the MOT.

- ✓ If the tyre sidewall carries a direction of rotation arrow, this must be pointing in the direction of normal wheel rotation (see illustration 16).

- ✓ Check that the wheel axle (spindle) nuts (where applicable) are properly secured. A self-locking nut or castellated nut with a split-pin or R-pin can be used (see illustration 17).

- ✓ Wheel alignment is checked with the motorcycle off the stand and a rider seated. With the front wheel pointing straight ahead, two perfectly straight lengths of metal or wood and placed against the sidewalls of both tyres (see illustration 18). The gap each side of the front tyre must be equidistant on both sides. Incorrect wheel alignment may be due to a cocked rear wheel (often as the result of poor chain adjustment) or in extreme cases, a bent frame.

## General checks and condition

- ✓ Check the security of all major fasteners, bodypanels, seat, fairings (where fitted) and mudguards.

- ✓ Check that the rider and pillion footrests, handlebar levers and brake pedal are securely mounted.

- ✓ Check for corrosion on the frame or any load-bearing components. If severe, this may affect the structure, particularly under stress.

## Sidecars

A motorcycle fitted with a sidecar requires additional checks relating to the stability of the machine and security of attachment and

swivel joints, plus specific wheel alignment (toe-in) requirements. Additionally, tyre and lighting requirements differ from conventional

motorcycle use. Owners are advised to check MOT test requirements with an official test centre.

## Tyres

- Place the bike on its centrestand or an auxiliary stand which will support the motorcycle in an upright position. Position wood blocks under the tyres to keep them off the ground and to provide insulation from damp. If the bike is being put into long-term storage, ideally both tyres should be off the ground; not only will this protect the tyres, but will also ensure that no load is placed on the steering head or wheel bearings.
- Deflate each tyre by 5 to 10 psi, no more or the beads may unseat from the rim, making subsequent inflation difficult on tubeless tyres.

## Pivots and controls

- Lubricate all lever, pedal, stand and footrest pivot points. If grease nipples are fitted to the rear suspension components, apply lubricant to the pivots.
- Lubricate all control cables.

## Cycle components

- Apply a wax protectant to all painted and plastic components. Wipe off any excess, but don't polish to a shine. Where fitted, clean the screen with soap and water.
- Coat metal parts with Vaseline (petroleum jelly). When applying this to the fork tubes, do

not compress the forks otherwise the seals will rot from contact with the Vaseline.

- Apply a vinyl cleaner to the seat.


## Storage conditions

- Aim to store the bike in a shed or garage which does not leak and is free from damp.
- Drape an old blanket or bedspread over the bike to protect it from dust and direct contact with sunlight (which will fade paint). This also hides the bike from prying eyes. Beware of tight-fitting plastic covers which may allow condensation to form and settle on the bike.

# Getting back on the road

## Engine and transmission

- Change the oil and replace the oil filter. If this was done prior to storage, check that the oil hasn't emulsified - a thick whitish substance which occurs through condensation.
- Remove the spark plugs. Using a spout-type oil can, squirt a few drops of oil into the cylinder(s). This will provide initial lubrication as the piston rings and bores come back into contact. Service the spark plugs, or fit new ones, and install them in the engine.
- Check that the clutch isn't stuck on. The plates can stick together if left standing for some time, preventing clutch operation. Engage a gear and try rocking the bike back and forth with the clutch lever held against the handlebar. If this doesn't work on cable-operated clutches, hold the clutch lever back against the handlebar with a strong elastic band or cable tie for a couple of hours (see illustration 8).



Hold clutch lever back against the handlebar with elastic bands or a cable tie

- If the air intakes or silencer end(s) were blocked off, remove the bung or cover used.
- If the fuel tank was coated with a rust preventative, oil or a stabiliser added to the fuel, drain and flush the tank and dispose of the fuel sensibly. If no action was taken with

the fuel tank prior to storage, it is advised that the old fuel is disposed of since it will go off over a period of time. Refill the fuel tank with fresh fuel.

## Frame and running gear

- Oil all pivot points and cables.
- Check the tyre pressures. They will definitely need inflating if pressures were reduced for storage.
- Lubricate the final drive chain (where applicable).
- Remove any protective coating applied to the fork tubes (stanchions) since this may well destroy the fork seals. If the fork tubes weren't protected and have picked up rust spots, remove them with very fine abrasive paper and refinish with metal polish.
- Check that both brakes operate correctly. Apply each brake hard and check that it's not possible to move the motorcycle forwards, then check that the brake frees off again once released. Brake caliper pistons can stick due to corrosion around the piston head, or on the sliding caliper types, due to corrosion of the slider pins. If the brake doesn't free after repeated operation, take the caliper off for examination. Similarly drum brakes can stick due to a seized operating cam, cable or rod linkage.
- If the motorcycle has been in long-term storage, renew the brake fluid and clutch fluid (where applicable).
- Depending on where the bike has been stored, the wiring, cables and hoses may have been nibbled by rodents. Make a visual check and investigate disturbed wiring loom tape.

## Battery

- If the battery has been previously removed and given top up charges it can simply be reconnected. Remember to connect the positive cable first and the negative cable last.
- On conventional refillable batteries, if the battery has not received any attention,

remove it from the motorcycle and check its electrolyte level. Top up if necessary then charge the battery. If the battery fails to hold a charge and a visual check shows heavy white sulphation of the plates, the battery is probably defective and must be renewed. This is particularly likely if the battery is old. Confirm battery condition with a specific gravity check.

- On sealed (MF) batteries, if the battery has not received any attention, remove it from the motorcycle and charge it according to the information on the battery case - if the battery fails to hold a charge it must be renewed.

## Starting procedure

- If a kickstart is fitted, turn the engine over a couple of times with the ignition OFF to distribute oil around the engine. If no kickstart is fitted, flick the engine kill switch OFF and the ignition ON and crank the engine over a couple of times to work oil around the upper cylinder components. If the nature of the ignition system is such that the starter won't work with the kill switch OFF, remove the spark plugs, fit them back into their caps and earth (ground) their bodies on the cylinder head. Reinstall the spark plugs afterwards.
- Switch the kill switch to RUN, operate the choke and start the engine. If the engine won't start don't continue cranking the engine - not only will this flatten the battery, but the starter motor will overheat. Switch the ignition off and try again later. If the engine refuses to start, go through the fault finding procedures in this manual. **Note:** If the bike has been in storage for a long time, old fuel or a carburettor blockage may be the problem. Gum deposits in carburettors can block jets - if a carburettor cleaner doesn't prove successful the carburettors must be dismantled for cleaning.
- Once the engine has started, check that the lights, turn signals and horn work properly.
- Treat the bike gently for the first ride and check all fluid levels on completion. Settle the bike back into the maintenance schedule.

## 1 Engine doesn't start or is difficult to start (continued)

- ☐ Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).
- ☐ Valve spring broken or weak. Caused by component failure or wear; the springs must be replaced (Chapter 2).
- ☐ Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburation) or an accumulation of carbon deposits on the seat (from carburation or lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).
- ☐ Intake air leak. Check for loose carburettor-to-intake manifold connections, loose or missing vacuum gauge adapter screws or hoses, or loose carburettor tops (Chapter 4).
- ☐ Engine idle speed incorrect. Turn idle adjusting screw until the engine idles at the specified rpm (Chapter 1).

### **Rough idle**

- ☐ Ignition malfunction. See Chapter 5.
- ☐ Idle speed incorrect. See Chapter 1.
- ☐ Carburettors not synchronised. Adjust carburettors with vacuum gauge or manometer set as described in Chapter 1.
- ☐ Carburettor malfunction. See Chapter 4.
- ☐ Fuel contaminated. The fuel can be contaminated with either dirt or water, or can change chemically if the machine is allowed to sit for several months or more. Drain the tank and float chambers (Chapter 4).
- ☐ Intake air leak. Check for loose carburettor-to-intake manifold connections, loose or missing vacuum gauge adapter screws or hoses, or loose carburettor tops (Chapter 4).
- ☐ Air filter clogged. Replace the air filter element (Chapter 1).

### **Stalls after starting**

- ☐ Improper choke action. Make sure the choke linkage shaft is getting a full stroke and staying in the out position (Chapter 4).
- ☐ Ignition malfunction. See Chapter 5.
- ☐ Carburettor malfunction. See Chapter 4.
- ☐ Fuel contaminated. The fuel can be contaminated with either dirt or water, or can change chemically if the machine is allowed to sit for several months or more. Drain the tank and float chambers (Chapter 4).

## 2 Poor running at low speeds

### **Spark weak**

- ☐ Battery voltage low. Check and recharge battery (Chapter 9).
- ☐ Spark plugs fouled, defective or worn out. Refer to Chapter 1 for spark plug maintenance.
- ☐ Spark plug cap or HT wiring defective. Refer to Chapters 1 and 5 for details on the ignition system.
- ☐ Spark plug caps not making contact.
- ☐ Incorrect spark plugs. Wrong type, heat range or cap configuration. Check and install correct plugs listed in Chapter 1.
- ☐ Ignition control unit defective. See Chapter 5.
- ☐ Pulse generator defective. See Chapter 5.
- ☐ Ignition HT coils defective. See Chapter 5.

### **Fuel/air mixture incorrect**

- ☐ Pilot screws out of adjustment (Chapter 4).
- ☐ Pilot jet or air passage clogged. Remove and overhaul the carburettors (Chapter 4).
- ☐ Air bleed holes clogged. Remove carburettor and blow out all passages (Chapter 4).
- ☐ Air filter clogged, poorly sealed or missing (Chapter 1).
- ☐ Air filter housing poorly sealed. Look for cracks, holes or loose clamps and replace or repair defective parts.
- ☐ Fuel level too high or too low. Check the float height (Chapter 4).
- ☐ Fuel tank breather hose obstructed.
- ☐ Carburettor inlet manifolds loose. Check for cracks, breaks, tears or loose clamps. Replace the rubber inlet manifold joints if split or perished.

### **Compression low**

- ☐ Spark plugs loose. Remove the plugs and inspect their threads. Reinstall and tighten to the specified torque (Chapter 1).
- ☐ Cylinder heads not sufficiently tightened down. If a cylinder head is suspected of being loose, then there's a chance that the gasket and head are damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).
- ☐ Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- ☐ Cylinder and/or piston worn. Excessive wear will cause

compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top-end overhaul is necessary (Chapter 2).

- ☐ Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburation problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top-end overhaul is necessary (Chapter 2).
- ☐ Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).
- ☐ Cylinder head gasket damaged. If a head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).
- ☐ Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).
- ☐ Valve spring broken or weak. Caused by component failure or wear; the springs must be replaced (Chapter 2).
- ☐ Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburation) or an accumulation of carbon deposits on the seat (from carburation, lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

### **Poor acceleration**

- ☐ Carburettors leaking or dirty. Overhaul the carburettors (Chapter 4).
- ☐ Timing not advancing. The pulse generator or the ignition control module may be defective. If so, they must be replaced with new ones, as they can't be repaired.
- ☐ Carburettors not synchronised. Adjust them with a vacuum gauge set or manometer (Chapter 1).
- ☐ Engine oil viscosity too high. Using a heavier oil than that recommended in Chapter 1 can damage the oil pump or lubrication system and cause drag on the engine.
- ☐ Brakes dragging. Usually caused by debris which has entered the brake piston seals, or from a warped disc or bent axle. Repair as necessary (Chapter 7).

# 1 Engine doesn't start or is difficult to start

## ***Starter motor doesn't rotate***

- ☐ Engine kill switch OFF.
- ☐ Fuse blown. Check main fuse and ignition fuse (Chapter 9).
- ☐ Battery voltage low. Check and recharge battery (Chapter 9).
- ☐ Starter motor defective. Make sure the wiring to the starter is secure. Make sure the starter relay clicks when the start button is pushed. If the relay clicks, then the fault is in the wiring or motor.
- ☐ Starter relay faulty. Check it according to the procedure in Chapter 9.
- ☐ Starter switch not contacting. The contacts could be wet, corroded or dirty. Disassemble and clean the switch (Chapter 9).
- ☐ Wiring open or shorted. Check all wiring connections and harnesses to make sure that they are dry, tight and not corroded. Also check for broken or frayed wires that can cause a short to ground (earth) (see wiring diagram, Chapter 9).
- ☐ Ignition (main) switch defective. Check the switch according to the procedure in Chapter 9. Replace the switch with a new one if it is defective.
- ☐ Faulty neutral, sidestand (RVF only) or clutch switch. Check the wiring to each switch and the switch itself according to the procedures in Chapter 9.

## ***Starter motor rotates but engine does not turn over***

- ☐ Starter motor clutch defective. Inspect and repair or replace (Chapter 2).
- ☐ Damaged idler or starter gears. Inspect and replace the damaged parts (Chapter 2).

## ***Starter works but engine won't turn over (seized)***

- ☐ Seized engine caused by one or more internally damaged components. Failure due to wear, abuse or lack of lubrication. Damage can include seized valves, camshafts, pistons, crankshaft, connecting rod bearings, or transmission gears or bearings. Refer to Chapter 2 for engine disassembly.

## ***No fuel flow***

- ☐ No fuel in tank.
- ☐ Fuel tank breather hose obstructed.
- ☐ Fuel tap filter clogged. Remove the tap and clean it and the filter (Chapter 4).
- ☐ Fuel tap vacuum hose split or detached. Check the hose.
- ☐ Fuel tap diaphragm split. Remove the tap and check the diaphragm (Chapter 4).
- ☐ Fuel line clogged. Pull the fuel line loose and carefully blow through it.
- ☐ Float needle valve clogged. For all of the valves to be clogged, either a very bad batch of fuel with an unusual additive has been used, or some other foreign material has entered the tank. Many times after a machine has been stored for many months without running, the fuel turns to a varnish-like liquid and forms deposits on the inlet needle valves and jets. The carburettors should be removed and overhauled if draining the float chambers doesn't solve the problem.

## ***Engine flooded***

- ☐ Float height too high. Check as described in Chapter 4.
- ☐ Float needle valve worn or stuck open. A piece of dirt, rust or other debris can cause the valve to seat improperly, causing excess fuel to be admitted to the float chamber. In this case, the float chamber should be cleaned and the needle valve and seat inspected. If the needle and seat are worn, then the leaking will persist and the parts should be replaced with new ones (Chapter 4).
- ☐ Starting technique incorrect. Under normal circumstances (ie, if all the carburettor functions are sound) the machine should start with little or no throttle. When the engine is cold, the choke should be

operated and the engine started without opening the throttle. When the engine is at operating temperature, only a very slight amount of throttle should be necessary. If the engine is flooded, turn the fuel tap OFF and hold the throttle open while cranking the engine. This will allow additional air to reach the cylinders. Remember to turn the fuel tap back ON after the engine starts.

## ***No spark or weak spark***

- ☐ Ignition switch OFF.
- ☐ Engine kill switch turned to the OFF position.
- ☐ Battery voltage low. Check and recharge the battery as necessary (Chapter 9).
- ☐ Spark plugs dirty, defective or worn out. Locate reason for fouled plugs using spark plug condition chart and follow the plug maintenance procedures (Chapter 1).
- ☐ Spark plug caps or secondary (HT) wiring faulty. Check condition. Replace either or both components if cracks or deterioration are evident (Chapter 5).
- ☐ Spark plug caps not making good contact. Make sure that the plug caps fit snugly over the plug ends.
- ☐ Ignition control unit defective. Check the unit, referring to Chapter 5 for details.
- ☐ Pulse generator defective. Check the unit, referring to Chapter 5 for details.
- ☐ Ignition HT coils defective. Check the coils, referring to Chapter 5.
- ☐ Ignition or kill switch shorted. This is usually caused by water, corrosion, damage or excessive wear. The switches can be disassembled and cleaned with electrical contact cleaner. If cleaning does not help, replace the switches (Chapter 9).
- ☐ Wiring shorted or broken between:
  - a) Ignition (main) switch and engine kill switch (or blown fuse)
  - b) Ignition control unit and engine kill switch
  - c) Ignition control unit and ignition HT coils
  - d) Ignition HT coils and spark plugs
  - e) Ignition control unit and pulse generator
- ☐ Make sure that all wiring connections are clean, dry and tight. Look for chafed and broken wires (Chapters 5 and 9).

## ***Compression low***

- ☐ Spark plugs loose. Remove the plugs and inspect their threads. Reinstall and tighten to the specified torque (Chapter 1).
- ☐ Cylinder heads not sufficiently tightened down. If a cylinder head is suspected of being loose, then there's a chance that the gasket or head is damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).
- ☐ Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- ☐ Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top-end overhaul is necessary (Chapter 2).
- ☐ Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburation problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top-end overhaul is necessary (Chapter 2).
- ☐ Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).
- ☐ Cylinder head gasket damaged. If a head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).

## 3 Poor running or no power at high speed

### **Firing incorrect**

- ☐ Air filter restricted. Clean or replace filter (Chapter 1).
- ☐ Spark plugs fouled, defective or worn out. See Chapter 1 for spark plug maintenance.
- ☐ Spark plug caps or HT wiring defective. See Chapters 1 and 5 for details of the ignition system.
- ☐ Spark plug caps not in good contact. See Chapter 5.
- ☐ Incorrect spark plugs. Wrong type, heat range or cap configuration. Check and install correct plugs listed in Chapter 1.
- ☐ Ignition control unit defective. See Chapter 5.
- ☐ Ignition coils defective. See Chapter 5.

### **Fuel/air mixture incorrect**

- ☐ Main jet clogged. Dirt, water or other contaminants can clog the main jets. Clean the fuel tap filter, the float chamber area, and the jets and carburettor orifices (Chapter 4).
- ☐ Main jet wrong size. The standard jetting is for sea level atmospheric pressure and oxygen content.
- ☐ Throttle shaft-to-carburettor body clearance excessive. Refer to Chapter 4 for inspection and part replacement procedures.
- ☐ Air bleed holes clogged. Remove and overhaul carburettors (Chapter 4).
- ☐ Air filter clogged, poorly sealed, or missing (Chapter 1).
- ☐ Air filter housing poorly sealed. Look for cracks, holes or loose clamps, and replace or repair defective parts.
- ☐ Fuel level too high or too low. Check the float height (Chapter 4).
- ☐ Fuel tank breather hose obstructed.
- ☐ Carburettor inlet manifolds loose. Check for cracks, breaks, tears or loose clamps. Replace the rubber inlet manifolds if they are split or perished (Chapter 4).

### **Compression low**

- ☐ Spark plugs loose. Remove the plugs and inspect their threads. Reinstall and tighten to the specified torque (Chapter 1).
- ☐ Cylinder heads not sufficiently tightened down. If a cylinder head is suspected of being loose, then there's a chance that the gasket and head are damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).
- ☐ Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- ☐ Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top-end overhaul is necessary (Chapter 2).
- ☐ Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburation problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top-end overhaul is necessary (Chapter 2).

- ☐ Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).
- ☐ Cylinder head gasket damaged. If a head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).
- ☐ Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).
- ☐ Valve spring broken or weak. Caused by component failure or wear; the springs must be replaced (Chapter 2).
- ☐ Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburation) or an accumulation of carbon deposits on the seat (from carburation or lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

### **Knocking or pinking**

- ☐ Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder heads will have to be removed and decarbonised (Chapter 2).
- ☐ Incorrect or poor quality fuel. Old or improper grades of fuel can cause detonation. This causes the piston to rattle, thus the knocking or pinking sound. Drain old fuel and always use the recommended fuel grade.
- ☐ Spark plug heat range incorrect. Uncontrolled detonation indicates the plug heat range is too hot. The plug in effect becomes a glow plug, raising cylinder temperatures. Install the proper heat range plug (Chapter 1).
- ☐ Improper air/fuel mixture. This will cause the cylinders to run hot, which leads to detonation. Clogged jets or an air leak can cause this imbalance. See Chapter 4.

### **Miscellaneous causes**

- ☐ Throttle valve doesn't open fully. Adjust the throttle grip freeplay (Chapter 1).
- ☐ Clutch slipping. May be caused by loose or worn clutch components. Refer to Chapter 2 for clutch overhaul procedures.
- ☐ Timing not advancing.
- ☐ Engine oil viscosity too high. Using a heavier oil than the one recommended in Chapter 1 can damage the oil pump or lubrication system and cause drag on the engine.
- ☐ Brakes dragging. Usually caused by debris which has entered the brake piston seals, or from a warped disc or bent axle. Repair as necessary.

## 6 Gearchange problems

### **Doesn't go into gear or lever doesn't return**

- ☐ Clutch not disengaging. See above.
- ☐ Selector fork(s) bent or seized. Often caused by dropping the machine or from lack of lubrication. Overhaul the transmission (Chapter 2).
- ☐ Gear(s) stuck on shaft. Most often caused by a lack of lubrication or excessive wear in transmission bearings and bushes. Overhaul the transmission (Chapter 2).
- ☐ Selector drum binding. Caused by lubrication failure or excessive wear. Replace the drum and bearing (Chapter 2).
- ☐ Gearchange shaft return spring weak or broken (Chapter 2).
- ☐ Gearchange lever broken. Splines stripped out of lever or shaft, caused by allowing the lever to get loose or from dropping the machine. Replace necessary parts (Chapter 2).

- ☐ Gearchange mechanism stopper arm broken or worn. Full engagement and rotary movement of selector drum results. Replace the arm (Chapter 2).
- ☐ Stopper arm spring broken. Allows arm to float, causing sporadic selector operation. Replace spring (Chapter 2).

### **Jumps out of gear**

- ☐ Selector fork(s) worn. Overhaul the transmission (Chapter 2).
- ☐ Gear groove(s) worn. Overhaul the transmission (Chapter 2).
- ☐ Gear dogs or dog slots worn or damaged. The gears should be inspected and replaced. No attempt should be made to service the worn parts.

### **Overselects**

- ☐ Stopper arm spring weak or broken (Chapter 2).
- ☐ Gearchange shaft return spring post broken or distorted (Chapter 2).

## 7 Abnormal engine noise

### **Knocking or pinking**

- ☐ Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonised (Chapter 2).
- ☐ Incorrect or poor quality fuel. Old or improper fuel can cause detonation. This causes the pistons to rattle, thus the knocking or pinking sound. Drain the old fuel and always use the recommended grade fuel (Chapter 4).
- ☐ Spark plug heat range incorrect. Uncontrolled detonation indicates that the plug heat range is too hot. The plug in effect becomes a glow plug, raising cylinder temperatures. Install the proper heat range plug (Chapter 1).
- ☐ Improper air/fuel mixture. This will cause the cylinders to run hot and lead to detonation. Clogged jets or an air leak can cause this imbalance. See Chapter 4.

- ☐ Connecting rod upper or lower end clearance excessive. Caused by excessive wear or lack of lubrication. Replace worn parts.

### **Valve noise**

- ☐ Incorrect valve clearances. Adjust the clearances by referring to Chapter 1.
- ☐ Valve spring broken or weak. Check and replace weak valve springs (Chapter 2).
- ☐ Camshaft or cylinder head worn or damaged. Lack of lubrication at high rpm is usually the cause of damage. Insufficient oil or failure to change the oil at the recommended intervals are the chief causes. Since there are no replaceable bearings in the head, the head itself will have to be replaced if there is excessive wear or damage (Chapter 2).

### **Other noise**

- ☐ Cylinder head gasket leaking.
- ☐ Exhaust pipe leaking at cylinder head connection. Caused by improper fit of pipe(s) or loose exhaust flange. All exhaust fasteners should be tightened evenly and carefully. Failure to do this will lead to a leak.
- ☐ Crankshaft runout excessive. Caused by a bent crankshaft (from over-revving) or damage from an upper cylinder component failure. Can also be attributed to dropping the machine on either of the crankshaft ends.
- ☐ Engine mounting bolts loose. Tighten all engine mount bolts (Chapter 2).
- ☐ Crankshaft bearings worn (Chapter 2).
- ☐ Camshaft drive gear assembly defective. Replace according to the procedure in Chapter 2.

### **Piston slap or rattling**

- ☐ Cylinder-to-piston clearance excessive. Caused by improper assembly. Inspect and overhaul top-end parts (Chapter 2).
- ☐ Connecting rod bent. Caused by over-revving, trying to start a badly flooded engine or from ingesting a foreign object into the combustion chamber. Replace the damaged parts (Chapter 2).
- ☐ Piston pin or piston pin bore worn or seized from wear or lack of lubrication. Replace damaged parts (Chapter 2).
- ☐ Piston ring(s) worn, broken or sticking. Overhaul the top-end (Chapter 2).
- ☐ Piston seizure damage. Usually from lack of lubrication or overheating. Replace the pistons and renew the crankcase/bore, as necessary (Chapter 2).

## 8 Abnormal driveline noise

### **Clutch noise**

- ☐ Clutch outer drum/friction plate clearance excessive (Chapter 2).
- ☐ Loose or damaged clutch pressure plate (Chapter 2).

### **Transmission noise**

- ☐ Bearings worn. Also includes the possibility that the shafts are worn. Overhaul the transmission (Chapter 2).
- ☐ Gears worn or chipped (Chapter 2).
- ☐ Metal chips jammed in gear teeth. Probably pieces from a broken clutch, gear or selector mechanism that were picked up by the gears. This will cause early bearing failure (Chapter 2).

- ☐ Engine oil level too low. Causes a howl from transmission. Also affects engine power and clutch operation (Chapter 1).

### **Final drive noise**

- ☐ Chain not adjusted properly (Chapter 1).
- ☐ Front or rear sprocket loose. Tighten fasteners (Chapter 6).
- ☐ Sprockets worn. Replace sprockets (Chapter 6).
- ☐ Rear sprocket warped. Replace sprockets (Chapter 6).
- ☐ Wheel drive pins worn or loose or drive pin holes worn. Check and tighten or replace (Chapter 7).

## 12 Poor handling or stability

### Handlebars hard to turn

- ☐ Steering head bearing adjuster nut too tight. Check adjustment as described in Chapter 1.
- ☐ Bearings damaged. Roughness can be felt as the bars are turned from side-to-side. Replace bearings and races (Chapter 6).
- ☐ Races dented or worn. Denting results from wear in only one position (eg, straight ahead), from a collision or hitting a pothole or from dropping the machine. Replace races and bearings (Chapter 6).
- ☐ Steering stem lubrication inadequate. Causes are grease getting hard from age or being washed out by high pressure car washes. Disassemble steering head and repack bearings (Chapter 6).
- ☐ Steering stem bent. Caused by a collision, hitting a pothole or by dropping the machine. Replace damaged part. Don't try to straighten the steering stem (Chapter 6).
- ☐ Front tyre air pressure too low (Chapter 1).

### Handlebar shakes or vibrates excessively

- ☐ Tyres worn or out of balance (Chapter 7).
- ☐ Swingarm bearings worn. Replace worn bearings (Chapter 6).
- ☐ Wheel rim(s) warped or damaged. Inspect wheels for runout (Chapter 7).
- ☐ Wheel bearings worn. Worn front wheel bearings or rear wheel holder bearings can cause poor tracking. Worn front bearings will cause wobble (Chapter 7).
- ☐ Handlebar clamp bolts loose (Chapter 6).
- ☐ Fork yoke bolts loose. Tighten them to the specified torque (Chapter 6).
- ☐ Engine mounting bolts loose. Will cause excessive vibration with increased engine rpm (Chapter 2).

### Handlebar pulls to one side

- ☐ Frame bent. Definitely suspect this if the machine has been dropped. May or may not be accompanied by cracking near the bend. Replace the frame (Chapter 6).
- ☐ Wheels out of alignment. Caused by improper location of axle spacers or from bent steering stem or frame (Chapter 6).
- ☐ Swingarm bent or twisted. Caused by age (metal fatigue) or impact damage. Replace the arm (Chapter 6).
- ☐ Steering stem bent. Caused by impact damage or by dropping the motorcycle. Replace the steering stem (Chapter 6).
- ☐ Fork tube bent. Disassemble the forks and replace the damaged parts (Chapter 6).
- ☐ Fork oil level uneven. Check and add or drain as necessary (Chapter 6).

### Poor shock absorbing qualities

#### Too hard:

- a) Fork oil level excessive (Chapter 6).
- b) Fork oil viscosity too high. Use a lighter oil (see the Specifications in Chapter 6).
- c) Fork tube bent. Causes a harsh, sticking feeling (Chapter 6).
- d) Shock shaft or body bent or damaged (Chapter 6).
- e) Fork internal damage (Chapter 6).
- f) Shock internal damage.
- g) Tyre pressure too high (Chapter 1).

#### Too soft:

- a) Fork or shock oil insufficient and/or leaking (Chapter 6).
- b) Fork oil level too low (Chapter 6).
- c) Fork oil viscosity too light (Chapter 6).
- d) Fork springs weak or broken (Chapter 6).
- e) Shock internal damage or leakage (Chapter 6).

## 13 Braking problems

### Brakes are spongy, don't hold

- ☐ Air in brake line. Caused by inattention to master cylinder fluid level or by leakage. Locate problem and bleed brakes (Chapter 7).
- ☐ Pad or disc worn (Chapters 1 and 7).
- ☐ Brake fluid leak. See paragraph 1.
- ☐ Contaminated pads. Caused by contamination with oil, grease, brake fluid, etc. Clean or replace pads. Clean disc thoroughly with brake cleaner (Chapter 7).
- ☐ Brake fluid deteriorated. Fluid is old or contaminated. Drain system, replenish with new fluid and bleed the system (Chapter 7).
- ☐ Master cylinder internal parts worn or damaged causing fluid to bypass (Chapter 7).
- ☐ Master cylinder bore scratched by foreign material or broken spring. Repair or replace master cylinder (Chapter 7).
- ☐ Disc warped. Replace disc (Chapter 7).

### Brake lever or pedal pulsates

- ☐ Disc warped. Replace disc (Chapter 7).
- ☐ Axle bent. Replace axle (Chapter 7).

- ☐ Brake caliper bolts loose (Chapter 7).
- ☐ Brake caliper sliders damaged or sticking (rear caliper), causing caliper to bind. Lubricate the sliders or replace them if they are corroded or bent (Chapter 7).
- ☐ Wheel warped or otherwise damaged (Chapter 7).
- ☐ Wheel bearings damaged or worn (Chapter 7).


### Brakes drag

- ☐ Master cylinder piston seized. Caused by wear or damage to piston or cylinder bore (Chapter 7).
- ☐ Lever balky or stuck. Check pivot and lubricate (Chapter 7).
- ☐ Brake caliper binds. Caused by inadequate lubrication or damage to caliper sliders (Chapter 7).
- ☐ Brake caliper piston seized in bore. Caused by wear or ingestion of dirt past deteriorated seal (Chapter 7).
- ☐ Brake pad damaged. Pad material separated from backing plate. Usually caused by faulty manufacturing process or from contact with chemicals. Replace pads (Chapter 7).
- ☐ Pads improperly installed (Chapter 7).

## REF•36 Fault Finding Equipment

the ignition switch ON; open the throttle fully and crank the engine over on the starter motor for a couple of revolutions until the gauge reading stabilises. If the starter will not operate with the kill switch OFF, turn the ignition switch OFF and refer to the next paragraph.

5 Install the spark plugs back into their suppressor caps and arrange the plug electrodes so that their metal bodies are earthed (grounded) against the cylinder head; this is essential to prevent damage to the ignition system as the engine is spun over (see illustration 2). Position the plugs well away from the plug holes otherwise there is a risk of atomised fuel escaping from the combustion chambers and igniting. As a safety precaution, cover the top of the valve cover with rag. Now turn the ignition switch ON and kill switch ON, open the throttle fully and crank the engine over on the starter motor for a couple of revolutions until the gauge reading stabilises.



**All spark plugs must be earthed (grounded) against the cylinder head**

6 After one or two revolutions the pressure should build up to a maximum figure and then stabilise. Take a note of this reading and on multi-cylinder engines repeat the test on the remaining cylinders.

7 The correct pressures are given in Chapter 2 Specifications. If the results fall within the specified range and on multi-cylinder engines all are relatively equal, the engine is in good condition. If there is a marked difference between the readings, or if the readings are lower than specified, inspection of the top-end components will be required.

8 Low compression pressure may be due to worn cylinder bores, pistons or rings, failure of the cylinder head gasket, worn valve seals, or poor valve seating.

9 To distinguish between cylinder/piston wear and valve leakage, pour a small quantity of oil into the bore to temporarily seal the piston rings, then repeat the compression tests (see illustration 3). If the readings show a noticeable increase in pressure this confirms that the cylinder bore, piston, or rings are worn. If, however, no change is indicated, the cylinder head gasket or valves should be examined.



**Bores can be temporarily sealed with a squirt of motor oil**


10 High compression pressure indicates excessive carbon build-up in the combustion chamber and on the piston crown. If this is the case the cylinder head should be removed and the deposits removed. Note that excessive carbon build-up is less likely with the used on modern fuels.

### Checking battery open-circuit voltage



**Warning: The gases produced by the battery are explosive - never smoke or create any sparks in the vicinity of the battery. Never allow the electrolyte to contact your skin or clothing - if it does, wash it off and seek immediate medical attention.**

- Before any electrical fault is investigated the battery should be checked.
  - You'll need a dc voltmeter or multimeter to check battery voltage. Check that the leads are inserted in the correct terminals on the meter, red lead to positive (+ve), black lead to negative (-ve). Incorrect connections can damage the meter.
  - A sound fully-charged 12 volt battery should produce between 12.3 and 12.6 volts across its terminals (12.8 volts for a maintenance-free battery). On machines with a 6 volt battery, voltage should be between 6.1 and 6.3 volts.
- 1 Set a multimeter to the 0 to 20 volts dc range and connect its probes across the



**Measuring open-circuit battery voltage**

battery terminals. Connect the meter's positive (+ve) probe, usually red, to the battery positive (+ve) terminal, followed by the meter's negative (-ve) probe, usually black, to the battery negative terminal (-ve) (see illustration 4).


2 If battery voltage is low (below 10 volts on a 12 volt battery or below 4 volts on a six volt battery), charge the battery and test the voltage again. If the battery repeatedly goes flat, investigate the motorcycle's charging system.

### Checking battery specific gravity (SG)



**Warning: The gases produced by the battery are explosive - never smoke or create any sparks in the vicinity of the battery. Never allow the electrolyte to contact your skin or clothing - if it does, wash it off and seek immediate medical attention.**

- The specific gravity check gives an indication of a battery's state of charge.
- A hydrometer is used for measuring specific gravity. Make sure you purchase one which has a small enough hose to insert in the aperture of a motorcycle battery.
- Specific gravity is simply a measure of the electrolyte's density compared with that of water. Water has an SG of 1.000 and fully-charged battery electrolyte is about 26% heavier, at 1.260.
- Specific gravity checks are not possible on maintenance-free batteries. Testing the open-circuit voltage is the only means of determining their state of charge.



**Float-type hydrometer for measuring battery specific gravity**

- 1 To measure SG, remove the battery from the motorcycle and remove the first cell cap. Draw some electrolyte into the hydrometer and note the reading (see illustration 5). Return the electrolyte to the cell and install the cap.
- 2 The reading should be in the region of 1.260 to 1.280. If SG is below 1.200 the battery needs charging. Note that SG will vary with temperature; it should be measured at 20°C (68°F). Add 0.007 to the reading for

every 10°C above 20°C, and subtract 0.007 from the reading for every 10°C below 20°C. Add 0.004 to the reading for every 10°F above 68°F, and subtract 0.004 from the reading for every 10°F below 68°F.

3 When the check is complete, rinse the hydrometer thoroughly with clean water.


## Checking for continuity

● The term continuity describes the uninterrupted flow of electricity through an electrical circuit. A continuity check will determine whether an **open-circuit** situation exists.


● Continuity can be checked with an ohmmeter, multimeter, continuity tester or battery and bulb test circuit (see illustrations 6, 7 and 8).



Digital multimeter can be used for all electrical tests



Battery-powered continuity tester



Battery and bulb test circuit

● All of these instruments are self-powered by a battery, therefore the checks are made with the ignition OFF.

● As a safety precaution, always disconnect the battery negative (-ve) lead before making checks, particularly if ignition switch checks are being made.

● If using a meter, select the appropriate ohms scale and check that the meter reads infinity ( $\infty$ ). Touch the meter probes together and check that meter reads zero; where necessary adjust the meter so that it reads zero.

● After using a meter, always switch it OFF to conserve its battery.

## Switch checks

1 If a switch is at fault, trace its wiring up to the wiring connectors. Separate the wire connectors and inspect them for security and condition. A build-up of dirt or corrosion here will most likely be the cause of the problem - clean up and apply a water dispersant such as WD40.




Continuity check of front brake light switch using a meter - note split pins used to access connector terminals

2 If using a test meter, set the meter to the ohms x 10 scale and connect its probes across the wires from the switch (see illustration 9). Simple ON/OFF type switches, such as brake light switches, only have two wires whereas combination switches, like the ignition switch, have many internal links. Study the wiring diagram to ensure that you are connecting across the correct pair of wires. Continuity (low or no measurable resistance - 0 ohms) should be indicated with the switch ON and no continuity (high resistance) with it OFF.

3 Note that the polarity of the test probes doesn't matter for continuity checks, although care should be taken to follow specific test procedures if a diode or solid-state component is being checked.

4 A continuity tester or battery and bulb circuit can be used in the same way. Connect its probes as described above (see illustration 10). The light should come on to indicate continuity in the ON switch position, but should extinguish in the OFF position.




Continuity check of rear brake light switch using a continuity tester

## Wiring checks

● Many electrical faults are caused by damaged wiring, often due to incorrect routing or chaffing on frame components.

● Loose, wet or corroded wire connectors can also be the cause of electrical problems, especially in exposed locations.

1 A continuity check can be made on a single length of wire by disconnecting it at each end and connecting a meter or continuity tester across both ends of the wire (see illustration 11).



Continuity check of front brake light switch sub-harness


2 Continuity (low or no resistance - 0 ohms) should be indicated if the wire is good. If no continuity (high resistance) is shown, suspect a broken wire.

## Checking for voltage

● A voltage check can determine whether current is reaching a component.

● Voltage can be checked with a dc voltmeter, multimeter set on the dc volts scale, test light or buzzer (see illustrations 12 and 13). A meter has the advantage of being able to measure actual voltage.

## REF•38 Fault Finding Equipment



**12**  
A simple test light can be used for voltage checks



**13**  
A buzzer is useful for voltage checks

- When using a meter, check that its leads are inserted in the correct terminals on the meter, red to positive (+ve), black to negative (-ve). Incorrect connections can damage the meter.

- A voltmeter (or multimeter set to the dc volts scale) should always be connected in parallel (across the load). Connecting it in series will destroy the meter.

- Voltage checks are made with the ignition ON.


1 First identify the relevant wiring circuit by referring to the wiring diagram at the end of this manual. If other electrical components share the same power supply (ie are fed from the same fuse), take note whether they are working correctly - this is useful information in deciding where to start checking the circuit.



**14**  
Checking for voltage at the rear brake light power supply wire using a meter...

2 If using a meter, check first that the meter leads are plugged into the correct terminals on the meter (see above). Set the meter to the dc volts function, at a range suitable for the battery voltage. Connect the meter red probe (+ve) to the power supply wire and the black probe to a good metal earth (ground) on the motorcycle's frame or directly to the battery negative (-ve) terminal (see illustration 14). Battery voltage should be shown on the meter with the ignition switched ON.

3 If using a test light or buzzer, connect its positive (+ve) probe to the power supply terminal and its negative (-ve) probe to a good earth (ground) on the motorcycle's frame or directly to the battery negative (-ve) terminal (see illustration 15). With the ignition ON, the test light should illuminate or the buzzer sound.



**15**  
... or a test light - note the earth connection to the frame (arrow)

4 If no voltage is indicated, work back towards the fuse continuing to check for voltage. When you reach a point where there is voltage, you know the problem lies between that point and your last check point.


### Checking the earth (ground)

- Earth connections are made either directly to the engine or frame (such as sensors, neutral switch etc. which only have a positive feed) or by a separate wire into the earth circuit of the wiring harness. Alternatively a short earth wire is sometimes run directly from the component to the motorcycle's frame.

- Corrosion is often the cause of a poor earth connection.

- If total failure is experienced, check the security of the main earth lead from the negative (-ve) terminal of the battery and also the main earth (ground) point on the wiring harness. If corroded, dismantle the connection and clean all surfaces back to bare metal.

1 To check the earth on a component, use an insulated jumper wire to temporarily bypass its earth connection (see illustration 16). Connect one end of the jumper wire between the earth terminal or metal body of the component and the other end to the motorcycle's frame.



**16**  
A selection of jumper wires for making earth (ground) checks

2 If the circuit works with the jumper wire installed, the original earth circuit is faulty. Check the wiring for open-circuits or poor connections. Clean up direct earth connections, removing all traces of corrosion and remake the joint. Apply petroleum jelly to the joint to prevent future corrosion.

### Tracing a short-circuit

- A short-circuit occurs where current shorts to earth (ground) bypassing the circuit components. This usually results in a blown fuse.

- A short-circuit is most likely to occur where the insulation has worn through due to wiring chafing on a component, allowing a direct path to earth (ground) on the frame.

1 Remove any bodypanels necessary to access the circuit wiring.

2 Check that all electrical switches in the circuit are OFF, then remove the circuit fuse and connect a test light, buzzer or voltmeter (set to the dc scale) across the fuse terminals. No voltage should be shown.

3 Move the wiring from side to side whilst observing the test light or meter. When the test light comes on, buzzer sounds or meter shows voltage, you have found the cause of the short. It will usually show up as damaged or burned insulation.

4 Note that the same test can be performed on each component in the circuit, even the switch.

**Lapping** see Grinding.

**LCD** Abbreviation for Liquid Crystal Display.

**LED** Abbreviation for Light Emitting Diode.

**Liner** A steel cylinder liner inserted in a aluminium alloy cylinder block.

**Locknut** A nut used to lock an adjustment nut, or other threaded component, in place.

**Lockstops** The lugs on the lower triple clamp (yoke) which abut those on the frame, preventing handlebar-to-fuel tank contact.

**Lockwasher** A form of washer designed to prevent an attaching nut from working loose.

**LT Low Tension** Description of the electrical circuit from the power supply to the primary winding of the ignition coil.

## M

**Main bearings** The bearings between the crankshaft and crankcase.

**Maintenance-free (MF) battery** A sealed battery which cannot be topped up.

**Manometer** Mercury-filled calibrated tubes used to measure intake tract vacuum. Used to synchronise carburettors on multi-cylinder engines.

**Micrometer** A precision measuring instrument that measures component outside diameters (see illustration).



Tappet shims are measured with a micrometer

**MON (Motor Octane Number)** A measure of a fuel's resistance to knock.

**Monograde oil** An oil with a single viscosity, eg SAE80W.

**Monoshock** A single suspension unit linking the swingarm or suspension linkage to the frame.

**mph** Abbreviation for miles per hour.

**Multigrade oil** Having a wide viscosity range (eg 10W40). The W stands for Winter, thus the viscosity ranges from SAE10 when cold to SAE40 when hot.

**Multimeter** An electrical test instrument with the capability to measure voltage, current and resistance. Some meters also incorporate a continuity tester and buzzer.

## N

**Needle roller bearing** Inner race of caged needle rollers and hardened outer race. Examples of uncaged needle rollers can be found on some engines. Commonly used in rear suspension applications and in two-stroke engines.

**Nm** Newton metres.

**NOx** Oxides of Nitrogen. A common toxic pollutant emitted by petrol engines at higher temperatures.

## O

**Octane** The measure of a fuel's resistance to knock.

**OE (Original Equipment)** Relates to components fitted to a motorcycle as standard or replacement parts supplied by the motorcycle manufacturer.

**Ohm** The unit of electrical resistance. Ohms = Volts ÷ Current.

**Ohmmeter** An instrument for measuring electrical resistance.

**Oil cooler** System for diverting engine oil outside of the engine to a radiator for cooling purposes.

**Oil injection** A system of two-stroke engine lubrication where oil is pump-fed to the engine in accordance with throttle position.

**Open-circuit** An electrical condition where there is a break in the flow of electricity - no continuity (high resistance).

**O-ring** A type of sealing ring made of a special rubber-like material; in use, the O-ring is compressed into a groove to provide the **Overlap (OS)** Term used for piston and ring size options fitted to a rebored cylinder.

**Overhead cam (sohc) engine** An engine with single camshaft located on top of the cylinder head.

**Overhead valve (ohv) engine** An engine with the valves located in the cylinder head, but with the camshaft located in the engine block or crankcase.

**Oxygen sensor** A device installed in the exhaust system which senses the oxygen content in the exhaust and converts this information into an electric current. Also called a Lambda sensor.

## P

**Plastigauge** A thin strip of plastic thread, available in different sizes, used for measuring clearances. For example, a strip of Plastigauge is laid across a bearing journal. The parts are assembled and dismantled; the width of the crushed strip indicates the clearance between journal and bearing.

**Polarity** Either negative or positive earth (ground), determined by which battery lead is connected to the frame (earth return). Modern motorcycles are usually negative earth.

**Pre-ignition** A situation where the fuel/air mixture ignites before the spark plug fires. Often due to a hot spot in the combustion chamber caused by carbon build-up. Engine has a tendency to 'run-on'.

**Pre-load (suspension)** The amount a spring is compressed when in the unloaded state. Preload can be applied by gas, spacer or mechanical adjuster.

**Premix** The method of engine lubrication on older two-stroke engines. Engine oil is mixed with the petrol in the fuel tank in a specific ratio. The fuel/oil mix is sometimes referred to as 'petrol'.

**Primary drive** Description of the drive from the crankshaft to the clutch. Usually by gear or chain.

**PS** Pfedestärke - a German interpretation of BHP.


**PSI** Pounds-force per square inch. Imperial measurement of tyre pressure and cylinder pressure measurement.

**PTFE** Polytetrafluoroethylene. A low friction substance.

**Pulse secondary air injection system** A process of promoting the burning of excess fuel present in the exhaust gases by routing fresh air into the exhaust ports.

## Q

**Quartz halogen bulb** Tungsten filament surrounded by a halogen gas. Typically used for the headlight (see illustration).



Quartz halogen headlight bulb construction

## R


**Rack-and-pinion** A pinion gear on the end of a shaft that mates with a rack (think of a geared wheel opened up and laid flat). Sometimes used in clutch operating systems.

**Radial play** Up and down movement about a shaft.

**Radial ply tyres** Tyre plies run across the tyre (from bead to bead) and around the circumference of the tyre. Less resistant to tread distortion than other tyre types.

**Radiator** A liquid-to-air heat transfer device designed to reduce the temperature of the coolant in a liquid cooled engine.

**Rake** A feature of steering geometry - the angle of the steering head in relation to the vertical (see illustration).



Steering geometry

## REF•40 Technical Terms Explained

**Decarbonisation** The process of removing carbon deposits - typically from the combustion chamber, valves and exhaust port/system.

**Detonation** Destructive and damaging explosion of fuel/air mixture in combustion chamber instead of controlled burning.

**Diode** An electrical valve which only allows current to flow in one direction. Commonly used in rectifiers and starter interlock systems.

**Disc valve (or rotary valve)** A induction system used on some two-stroke engines.

**Double-overhead camshaft (DOHC)** An engine that uses two overhead camshafts, one for the intake valves and one for the exhaust valves.

**Drivebelt** A toothed belt used to transmit drive to the rear wheel on some motorcycles. A drivebelt has also been used to drive the camshafts. Drivebelts are usually made of Kevlar.

**Driveshaft** Any shaft used to transmit motion. Commonly used when referring to the final driveshaft on shaft drive motorcycles.

## E

**Earth return** The return path of an electrical circuit, utilising the motorcycle's frame.

**ECU (Electronic Control Unit)** A computer which controls (for instance) an ignition system, or an anti-lock braking system.

**EGO** Exhaust Gas Oxygen sensor. Sometimes called a Lambda sensor.

**Electrolyte** The fluid in a lead-acid battery.

**EMS (Engine Management System)** A computer-controlled system which manages the fuel injection and the ignition systems in an integrated fashion.

**Endfloat** The amount of lengthways movement between two parts. As applied to a crankshaft, the distance that the crankshaft can move side-to-side in the crankcase.

**Endless chain** A chain having no joining link. Common use for cam chains and final drive chains.

**EP (Extreme Pressure)** Oil type used in locations where high loads are applied, such as between gear teeth.

**Evaporative emission control system** Describes a charcoal filled canister which stores fuel vapours from the tank rather than allowing them to vent to the atmosphere. Usually only fitted to California models and referred to as an EVAP system.

**Expansion chamber** Section of two-stroke engine exhaust system so designed to improve engine efficiency and boost power.

## F

**Feeler blade or gauge** A thin strip or blade of hardened steel, ground to an exact thickness, used to check or measure clearances between parts.

**Final drive** Description of the drive from the transmission to the rear wheel. Usually by chain or shaft, but sometimes by belt.

**Firing order** The order in which the engine cylinders fire, or deliver their power strokes, beginning with the number one cylinder.

**Flooding** Term used to describe a high fuel level in the carburettor float chambers, leading to fuel overflow. Also refers to excess fuel in the combustion chamber due to incorrect starting technique.

**Free length** The no-load state of a component when measured. Clutch, valve and fork spring lengths are measured at rest, without any preload.

**Freeplay** The amount of travel before any action takes place. The looseness in a linkage, or an assembly of parts, between the initial application of force and actual movement. For example, the distance the rear brake pedal moves before the rear brake is actuated.

**Fuel injection** The fuel/air mixture is metered electronically and directed into the engine intake ports (indirect injection) or into the cylinders (direct injection). Sensors supply information on engine speed and conditions.

**Fuel/air mixture** The charge of fuel and air going into the engine. See **Stoichiometric ratio**.

**Fuse** An electrical device which protects a circuit against accidental overload. The typical fuse contains a soft piece of metal which is calibrated to melt at a predetermined current flow (expressed as amps) and break the circuit.

## G

**Gap** The distance the spark must travel in jumping from the centre electrode to the side electrode in a spark plug. Also refers to the distance between the ignition rotor and the pickup coil in an electronic ignition system.

**Gasket** Any thin, soft material - usually cork, cardboard, asbestos or soft metal - installed between two metal surfaces to ensure a good seal. For instance, the cylinder head gasket seals the joint between the block and the cylinder head.

**Gauge** An instrument panel display used to monitor engine conditions. A gauge with a movable pointer on a dial or a fixed scale is an analogue gauge. A gauge with a numerical readout is called a digital gauge.

**Gear ratios** The drive ratio of a pair of gears in a gearbox, calculated on their number of teeth.


**Glaze-busting** see **Honing**

**Grinding** Process for renovating the valve face and valve seat contact area in the cylinder head.

**Gudgeon pin** The shaft which connects the connecting rod small-end with the piston. Often called a piston pin or wrist pin.

## H

**Helical gears** Gear teeth are slightly curved and produce less gear noise than straight-cut gears. Often used for primary drives.



Installing a Helicoil thread insert in a cylinder head

**Helicoil** A thread insert repair system. Commonly used as a repair for stripped spark plug threads (see illustration).

**Honing** A process used to break down the glaze on a cylinder bore (also called glaze-busting). Can also be carried out to roughen a rebored cylinder to aid ring bedding-in.

**HT High Tension** Description of the electrical circuit from the secondary winding of the ignition coil to the spark plug.

**Hydraulic** A liquid filled system used to transmit pressure from one component to another. Common uses on motorcycles are brakes and clutches.

**Hydrometer** An instrument for measuring the specific gravity of a lead-acid battery.

**Hygroscopic** Water absorbing. In motorcycle applications, braking efficiency will be reduced if DOT 3 or 4 hydraulic fluid absorbs water from the air - care must be taken to keep new brake fluid in tightly sealed containers.

## I

**lbf ft** Pounds-force feet. An imperial unit of torque. Sometimes written as ft-lbs.

**lbf in** Pound-force inch. An imperial unit of torque, applied to components where a very low torque is required. Sometimes written as in-lbs.

**IC** Abbreviation for Integrated Circuit.

**Ignition advance** Means of increasing the timing of the spark at higher engine speeds. Done by mechanical means (ATU) on early engines or electronically by the ignition control unit on later engines.

**Ignition timing** The moment at which the spark plug fires, expressed in the number of crankshaft degrees before the piston reaches the top of its stroke, or in the number of millimetres before the piston reaches the top of its stroke.

**Infinity (∞)** Description of an open-circuit electrical state, where no continuity exists.

**Inverted forks (upside down forks)** The sliders or lower legs are held in the yokes and the fork tubes or stanchions are connected to the wheel axle (spindle). Less unsprung weight and stiffer construction than conventional forks.

## J

**JASO** Quality standard for 2-stroke oils.

**Joule** The unit of electrical energy.

**Journal** The bearing surface of a shaft.

## K

**Kickstart** Mechanical means of turning the engine over for starting purposes. Only usually fitted to mopeds, small capacity motorcycles and off-road motorcycles.

**Kill switch** Handbar-mounted switch for emergency ignition cut-out. Cuts the ignition circuit on all models, and additionally prevent starter motor operation on others.

**km** Symbol for kilometre.

**kph** Abbreviation for kilometres per hour.

## L

**Lambda (λ) sensor** A sensor fitted in the exhaust system to measure the exhaust gas oxygen content (excess air factor).

## REF•42 Technical Terms Explained

**Rebore** Providing a new working surface to the cylinder bore by boring out the old surface. Necessitates the use of oversize piston and rings.

**Rebound damping** A means of controlling the oscillation of a suspension unit spring after it has been compressed. Resists the spring's natural tendency to bounce back after being compressed.

**Rectifier** Device for converting the ac output of an alternator into dc for battery charging.

**Reed valve** An induction system commonly used on two-stroke engines.

**Regulator** Device for maintaining the charging voltage from the generator or alternator within a specified range.

**Relay** A electrical device used to switch heavy current on and off by using a low current auxiliary circuit.

**Resistance** Measured in ohms. An electrical component's ability to pass electrical current.

**RON (Research Octane Number)** A measure of a fuel's resistance to knock.

**rpm** revolutions per minute.

**Runout** The amount of wobble (in-and-out movement) of a wheel or shaft as it's rotated. The amount a shaft rotates 'out-of-true'. The out-of-round condition of a rotating part.

## S

**SAE (Society of Automotive Engineers)** A standard for the viscosity of a fluid.

**Sealant** A liquid or paste used to prevent leakage at a joint. Sometimes used in conjunction with a gasket.

**Service limit** Term for the point where a component is no longer useable and must be renewed.

**Shaft drive** A method of transmitting drive from the transmission to the rear wheel.

**Shell bearings** Plain bearings consisting of two shell halves. Most often used as big-end and main bearings in a four-stroke engine. Often called bearing inserts.

**Shim** Thin spacer, commonly used to adjust the clearance or relative positions between two parts. For example, shims inserted into or under tappets or followers to control valve clearances. Clearance is adjusted by changing the thickness of the shim.

**Short-circuit** An electrical condition where current shorts to earth (ground) bypassing the circuit components.

**Skimming** Process to correct warpage or repair a damaged surface, eg on brake discs or drums.

**Slide-hammer** A special puller that screws into or hooks onto a component such as a shaft or bearing; a heavy sliding handle on the shaft bottoms against the end of the shaft to knock the component free.

**Small-end bearing** The bearing in the upper end of the connecting rod at its joint with the gudgeon pin.

**Spalling** Damage to camshaft lobes or bearing journals shown as pitting of the working surface.

**Specific gravity (SG)** The state of charge of the electrolyte in a lead-acid battery. A measure of the electrolyte's density compared with water.

**Straight-cut gears** Common type gear used on gearbox shafts and for oil pump and water pump drives.

**Stanchion** The inner sliding part of the front forks, held by the yokes. Often called a fork tube.

**Stoichiometric ratio** The optimum chemical air/fuel ratio for a petrol engine, said to be 14.7 parts of air to 1 part of fuel.

**Sulphuric acid** The liquid (electrolyte) used in a lead-acid battery. Poisonous and extremely corrosive.

**Surface grinding (lapping)** Process to correct a warped gasket face, commonly used on cylinder heads.

## T

**Tapered-roller bearing** Tapered inner race of caged needle rollers and separate tapered outer race. Examples of taper roller bearings can be found on steering heads.

**Tappet** A cylindrical component which transmits motion from the cam to the valve stem, either directly or via a pushrod and rocker arm. Also called a cam follower.

**TCS** Traction Control System. An electronically-controlled system which senses wheel spin and reduces engine speed accordingly.

**TDC** Top Dead Centre denotes that the piston is at its highest point in the cylinder.

**Thread-locking compound** Solution applied to fastener threads to prevent slackening. Select type to suit application.

**Thrust washer** A washer positioned between two moving components on a shaft. For example, between gear pinions on gearshaft.

**Timing chain** See **Cam Chain**.

**Timing light** Stroboscopic lamp for carrying out ignition timing checks with the engine running.

**Top-end** A description of an engine's cylinder block, head and valve gear components.

**Torque** Turning or twisting force about a shaft.

**Torque setting** A prescribed tightness specified by the motorcycle manufacturer to ensure that the bolt or nut is secured correctly. Undertightening can result in the bolt or nut coming loose or a surface not being sealed. Overtightening can result in stripped threads, distortion or damage to the component being retained.

**Torx key** A six-point wrench.

**Tracer** A stripe of a second colour applied to a wire insulator to distinguish that wire from another one with the same colour insulator. For example, Br/W is often used to denote a brown insulator with a white tracer.

**Trail** A feature of steering geometry. Distance from the steering head axis to the tyre's central contact point.

**Triple clamps** The cast components which extend from the steering head and support the fork stanchions or tubes. Often called fork yokes.

**Turbocharger** A centrifugal device, driven by exhaust gases, that pressurises the intake air. Normally used to increase the power output from a given engine displacement.

**TWI** Abbreviation for Tyre Wear Indicator. Indicates the location of the tread depth indicator bars on tyres.

## U

**Universal joint or U-joint (UJ)** A double-pivoted connection for transmitting power from a driving to a driven shaft through an angle. Typically found in shaft drive assemblies.

**Unsprung weight** Anything not supported by the bike's suspension (ie the wheel, tyres, brakes, final drive and bottom (moving) part of the suspension).

## V

**Vacuum gauges** Clock-type gauges for measuring intake tract vacuum. Used for carburettor synchronisation on multi-cylinder engines.

**Valve** A device through which the flow of liquid, gas or vacuum may be stopped, started or regulated by a moveable part that opens, shuts or partially obstructs one or more ports or passageways. The intake and exhaust valves in the cylinder head are of the poppet type.

**Valve clearance** The clearance between the valve tip (the end of the valve stem) and the rocker arm or tappet/follower. The valve clearance is measured when the valve is closed. The correct clearance is important - if too small the valve won't close fully and will burn out, whereas if too large noisy operation will result.

**Valve lift** The amount a valve is lifted off its seat by the camshaft lobe.

**Valve timing** The exact setting for the opening and closing of the valves in relation to piston position.

**Vernier caliper** A precision measuring instrument that measures inside and outside dimensions. Not quite as accurate as a micrometer, but more convenient.

**VIN** Vehicle Identification Number. Term for the bike's engine and frame numbers.

**Viscosity** The thickness of a liquid or its resistance to flow.

**Volt** A unit for expressing electrical "pressure" in a circuit. Volts = current x ohms.

## W

**Water pump** A mechanically-driven device for moving coolant around the engine.

**Watt** A unit for expressing electrical power. Watts = volts x current.

**Wear limit** see **Service limit**

**Wet liner** A liquid-cooled engine design where the pistons run in liners which are directly surrounded by coolant (see illustration).



Wet liner arrangement

**Wheelbase** Distance from the centre of the front wheel to the centre of the rear wheel.

**Wiring harness or loom** Describes the electrical wires running the length of the motorcycle and enclosed in tape or plastic sheathing. Wiring coming off the main harness is usually referred to as a sub harness.

**Woodruff key** A key of semi-circular or square section used to locate a gear to a shaft. Often used to locate the alternator rotor on the crankshaft.

**Wrist pin** Another name for gudgeon or piston pin.

# REF•44 VFR400Z and VFR400R (NC21, NC24) specifications

## Valves, guides and springs

### Valve clearances (COLD engine)

|                |                 |
|----------------|-----------------|
| Inlet valves   | 0.11 to 0.15 mm |
| Exhaust valves | 0.18 to 0.22 mm |

### Inlet valve

#### Stem diameter

##### VFR400 RG and ZG

|                     |                   |
|---------------------|-------------------|
| Standard            | 4.975 to 4.990 mm |
| Service limit (min) | 4.97 mm           |

##### VFR400 RH, RJ and ZH

|                     |                   |
|---------------------|-------------------|
| Standard            | 4.475 to 4.490 mm |
| Service limit (min) | 4.46 mm           |

#### Guide bore diameter

##### VFR400 RG and ZG

|                     |                   |
|---------------------|-------------------|
| Standard            | 5.000 to 5.012 mm |
| Service limit (max) | 5.04 mm           |

##### VFR400 RH, RJ and ZH

|                     |                   |
|---------------------|-------------------|
| Standard            | 4.500 to 4.512 mm |
| Service limit (max) | 4.54 mm           |

#### Stem-to-guide clearance

|                     |                   |
|---------------------|-------------------|
| Standard            | 0.010 to 0.037 mm |
| Service limit (max) | 0.07 mm           |

#### Seat width

|          |                 |
|----------|-----------------|
| Standard | 1.70 to 2.30 mm |
|----------|-----------------|

#### Valve guide height above cylinder head

|          |         |
|----------|---------|
| Standard | 10.0 mm |
|----------|---------|

### Exhaust valve

#### Stem diameter

##### VFR400 RG and ZG

|                     |                   |
|---------------------|-------------------|
| Standard            | 4.955 to 4.970 mm |
| Service limit (min) | 4.94 mm           |

##### VFR400 RH, RJ and ZH

|                     |                   |
|---------------------|-------------------|
| Standard            | 4.455 to 4.470 mm |
| Service limit (min) | 4.44 mm           |

#### Guide bore diameter

##### VFR400 RG and ZG

|                     |                   |
|---------------------|-------------------|
| Standard            | 5.000 to 5.012 mm |
| Service limit (max) | 5.04 mm           |

##### VFR400 RH, RJ and ZH

|                     |                   |
|---------------------|-------------------|
| Standard            | 4.500 to 4.512 mm |
| Service limit (max) | 4.54 mm           |

#### Stem-to-guide clearance

|                     |                   |
|---------------------|-------------------|
| Standard            | 0.030 to 0.057 mm |
| Service limit (max) | 0.10 mm           |

### Valve springs free length (inlet and exhaust)

#### VFR400 RG and ZG

##### Inner spring

|                     |          |
|---------------------|----------|
| Standard            | 29.84 mm |
| Service limit (min) | 28.50 mm |

##### Outer spring

|                     |          |
|---------------------|----------|
| Standard            | 32.89 mm |
| Service limit (min) | 31.60 mm |

#### VFR400 RH, RJ and ZH

##### Inner spring

|                     |                   |
|---------------------|-------------------|
| Standard            | 29.28 or 28.89 mm |
| Service limit (min) | 28.80 or 28.60 mm |

##### Outer spring

|                     |                   |
|---------------------|-------------------|
| Standard            | 31.90 or 32.08 mm |
| Service limit (min) | 30.60 or 30.80 mm |

## Clutch

### Friction plate thickness

|                     |                |
|---------------------|----------------|
| Standard            | 2.90 to 3.0 mm |
| Service limit (min) | 2.7 mm         |

### Plain plate warpage (max)

|          |        |
|----------|--------|
| Standard | 0.3 mm |
|----------|--------|

### Spring free height

#### VFR400 RG and ZG

|                     |         |
|---------------------|---------|
| Standard            | 41.2 mm |
| Service limit (min) | 40 mm   |

#### VFR400 RH, RJ and ZH

|                     |         |
|---------------------|---------|
| Standard            | 37.6 mm |
| Service limit (min) | 36.5 mm |

# REF•46 VFR400Z and VFR400R (NC21, NC24) specifications

## Pistons

|                                                                             |                     |
|-----------------------------------------------------------------------------|---------------------|
| Piston diameter (measured 10.0 mm up from skirt, at 90° to piston pin axis) |                     |
| Standard                                                                    | 54.960 to 54.990 mm |
| Service limit (min)                                                         | 54.85 mm            |
| Piston-to-bore clearance                                                    |                     |
| Standard                                                                    | 0.010 to 0.055 mm   |
| Service limit (max)                                                         | 0.10 mm             |
| Piston pin diameter                                                         |                     |
| Standard                                                                    | 13.994 to 14.000 mm |
| Service limit (min)                                                         | 13.98 mm            |
| Piston pin bore diameter in piston                                          |                     |
| Standard                                                                    | 14.002 to 14.008 mm |
| Service limit (max)                                                         | 14.06 mm            |
| Piston pin-to-piston pin bore clearance                                     |                     |
| Standard                                                                    | 0.002 to 0.014 mm   |
| Service limit (max)                                                         | 0.04 mm             |

## Piston rings

|                          |                              |
|--------------------------|------------------------------|
| Ring end gap (installed) |                              |
| Top ring                 |                              |
| Standard                 | 0.18 to 0.33 mm              |
| Service limit (max)      | 0.5 mm                       |
| 2nd ring                 |                              |
| Standard                 | 0.18 to 0.33 mm              |
| Service limit (max)      | 0.5 mm                       |
| Oil ring side-rail       |                              |
| Standard                 | 0.20 to 0.70 mm              |
| Service limit (max)      | 0.90 mm                      |
| Ring-to-groove clearance |                              |
| Top ring                 |                              |
| Standard                 | 0.015 to 0.050 mm            |
| Service limit (max)      | 0.10 mm                      |
| 2nd ring                 |                              |
| Standard                 | 0.015 to 0.050 mm            |
| Service limit (max)      | 0.10 mm                      |
| Ring identification      |                              |
| Top ring                 | "R" (facing up)              |
| 2nd ring                 | "•" mark or "RN" (facing up) |

## Crankshaft and bearings

|                            |                   |
|----------------------------|-------------------|
| Main bearing oil clearance |                   |
| Standard                   | 0.025 to 0.049 mm |
| Service limit (max)        | 0.07 mm           |
| Runout (max)               |                   |
|                            | 0.03 mm           |

## Transmission

|                                                      |                     |
|------------------------------------------------------|---------------------|
| Gear ratios (no. of teeth)                           |                     |
| Primary reduction                                    | 2.117 to 1          |
| Final reduction                                      | 3.000 to 1          |
| 1st gear                                             | 3.307 to 1          |
| 2nd gear                                             | 2.352 to 1          |
| 3rd gear                                             | 1.850 to 1          |
| 4th gear                                             | 1.545 to 1          |
| 5th gear                                             | 1.333 to 1          |
| 6th gear                                             |                     |
| VFR400 RG and ZG                                     | 1.192 to 1          |
| VFR400 RH, RJ and ZH                                 | 1.227 to 1          |
| Input shaft 5th and 6th gears ID                     |                     |
| Standard                                             | 25.000 to 25.021 mm |
| Service limit (max)                                  | 25.05 mm            |
| Input shaft 5th and 6th gears bush OD                |                     |
| Standard                                             | 24.959 to 24.980 mm |
| Service limit (min)                                  | 24.92 mm            |
| Input shaft 5th and 6th gears gear-to-bush clearance |                     |
| Standard                                             | 0.020 to 0.062 mm   |
| Service limit (max)                                  | 0.10 mm             |
| Input shaft 5th gear bush ID                         |                     |
| Standard                                             | 21.985 to 22.006 mm |
| Service limit (max)                                  | 22.02 mm            |

## REF•48 VFR400Z and VFR400R (NC21, NC24) specifications

### Fuel and exhaust systems

#### Fuel

|                                              |                                                   |
|----------------------------------------------|---------------------------------------------------|
| Grade .....                                  | Unleaded, minimum 91 RON (Research Octane Number) |
| Fuel tank capacity (including reserve) ..... | 16.0 litres                                       |

#### Carburettors

|                                       |                |
|---------------------------------------|----------------|
| Type .....                            | CV             |
| Pilot screw setting (turns out) ..... | 2 turns out    |
| Float height .....                    | 6.8 mm         |
| Engine idle speed .....               | 1300 ± 100 rpm |
| Throttle cable freeplay .....         | 2 to 6 mm      |

#### Carburettor jet sizes

|                                   |     |
|-----------------------------------|-----|
| Pilot jet .....                   | 35  |
| Main jet .....                    |     |
| Front cylinder carburettors ..... | 112 |
| Rear cylinder carburettors .....  | 110 |

### Ignition system

#### General

|                    |         |
|--------------------|---------|
| Firing order ..... | 1-3-2-4 |
|--------------------|---------|

#### Spark plugs

|                                      |                                  |
|--------------------------------------|----------------------------------|
| Type .....                           |                                  |
| Standard .....                       | NGK C8EH-9 or Nippondenso U24FE9 |
| For extended high speed riding ..... | NGK C9EH-9 or Nippondenso U27FE9 |
| For cold climate (below 5°C) .....   | NGK C7EH-9 or Nippondenso U22FE9 |
| Electrode gap .....                  | 0.8 to 0.9 mm                    |

#### Ignition timing

|                            |          |
|----------------------------|----------|
| At idle .....              |          |
| VFR400 RG and ZG .....     | 15° BTDC |
| VFR400 RH, RJ and ZH ..... | 18° BTDC |
| Full advance .....         | 37° BTDC |

#### Pulse generator coils

|                            |                 |
|----------------------------|-----------------|
| Resistance .....           |                 |
| VFR400 RG and ZG .....     | 350 to 430 ohms |
| VFR400 RH, RJ and ZH ..... | 400 to 500 ohms |

#### Ignition HT coils

|                                    |                     |
|------------------------------------|---------------------|
| Primary winding resistance .....   |                     |
| VFR400 RG and ZG .....             | 2.6 to 3.2 ohms     |
| VFR400 RH, RJ and ZH .....         | 2.0 to 4.0 ohms     |
| Secondary winding resistance ..... |                     |
| VFR400 RG and ZG .....             |                     |
| with plug cap .....                | 15.0 to 20.6 K ohms |
| without plug cap .....             | 11.7 to 14.3 K ohms |
| VFR400 RH, RJ and ZH .....         |                     |
| with plug cap .....                | 15.0 to 21.0 K ohms |
| without plug cap .....             | 11.0 to 15.0 K ohms |

## REF•50 VFR400Z and VFR400R (NC21, NC24) specifications

### Brakes (continued)

|                                                  |                     |
|--------------------------------------------------|---------------------|
| Rear calliper piston OD                          |                     |
| VFR400 RG and ZG                                 |                     |
| Standard                                         | 26.918 to 26.968 mm |
| Service limit (min)                              | 26.910 mm           |
| VFR400 RH, RJ and ZH                             |                     |
| Standard                                         | 38.115 to 38.148 mm |
| Service limit (min)                              | 38.105 mm           |
| Rear disc minimum thickness                      |                     |
| Standard                                         | 4.8 to 5.2 mm       |
| Service limit (min)                              | 4.0 mm              |
| Disc maximum runout (front and rear, all models) |                     |
|                                                  | 0.3 mm              |
| Rear master cylinder bore ID                     |                     |
| VFR400 RG and ZG                                 |                     |
| Standard                                         | 12.700 to 12.743 mm |
| Service limit (max)                              | 12.755 mm           |
| VFR400 RH, RJ and ZH                             |                     |
| Standard                                         | 14.000 to 14.043 mm |
| Service limit (max)                              | 14.055 mm           |
| Rear master cylinder piston OD                   |                     |
| VFR400RG and ZG                                  |                     |
| Standard                                         | 12.657 to 12.684 mm |
| Service limit (min)                              | 12.645 mm           |
| VFR400RH, RJ and ZH                              |                     |
| Standard                                         | 13.957 to 13.984 mm |
| Service limit (min)                              | 13.945 mm           |

### Wheels

|                                       |         |
|---------------------------------------|---------|
| Maximum wheel runout (front and rear) |         |
| Axial (side-to-side)                  | 2.0 mm  |
| Radial (out-of-round)                 | 2.0 mm  |
| Maximum axle runout (front and rear)  | 0.20 mm |

### Tyres

|                       |                                   |                                  |
|-----------------------|-----------------------------------|----------------------------------|
| Tyre pressures (cold) |                                   |                                  |
| Rider only            | <b>Front</b><br>32 psi (2.20 Bar) | <b>Rear</b><br>36 psi (2.50 Bar) |
| Rider and passenger   | 32 psi (2.20 Bar)                 | 40 psi (2.75 Bar)                |
| Tyre sizes*           |                                   |                                  |
| Front                 | 100/90-16 54H                     |                                  |
| Rear                  | 130/70-18 63H                     |                                  |

\*Refer to the owners handbook or the tyre information label on the swingarm for approved tyre brands.

## Electrical system

### Battery

|                 |                       |
|-----------------|-----------------------|
| Capacity        | 12 V, 9 Ah            |
| Voltage         |                       |
| Fully charged   | 13.0 V                |
| Uncharged       | Below 12.0 V          |
| Charging rate   |                       |
| Normal          | 0.9 A for 5 to 10 hrs |
| Quick           | 3.0 A for 1hr         |
| Current leakage | 1 mA (max)            |

### Alternator

|                        |                   |
|------------------------|-------------------|
| Power output           |                   |
| VFR400 RG and ZG       | 270 W @ 5000 rpm  |
| VFR400 RH, RJ and ZH   | 350 W @ 5000 rpm  |
| Stator coil resistance |                   |
| VFR400 RG and ZG       | 0.28 to 0.65 ohms |
| VFR400 RH, RJ and ZH   | 0.30 to 0.45 ohms |

### Regulator/rectifier

|                          |                |
|--------------------------|----------------|
| Regulated voltage output | 14.1 to 15.1 V |
|--------------------------|----------------|

### Starter motor

|                     |                 |
|---------------------|-----------------|
| Brush length        |                 |
| Standard            | 12.0 to 13.0 mm |
| Service limit (min) | 6.5 mm          |

### Fuses

|        |                    |
|--------|--------------------|
| Main   | 30 A               |
| Others | 10 A x 6, 15 A x 1 |

**Note:** References throughout this index relate to Chapter•page number

## A

**Air filter and housing** - 1•18, 4•4  
**Alternator** - 9•23  
**Antifreeze** - 0•13, 1•2, 1•21, REF•48

## B

**Battery** - 1•12, 9•3, 9•4  
     open-circuit voltage - REF•36  
     specific gravity - REF•36  
**Bearings** - REF•14  
     engine - 2•45, 2•51  
     steering head - 1•16, 1•23, 6•19  
     transmission - 2•53  
     wheel - 1•22, 7•21  
**Bleeding the brakes** - 7•14  
**Bodywork** - 8•1 *et seq*  
**Bolt tightness** - 1•18  
**Brakes** - 7•1 *et seq*  
     bleeding - 7•14  
     calipers - 1•23, 7•4, 7•10  
     check - 1•14  
     discs - 7•6, 7•12  
     fluid - 0•12, 1•2, 1•19, REF•50  
     hoses - 1•23, 7•14  
     light bulb - 9•7  
     light switches - 9•9  
     master cylinder - 7•6, 7•12  
     pads - 1•7, 7•3, 7•9  
     pedal - 6•3  
     problems - REF•34  
**Bulbs** - 9•6, 9•7, 9•8, 9•14

## C

**Cable lubrication** - 1•10  
**Calipers** - 1•23, 7•4, 7•10  
**Camshafts** - 2•13  
     drive gear assemblies - 2•18  
**Capacities** - 1•2, REF•45, REF•48

**Carburettor** - 4•4, 4•5, 4•6, 4•9, 4•11  
     synchronisation - 1•13  
**Chains** - REF•18  
**Charging system**  
     leakage and output test - 9•23  
     testing - 9•23  
**Choke cable** - 1•12, 4•15  
**Clutch** - 2•1 *et seq*  
     cable - 2•33  
     check and adjustment - 1•8  
     problems - REF•31  
     removal, inspection and installation - 2•28  
     switch - 9•17  
**Components locations** - 1•4, 1•5  
**Connecting rods and bearings** - 2•45  
**Continuity** - REF•37  
**Conversion factors** - REF•20  
**Coolant** - 0•13, 1•2, 1•21, REF•48  
     hoses - 3•7  
     pump - 3•6  
     reservoir - 3•2  
     temperature gauge and sender - 3•3  
**Cooling fan and switch** - 3•2  
**Cooling system** - 3•1 *et seq*  
     check - 1•14  
     draining, flushing and refilling - 1•21  
**Crankcase halves** - 2•42, 2•44  
**Crankshaft and main bearings** - 2•51  
**Cylinder bores** - 2•44  
**Cylinder compression** - 1•22  
**Cylinder heads** - 2•19, 2•21

## D

**Daily (pre-ride) checks** - 0•11 *et seq*  
**Dimensions** - REF•1  
**Diode** - 9•17  
**Discs** - 7•6, 7•12  
**Draining the cooling system** - 1•21  
**Drive chain** - 0•13, 1•6, 6•26  
**Driveline noise** - REF•32

## O

**Oil, engine/transmission** - 0•11, 1•2, 1•10, REF•45  
**Oil cooler and pipes** - 2•11  
**Oil filter** - 1•10  
**Oil pressure**  
 check - 1•22  
 relief valve - 2•34  
 switch - 9•14  
 warning light comes on - REF•33  
**Oil pump** - 2•35  
**Oil seals** - REF•16  
**Oil strainer** - 2•34  
**Oil sump** - 2•34  
**Overheating** - REF•31

## P

**Pads** - 1•7, 7•3, 7•9  
**Pistons** - 2•48  
 rings - 2•50  
**Poor engine running** - REF•29, REF•30  
**Poor handling or stability** - REF•34  
**Pressure**  
 cylinder compression - 1•22  
 oil - 1•22  
 tyre - 0•14  
**Pulse generator coil assembly** - 5•4

## R

**Radiator** - 3•5  
 pressure cap - 3•2  
**Rear view mirrors** - 8•3  
**Rear wheel and hub assembly** - 7•17  
**Reference** - REF•1 *et seq*  
**Refilling the cooling system** - 1•21  
**Regulator/rectifier** - 9•25  
**Rings, piston** - 2•50  
**Rocker arms and shafts** - 2•17  
**Routine maintenance and servicing** - 1•1 *et seq*  
**Running-in procedure** - 2•62

## S

**Safety checks** - 0•11  
**Safety first** - 0•10  
**Sealants** - REF•17  
**Seals** - 1•23  
**Seat cowling** - 8•2  
**Selector drum and forks** - 2•60  
**Servicing** see *Routine maintenance*  
**Shock absorber and linkage** - 6•20  
**Short-circuit** - REF•38  
**Sidelight bulb** - 9•6  
**Sidestand** - 1•15, 6•4  
 switch - 9•16  
**Spare parts** - 0•9  
**Spark plugs** - 1•13  
 gaps - 1•8  
**Speedometer cable** - 9•10  
**Sprockets** - 6•26

**Stand lubrication** - 1•10  
**Starter clutch and primary drive gear** - 2•24  
**Starter motor** - 9•19  
**Starter relay** - 9•18  
**Starting problems** - REF•28  
**Steering** - 0•13  
 head bearings - 1•16, 1•23, 6•19  
 stem - 6•18  
**Storage** - REF•25  
**Suspension** - 6•1 *et seq*  
 adjustment - 6•22  
 check - 0•13, 1•15  
 noise - REF•33  
**Suspension linkage, rear** - 1•23, 6•20  
**Swingarm** - 1•23, 6•23, 6•25  
**Switches** - 9•9, 9•14, 9•15, 9•16, 9•17

## T

**Tail light**  
 assembly - 9•8  
 bulb - 9•7  
**Technical terms explained** - REF•39  
**Thermostat and housing** - 3•4  
**Throttle cable** - 1•12, 4•13  
**Tools** - REF•2  
**Torque** - REF•13  
**Transmission** - 2•1 *et seq*  
 bearings - 2•53  
 oil - 0•11, 1•2, 1•10, REF•45  
 shafts - 2•53, 2•55  
**Turn signal**  
 assemblies - 9•9  
 bulbs - 9•8  
 circuit - 9•8  
**Tyres** - 7•1 *et seq*  
 check - 1•18  
 fitting - 7•22  
 pressure - 0•14

## V

**Valves**  
 clearances - 1•19  
 covers - 2•12  
 seats and guides - 2•20, 2•21  
**Voltage regulator** - 9•25

## W

**Warning light bulbs** - 9•14  
**Water pump** - 3•6  
**Weights** - REF•1  
**Wheels** - 7•1 *et seq*  
 alignment check - 7•15  
 bearings - 1•22, 7•21  
 check - 1•18  
 inspection and repair - 7•15  
 removal - 7•15, 7•17  
**Wiring diagrams** - 9•27, 9•28  
**Workshop tips** - REF•4

## Preserving Our Motoring Heritage



< The Model J Duesenberg Derham Tourster. Only eight of these magnificent cars were ever built – this is the only example to be found outside the United States of America

Almost every car you've ever loved, loathed or desired is gathered under one roof at the Haynes Motor Museum. Over 300 immaculately presented cars and motorbikes represent every aspect of our motoring heritage, from elegant reminders of bygone days, such as the superb Model J Duesenberg to curiosities like the bug-eyed BMW Isetta. There are also many old friends and flames. Perhaps you remember the 1959 Ford Popular that you did your courting in? The magnificent 'Red Collection' is a spectacle of classic sports cars including AC, Alfa Romeo, Austin Healey, Ferrari, Lamborghini, Maserati, MG, Riley, Porsche and Triumph.

### A Perfect Day Out

Each and every vehicle at the Haynes Motor Museum has played its part in the history and culture of Motoring. Today, they make a wonderful spectacle and a great day out for all the family. Bring the kids, bring Mum and Dad, but above all bring your camera to capture those golden memories for ever. You will also find an impressive array of motoring memorabilia, a comfortable 70 seat video cinema and one of the most extensive transport book shops in Britain. The Pit Stop Cafe serves everything from a cup of tea to wholesome, home-made meals or, if you prefer, you can enjoy the large picnic area nestled in the beautiful rural surroundings of Somerset.



> John Haynes O.B.E., Founder and Chairman of the museum at the wheel of a Haynes Light 12.



< The 1936 490cc sohc-engined International Norton – well known for its racing success



The Museum is situated on the A359 Yeovil to Frome road at Sparkford, just off the A303 in Somerset. It is about 40 miles south of Bristol, and 25 minutes drive from the M5 intersection at Taunton.

Open 9.30am - 5.30pm (10.00am - 4.00pm Winter) 7 days a week, except Christmas Day, Boxing Day and New Years Day  
Special rates available for schools, coach parties and outings Charitable Trust No. 292048

## Honda VFR and RVF models covered by this manual:

|                |       |            |
|----------------|-------|------------|
| VFR400R (NC30) | 399cc | '89 to '98 |
| RVF400R (NC35) | 399cc | '94 to '98 |

*Note: This manual also contains specifications for the VFR400 NC21 and NC24 models – procedures are not included for these models.*



Whether carrying out a routine service or rebuilding the engine, Haynes **SHOWS YOU HOW** and **SAVES YOU MONEY**.

### Step-by-step instructions

clearly linked to hundreds of photos and illustrations guide you through each job.

**Spanner ratings** grade all tasks by experience level – from simple servicing jobs for beginners through to more difficult tasks for the expert.

### Haynes Hints and Tool Tips

give you valuable 'inside' information such as ways of removing parts without using special tools.


100 6000 Miles/12,000 km or 12 months



## Inside this Manual

- ◆ **Model history** and **Pre-ride Checks** in colour.
- ◆ A complete step-by-step guide to **servicing** and **routine maintenance**.
- ◆ **Engine** and **transmission** – servicing and overhaul.
- ◆ **Fuel** and **ignition systems** explained.
- ◆ **Suspension and steering** – adjustment and overhaul.
- ◆ **Cooling system** – checks and remedies.
- ◆ **Braking system** – safety checks and repairs.
- ◆ **Electrical system** – fault finding and repairs.
- ◆ Comprehensive **colour wiring diagrams**.
- ◆ 18 page **Tools & Workshop Tips** section in **colour**.
- ◆ **Fault finding** checklist and equipment to pinpoint specific problems.
- ◆ **Fully indexed** to help you find information easily.

ISBN 1 85960 496 X



9 781859 604960

*"These Manuals are essential reading for any biker tackling his own servicing..."*

Motor Cycle News

*"...I couldn't live without my Haynes..."*

Superbike

Haynes Publishing, Sparkford, Yeovil, Somerset BA22 7JJ England. [www.haynes.co.uk](http://www.haynes.co.uk)

UPC CODE



0 38345 03496 1

ABCODE@UK