



JIANSHE MOTORCYCLE MODEL JS125-6B

# MAINTENANCE MANUAL



JIANSHE INDUSTRIES CO.,LTD.(GROUP)



# MAINTENANCE MANUAL

## NOTICE

This manual was produced by the chongqing Jianshe motorcycle co., Ltd primarily for use by Jianshe Group dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on JS125-6B motorcycle has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and until for use.

Chongqing Jianshe Industries(Group)Co., Ltd is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Jianshe Group dealers and will appear in future editions of this manual where applicable.

## IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.

The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander or a person inspecting or repairing the machine.

A CAUTION indicates special precautions that must be taken to avoid damage to the machine.


A NOTE provides key information to make procedures easier or clearer.

### **Maintenance manual of four-wheeled cross-country vehicle model JS125-6B**

**First edition July 2007**

This manual is published by Jianshe Industries Co., Ltd (Group) publishing factory. Jianshe Industries Co., Ltd (Group) maintains the copyright of publishing. Without permitted, publishing is prohibited.

## ILLUSTRATED SYMBOLS

|                                                                                          |                                                                                          |                                                                                         |
|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| 1<br>   | 2<br>   | 3<br>  |
| 4<br>   | 5<br>   | 6<br>  |
| 7<br>   | 8<br>   | 9<br>  |
| 10<br>  | 11<br>  | 12<br> |
| 13<br> | 14<br> |                                                                                         |

- 1 Special tool
- 2 Tighten
- 3 Filling electrolyte
- 4 Wear limit, clearance
- 5 Engine speed
- 6 Tester
- 7 Apply engine oil
- 8 Apply gear oil
- 9 Apply molybdenum disulfide oil
- 10 Apply wheel bearing grease
- 11 Apply lightweight lithium-soap base grease
- 12 Apply molybdenum disulfide grease
- 13 Apply fluid locking agent
- 14 Install a new part

## COLOR INDICATIONS

| Abbreviation | Full name  | Abbreviation | Full name    |
|--------------|------------|--------------|--------------|
| B            | Black      | B/W          | Black/white  |
| Br           | Brown      | B/R          | Black/red    |
| Ch           | Dark brown | Br/W         | Brown/white  |
| Dg           | Dark green | G/W          | Green/white  |
| G            | Green      | G/Y          | Green/yellow |
| L            | Blue       | W/L          | White/blue   |
| Or           | Orange     | W/R          | White/red    |
| Sb           | Light blue | B/Y          | Black/yellow |
| P            | Pink       | L/W          | Blue/white   |
| R            | Red        | L/B          | Blue/black   |
| Y            | Yellow     | R/W          | Red/white    |
| W            | White      |              |              |

# CONTENT

## CHAPTER 1 GENERAL INFORMATION

|                                 |   |
|---------------------------------|---|
| Motorcycle identification ..... | 2 |
| Important Information .....     | 3 |
| Special tools .....             | 6 |

## CHAPTER 2 SPECIFICATIONS

|                                                |    |
|------------------------------------------------|----|
| General specifications .....                   | 10 |
| Check the Specification .....                  | 13 |
| Lock torque .....                              | 18 |
| Lubrication point and type of lubricants ..... | 21 |
| Engine lubrication flow .....                  | 23 |

## CHAPTER 3 PERIODIC INSPECTION AND ADJUSTMENT

|                                                                          |    |
|--------------------------------------------------------------------------|----|
| Introduction .....                                                       | 26 |
| Periodic maintenance/lubrication .....                                   | 26 |
| Disassemble and install the seat cushion, oil tank and cover types ..... | 28 |
| Check and adjust valve clearance .....                                   | 30 |
| Adjust idle speed .....                                                  | 32 |
| Check/adjust the free play of the throttle cable .....                   | 33 |
| Check the spark plug .....                                               | 34 |
| Inspect compression pressure .....                                       | 35 |
| Check engine oil .....                                                   | 36 |
| Replace engine oil .....                                                 | 37 |

|                                        |    |
|----------------------------------------|----|
| Adjust clutch .....                    | 38 |
| Clean the air cleaner .....            | 39 |
| Adjust front brake .....               | 40 |
| Check front brake shoes .....          | 41 |
| Check front brake (disk) .....         | 42 |
| Check brake lining .....               | 42 |
| Check the amount of brake fluid .....  | 42 |
| Exhaust .....                          | 43 |
| Replace brake fluid .....              | 44 |
| Check and adjust the rear brake .....  | 45 |
| Check the rear brake shoes .....       | 45 |
| Check the rear brake switch .....      | 45 |
| Check and adjust the drive chain ..... | 46 |
| Check front fork .....                 | 47 |
| Adjust rear shock absorber .....       | 47 |
| Check Tire .....                       | 48 |
| Check steering device .....            | 49 |
| Check battery .....                    | 50 |

## CHAPTER 4 ENGINE

|                                              |    |
|----------------------------------------------|----|
| Disassemble the engine .....                 | 54 |
| Ready to disassemble the engine .....        | 54 |
| Disassemble the engine .....                 | 55 |
| Disconnect the engine .....                  | 56 |
| Cylinder head, cylinder and piston .....     | 56 |
| Left crankcase cover and starter motor ..... | 58 |
| Clutch and oil pump .....                    | 59 |

|                                                                     |    |
|---------------------------------------------------------------------|----|
| Oil pump .....                                                      | 61 |
| Starting shaft and idle gear .....                                  | 61 |
| Shift shaft .....                                                   | 62 |
| Rotor .....                                                         | 62 |
| Crankcase .....                                                     | 63 |
| Balancing device, transmission and shifting rod .....               | 63 |
| Crankshaft and counterbalance .....                                 | 64 |
| Rocker arm and camshaft .....                                       | 64 |
| Valve .....                                                         | 65 |
| Check and repair .....                                              | 66 |
| Cylinder head .....                                                 | 66 |
| Valve seat .....                                                    | 67 |
| Valve and valve guide .....                                         | 69 |
| Valve spring .....                                                  | 70 |
| Camshaft .....                                                      | 70 |
| Rocker arm and rocker arm shaft .....                               | 71 |
| Timing chain, sprocket, chain guide plate and chain tensioner ..... | 72 |
| Cylinder and piston .....                                           | 73 |
| Piston pin .....                                                    | 74 |
| Piston ring .....                                                   | 75 |
| Crankshaft .....                                                    | 76 |
| Balancing device .....                                              | 77 |
| Cultch .....                                                        | 77 |
| Transmission and shift lever .....                                  | 79 |
| Kick starter .....                                                  | 80 |
| Oil pump and oil filter .....                                       | 81 |
| Crankcase .....                                                     | 82 |

|                                                                 |     |
|-----------------------------------------------------------------|-----|
| Bearing and oil seal .....                                      | 82  |
| Circlip and washer .....                                        | 82  |
| Engine assembly and adjustment .....                            | 83  |
| Valve, rocker arm and cam shaft .....                           | 83  |
| Crankshaft and balance device .....                             | 86  |
| Transmission .....                                              | 88  |
| Gear shift cam and fork .....                                   | 89  |
| Crankcase .....                                                 | 92  |
| Shift shaft, kick starter axle and kick starter idle gear ..... | 94  |
| Clutch, oil pump .....                                          | 97  |
| Timing system .....                                             | 102 |
| Cylinder and piston .....                                       | 106 |
| Cylinder head .....                                             | 107 |
| Cam shaft and dowel pin .....                                   | 108 |
| Intake and exhaust system .....                                 | 109 |
| Carburetor .....                                                | 109 |
| Intake, exhaust system .....                                    | 114 |

## CHAPTER 5 CHASSIS

|                                        |     |
|----------------------------------------|-----|
| Front wheel .....                      | 116 |
| Front brake .....                      | 117 |
| Rear wheel .....                       | 124 |
| Rear brake .....                       | 125 |
| Driving chain .....                    | 128 |
| Front fork .....                       | 132 |
| Steering seat and handlebar .....      | 139 |
| Rear shock absorber and rear arm ..... | 146 |

## CHAPTER 6 CABLE AND ELECTRIC APPLIANCE SYSTEM

|                                        |     |
|----------------------------------------|-----|
| Cable /harness wire/tube diagram ..... | 150 |
| Electric device principle .....        | 158 |
| Electric appliance .....               | 159 |
| Components of electric appliance ..... | 161 |
| Ignition system diagram .....          | 165 |
| Starting motor .....                   | 174 |
| Charging system .....                  | 178 |
| Lighting system .....                  | 181 |
| Signal system .....                    | 186 |

## CHAPTER 7 TROUBLESHOOTING

|                                 |     |
|---------------------------------|-----|
| Electric Appliance System ..... | 196 |
| Compression System .....        | 197 |
| Intake \Exhaust System .....    | 198 |




# **CHAPTER 1**

## **GENERAL INFORMATION**

## Motorcycle identification


### Frame identification

The number is stamped on the front tube of frame.  
The frame number is made up of 3 parts, the first part (3 ones) is the code of manufacturer(WMI); The second part (6 ones) is the direction code of motorcycle (VDS) the third part (8 ones) is the inspecting position. (VIS).



### Engine Ser. No

The No.s of engines stamped on the crankcase.



Engine No.

JS154FMI/JYM154FMI ※ 00000001 ※

#### Note

There will be no further notice if the design or rule is changed.

## Important Information

### Important information to ensure safe and high active work


#### (1)Motorcycle wash

Clear out the frame and engine to prevent the entry of dust



#### (2)No smoking

Keep out fire from replacement position .



#### (3)Choose right tools

- Use only the appropriate special tools will help prevent damage caused by the use of inappropriate tools or improvised techniques.
- Use appropriate tools and metro logic instrument for replacement.
- Use double offset ring spanner and socket key instead of non-adjustable wrench.


#### (4)Use authentic replacement parts

- Use only genuine Jianshe Group parts for all re - placements. Use oil and grease recommended by Jianshe Group for all lubrication jobs. Do not use Other Brands' re-placement parts.

#### (5)Wearing parts must usually replaced (marked with

**NEW** )

- Replace all gaskets, oil seals , cotter pin ,circlip and O-rings.






#### (6) Safe operation

- Be careful in operation to avoid accident or get a burn by the engine, exhaust pipe and silencer..
- Always think of the right tools, right ways, right fixture and the right position to ensure body's steady.




#### (7) The operation should be broken down in order and the taken apart parts should be sort out in time.

- Unscrew: from offside to inside on a cross by 2 or 3 times.
- Check and measure the important parts while breaking down, and keep the records for reference. The disassemble parts should be put in order to prevent mix and loss.
- The parts of the engine transmission must be cleaned by oil and dried by compressed air after knocked down.




#### (8) Defer to each part to confirm while assembling. Screw down: from inside to offside on a cross by 2 or 3 times.

- Defer to each part's correct results and the data before broken down during the operation.
- Do not let dust sticks on various components in assembly
- Smear motor oil on rotary and sliding parts (smear grease on oil seal and O-rings). Make sure to follow the screw moment method.
- Two persons should cooperation perfectly when work in with each other.




#### (9) Maintenance manual and parts catalog is necessary

- Maintenance manual and parts catalog is necessary. For efficiently, reliable and safe operation.




### Gaskets Oil seal and O-rings

1. Replace all gaskets, oil seals and O-rings when overhauling the engine. All gasket surfaces, oil seal lips and o-rings surface must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.




### Lock washer/plates and cotter pins

1. Replace all lock washer/plates and cotter pins after removal. Bend lock tabs along the bolt or nut flats after the bolt or nut has been tightened to specification.



### Bearings and oil seals

Install bearings and oil seals so that the manufactures marks of numbers are visible. When in-stalling oil seals, apply a light coating of lightweight lithium base grease to the seal lips. Oil bearings liberally when installing, if appropriate.



### Circlips


Check all circlips carefully before reassembly. Always replace piston pinclips after one use. Replace distorted circlips, when installing a circlip make sure that the sharp edged corner is positioned opposite the thrust it receives view. Shafe.

### Caution

Do not use compressed air to spin the bearings dry. This will damage the bearing surfaces.

## Special tools

The proper special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools will help prevent damage caused by the use of inappropriate tools or improvised techniques.

| Special tools name                                                                                                                        | Drawing                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Slide hammer bolt①<br>Weight②                                                                                                             |    |
| Crankcase separating tool                                                                                                                 |    |
| Crankshaft installer set ①<br>Crankshaft installer bolt②<br>Joint of different diameter tide ③<br>Spacer ④<br>Crankshaft installer tool ⑤ |    |
| Shock absorber lever yoke<br>Handle<br>Antic kid tool                                                                                     |  |
| Valve adjusting tools                                                                                                                     |  |
| Liquid meter<br>Fuel level gauge                                                                                                          |  |
| Rotor strip down tools<br>Strip down rotor tools                                                                                          |  |
| Front fork gasket press tool<br>Front fork gasket press tool ①<br>Front fork gasket press tool attachment ②                               |  |


| Special tools name              | Drawing                                                                               |
|---------------------------------|---------------------------------------------------------------------------------------|
| Turning and exhaust pipe wrench |    |
| Turning wrench                  |    |
| Magneto rotor holder            |    |
| Clearance ruler                 |    |
| Cylinder compression gauge      |   |
| Pocket tester                   |  |
| Inductive techometer            |  |
| Valve spring compressor         |  |
| Universal clutch holder         |  |
| Ignition checker                |  |



# **CHAPTER 2**

## **SPECIFICATIONS**


## General specifications

| Item                                      | Standard                                                                             |
|-------------------------------------------|--------------------------------------------------------------------------------------|
| Model code:                               | JS125-6B                                                                             |
| Dimensions:                               |                                                                                      |
| Overall length                            | 1980mm                                                                               |
| Overall width                             | 745mm                                                                                |
| Overall height                            | 1050mm                                                                               |
| Seat height                               | 775mm                                                                                |
| Wheelbase                                 | 1290mm                                                                               |
| Minimum ground clearance                  | 160mm                                                                                |
| Minimum turning radius                    | 1750mm                                                                               |
| Basic weight: With oil and full fuel tank | 117kg                                                                                |
| Engine:                                   |                                                                                      |
| Engine type                               | Air-cooled 4-stroke, SOHC                                                            |
| Cylinder arrangement                      | Forward-inclined single cylinder                                                     |
| Displacement                              | 123m <sup>3</sup>                                                                    |
| Bore×stroke                               | 54.0×54.0mm                                                                          |
| Compression ratio                         | 10:1                                                                                 |
| Starter                                   | Electric and Kick starter                                                            |
| Lubrication                               | Compress and splash                                                                  |
| Oil                                       |                                                                                      |
| Engine oil capacity                       |  |
| Periodic oil change                       | 1L(1000cm <sup>3</sup> )                                                             |
| Total amount                              | 1.2L(1200cm <sup>3</sup> )                                                           |
| Lubrication system                        | Wet sump                                                                             |
| Oil filter                                |                                                                                      |
| Type                                      | 90#gasoline                                                                          |
| Fuel tank capacity                        | 13L                                                                                  |
| Fuel reserve amount                       | 1.4L                                                                                 |

| Item                                                                                                                                                                                                            | Standard                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Carburetor                                                                                                                                                                                                      | Z20P-1B/VM22SH                                                                                                                                                                                    |
| Spark plug<br>Type<br>Spark plug gap                                                                                                                                                                            | A6RTC/CR6HSA<br>0.6mm~0.7mm                                                                                                                                                                       |
| Clutch<br>Type                                                                                                                                                                                                  | Wet ,multi-piece with handle                                                                                                                                                                      |
| Transmission<br>Primary reduction system<br>Primary reduction ratio<br>Secondary reduction system<br>Secondary reduction ratio<br>Type<br>Gear ratio<br>1 <sup>st</sup><br>2 <sup>nd</sup><br>3rd<br>4th<br>5th | Spur gear<br>68/20(3.400)<br>Chain drive<br>45/14(3.214)<br>Constant mesh 5-speed<br>37/14 (2.643)<br>32/18 (1.778)<br>25/19 (1.316)<br>23/22 (1.045)<br>21/24 (0.875)                            |
| Chassis<br>Frame type<br>King pin front caster angle                                                                                                                                                            | Rhombus<br>26.4°                                                                                                                                                                                  |
| Tire<br>Type<br>Size<br>Front wheel<br>Rear wheel<br>Tyre pressure<br>Single<br>Front tyre pressure<br>Rear tyre pressure<br>Couples<br>Front tyre pressure<br>Rear tyre pressure                               | With tube<br>2.75-18(42P)<br>90/90-(18(51P))<br><br>175kPa(1.75kgf/cm <sup>2</sup> )<br>196kPa(2.0kgf/cm <sup>2</sup> )<br><br>195kPa(2.0kgf/cm <sup>2</sup> )<br>245kPa(2.5kgf/cm <sup>2</sup> ) |
| Brake type (front/rear)                                                                                                                                                                                         | Drum brake .disk/drum brake                                                                                                                                                                       |
| Brake<br>Front brake type<br>Front brake operation<br>Rear brake type<br>Rear brake operation                                                                                                                   | Single-disc hydraulic brake or drum brake<br>Right hand operation<br>Drum brake<br>Right foot operation                                                                                           |

| Item                   | Standard                 |
|------------------------|--------------------------|
| Suspension             |                          |
| Front                  | Telescope tube           |
| Rear                   | Swingarm rear fork       |
| Shock absorber         |                          |
| Front                  | Coil spring / oil damper |
| Rear                   | Coil spring / oil damper |
| Wheel base             | 1290mm                   |
| Electrical             |                          |
| Ignition system        | CDI                      |
| Generator system       | A.C. magneto             |
| Battery type           |                          |
| Battery capacity       | 12V5Ah                   |
| Headlight type         | Bulb type                |
| Bulb power:            |                          |
| Headlight              | 12V35/35w × 1            |
| Tail light/brake light | 12V21W/5/W × 1           |
| Meter light            | 12V3W × 3                |
| Position indicator     | 12V3W                    |
| Neutral indicator      | 12V1.7W × 1              |
| High beam indicator    | 12V1.7W × 2              |
| Turn indicator         | 12V1.7W × 2              |

## Check the Specification

| Item                                                                                                            | Specification                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Limit                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cylinder head:<br>Warp limit                                                                                    | 0.03mm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 0.03mm                                                                                                                                                                                                         |
| Cylinder:<br>Bore size<br>Wear limit                                                                            | 54.060mm-54.075mm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                |
| Cam shaft:<br>Cam dimensions<br>Intake "A"<br>"B"<br>"C"<br>Exhaust "A"<br>"B"<br>"C"<br>Cam shaft runout limit | <br>25.881mm~25.981mm<br>21.194mm~21.294mm<br>5.081mm~4.781mm<br>25.841mm~25.941mm<br>21.097mm~20.097mm<br>5.041mm~4.741                                                                                                                                                                                                                                                                                                                                                     | <br><25.851><br><21.165><br><br><25.817><br><21.027><br><br>0.03mm                                                                                                                                             |
| Cam Chain:<br>Cam chain type<br>Cam chain adjustment method                                                     | DID25/88<br>Automatic                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                |
| Rocker arm /rocker arm shaft:<br>Rocker arm inside diameter<br>Shaft outside diameter<br>Arm to-shaft clearance | 10.000mm~10.015mm<br>9.981mm~9.991mm<br>0.009mm~0.034mm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <10.03mm><br><9.95mm>                                                                                                                                                                                          |
| Valve, valve seat, valve guide:<br>Valve clearance(cold) IN<br>EX<br>Valve dimensions:<br>Intake                | <br>0.08~0.12mm<br>0.10~0.14mm<br><br>   <br>"A" valve head outside diameter IN<br>EX<br>"B" face width IN<br>EX<br>"C" seat width IN<br>EX<br>"D" margin thickness IN<br>EX<br>Stem outside diameter IN<br>EX | <br>0.08~0.12mm<br>0.10~0.14mm<br><br><br>25.9~26.1mm<br>21.9~22.1mm<br>1.4~3.0mm<br>1.3~2.4mm<br>1.2~1.4mm<br>0.9~0.1mm<br>0.4~0.8mm<br>0.8~1.2mm<br>4.975~4.990mm<br>4.960~4.975mm<br><br><4.950><br><4.935> |

| Item                          | Specification    | Limit   |
|-------------------------------|------------------|---------|
| Guide inside diameter         |                  |         |
| IN                            | 5.000~5.012mm    | 5.042mm |
| EX                            | 5.000~5.012mm    | 5.042mm |
| Stem-to-guide clearance       |                  |         |
| IN                            | 0.010~0.037mm    | 0.08mm  |
| EX                            | 0.025~0.052mm    | 0.10mm  |
| Stem runout limit             |                  | 0.01mm  |
| Valve seat width              |                  |         |
| IN                            | 0.2~1.4mm        | 1.6mm   |
| EX                            | 0.56~1.64mm      | 1.6mm   |
| Valve spring                  |                  |         |
| Free length                   | 39.62mm          |         |
| Set length (valve closed)     | 25.6mm           |         |
| Force of compression          | 132~236N         |         |
| Direction of winding          | Clockwise        |         |
| Piston:                       |                  |         |
| Piston clearance              | 0.02~0.034mm     |         |
| Piston size "D"               | 53.997~54.028mm  |         |
| Measuring point "H"           | 4.5mm            |         |
| Piston pin hole inside diar   | 15.002~15.013mm  |         |
| Piston pin outside diameter   | 14.991~15.000mm  |         |
| Piston to cylinder clearence  | 0.002~0.022mm    |         |
| Piston rings:                 |                  |         |
| First ring                    |                  |         |
| Type                          | Drum piston ring |         |
| Size (BT)                     | 1.0×2.1mm        |         |
| Split clearance installed     | 0.15~0.30mm      | 0.4mm   |
| Side clearance (installed)    | 0.035~0.07mm     | 0.12mm  |
| Second ring                   |                  |         |
| Type                          | Flat piston ring |         |
| Size (BT)                     | 1.0×2.1mm        |         |
| Split clearance installed     | 0.30~0.45mm      | 0.55mm  |
| Side clearance (installed)    | 0.02~0.06mm      | 0.12mm  |
| Oil ring                      |                  |         |
| Size (BT)                     | 2.0×2.25         |         |
| Crank shaft:                  |                  |         |
| Crank width "A"               | 46.95~47mm       |         |
| Runout limit "C"              | 0.03mm           | 0.03mm  |
| Big end side clearance "D"    | 0.15~0.45mm      | 0.8mm   |
| Big end side radial clearance | 0.095~0.073mm    |         |
| Balancing device              |                  |         |
| Balancer drive way            | Gear             |         |
| Transmission:                 |                  |         |
| Main axle deflection          |                  | 0.08mm  |
| Drive axle deflection         |                  | 0.08mm  |

| Item                                                                                                                                                                                                                 | Specification                                                                                                         | Limit                      |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------|
| Clutch:<br>Friction plate:<br>Thickness<br>Quantity<br>Clutch plate:<br>Thickness<br>Quantity<br>Clutch spring:<br>Free length<br>Quantity<br>Clutch out                                                             | 2.9~3.0mm<br>4<br>1.55~1.65mm<br>3<br>29.29mm<br>4<br>Cam actuated                                                    | 2.8mm<br>0.05mm<br>31mm    |
| Kick starter<br>Type                                                                                                                                                                                                 | Kick starter and mesh type                                                                                            |                            |
| Carburetor<br>Identification code<br>Main jet<br>Main air jet<br>Jet nozzle<br>Pilot Air jet<br>Pilot mixture outlet<br>Pilot jet<br>Pilot mixture adjustable bolt<br>Oil level<br>Idle speed<br>Suction subpressure | VM22SH<br>#97.5<br>0.9<br>5EJ49-2(L=50.0)<br>1.4<br>1.0<br>#15<br>21.2±3/4<br>7.1±0.05mm<br>1400±100pm<br>31.9±2.7kPa |                            |
| Oil pump type:<br>Tip clearance<br>Side clearance<br>The clearance from magneto rotor to rotor chamber                                                                                                               | Trochoid type<br>0.15mm<br>0.06~0.10mm<br>0.06~0.10mm                                                                 | 0.23mm<br>0.14mm<br>0.14mm |
| Steering system:<br>Steering bearing type                                                                                                                                                                            | Ball bearing                                                                                                          |                            |
| Front suspension:<br>Front fork travel<br>Fork spring free length<br>Fuel capacity<br>Fuel level<br>Fuel degree<br>Inner tube angularity limit                                                                       | 120mm<br>337mm<br>154.5cm <sup>3</sup><br>156mm<br>10W or equivalent oil                                              | 330mm<br>0.2mm             |
| Rear suspension:<br>Shock absorber travel<br>Spring free length                                                                                                                                                      | 90mm<br>239.5mm                                                                                                       | 235mm                      |
| Front wheel:<br>Type<br>Rim size<br>Rim material<br>Rim runout limit<br>Radial<br>Lateral                                                                                                                            | Spoke wheel /radial wheel<br>18X1.60(W)<br>Aluminium                                                                  | 0.5mm<br>0.5mm             |

| Item                                                                                                       | Specification                              | Limit          |
|------------------------------------------------------------------------------------------------------------|--------------------------------------------|----------------|
| Rear wheel:<br>Type<br>Rim size<br>Rim material<br>Rim runout limit<br>Radial<br>Lateral                   | Spoke/radial<br>1.85×18(W)                 | 0.5mm<br>0.5mm |
| Drive chain<br>No.s of link<br>Looseness of chain                                                          | 118<br>20~30mm                             |                |
| Front wheel brake<br>Type<br>Brake drum inside diameter<br>Drum thickness<br>Brake shoe spring free length | Drum brake<br>130mm<br>4mm<br>36.5mm       | 131mm<br>2.0mm |
| Rear wheel brake<br>Type<br>Brake drum inside diameter<br>Drum thickness<br>Brake shoe spring free length  | Drum brake<br>130mm<br>4mm<br>36.5mm       | 131mm<br>2.0mm |
| Brake lever and brake pedal:<br>Brake pedal free play<br>Brake pedal free play                             | 5.5~10.5m/10~15m (Disk/drum)<br>20~30mm    |                |
| Clutch lever<br>Clutch lever free play                                                                     | 10~15mm                                    |                |
| Ignition time:<br>Ignition timing (B.T.D.C.)<br>Advanced timing(B.T.D.C.)<br>Advancer type                 | 7°<br>29°<br>Electrical                    |                |
| C.D.I:<br>Pulse coil resistance /color<br>Source coil resistance /color                                    | (290~330Ω)/20℃<br>(810Ω±20%) (Brown-green) |                |
| Ignition coil<br>Primary winding resistance<br>Secondary winding resistance                                | (0.4Ω±20%)/20℃<br>(7.1kΩ±20%)/20℃          |                |
| Spark plug gap<br>Type<br>Resistance                                                                       | Resin type<br>5kΩ±20%/20℃                  |                |

| Item                                                                                                         | Specification                                                  | Limit |
|--------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|-------|
| Rectifier / regulator<br>No load regulated voltage<br>Capacity<br>Withstand voltage                          | 14.5V $\pm$ 0.5<br>5A<br>240V/min                              |       |
| Battery<br>Specific gravity                                                                                  | 1.280 $\pm$ 0.01(20°C)                                         |       |
| Starter motor<br>Type<br>Output<br>Rotor winding resistance<br>Brush overall length<br>Brush spring pressure | 0.4KW<br>0.171 $\sim$ 0.209 $\Omega$<br>10mm<br>0.9N $\pm$ 20% |       |
| Start relay:<br>Nominal current<br>Coil resistance                                                           | 30A<br>4 $\Omega$ $\pm$ 10%(20°C)                              |       |
| Horn:<br>Type<br>Max. current                                                                                | 1.5A                                                           |       |
| Fuel meter:<br>Resistance of sensor—Full<br>—Empty                                                           | 10 $\Omega$ (20°C)<br>90 $\Omega$ (20°C)                       |       |
| Flashing replay:<br>Type<br>Flash period                                                                     | 60 $\sim$ 120 frequency/min                                    |       |
| Circuit breaker<br>Type<br>Main circuit<br>Reserve circuit                                                   | Fuse<br>15A $\times$ 1<br>15A $\times$ 1                       |       |

## Lock torque




### Engine

| Ser. No | Locking component and location     | Name          | Size of thread | Q'ty | Tightening torque |          |
|---------|------------------------------------|---------------|----------------|------|-------------------|----------|
|         |                                    |               |                |      | Kgf.m             | N.m      |
| 1       | Cylinder head                      | Bolt          | M8×1.25        | 4    | 2.2±0.2           | 22±2     |
| 2       | Cylinder head(timing chain)        | Bolt          | M6×1.0         | 2    | 1.0±0.2           | 10±2     |
| 3       | Oil check bolt                     | Bolt          | M6×1.0         | 1    | 0.7±0.2           | 7±2      |
| 4       | Spark plug                         |               | M10×1.0        | 1    | 1.25±0.25         | 12.5±2.5 |
| 5       | Cylinder head side cover 3         | Bolt          | M6×1.0         | 2    | 1.0±0.2           | 10±2     |
| 6       | Cylinder head side cover 1 (Valve) |               | M45×1.5        | 2    | 1.0±0.2           | 17.5±2.5 |
| 7       | Magneto rotor                      | Nut           | M12×1.25       | 1    | 7.0±1.0           | 70±10    |
| 8       | Chain guide stopper 2              | Bolt          | M6×1.0         | 1    | 1.0±0.2           | 10±2     |
| 9       | Valve locking nut                  | Nut           | M5×0.5         | 2    | 0.75±0.15         | 7.5±1.5  |
| 10      | Timing gear                        | Bolt          | M8×1.25        | 1    | 2.0±0.2           | 20±2     |
| 11      | Cylinder head pressure plate       | Bolt          | M6×1.0         | 1    | 1.0±0.2           | 10±2     |
| 12      | Cam chain tensioner                | Bolt          | M6×1.0         | 2    | 1.0±0.2           | 10±2     |
| 13      | Oil pump assy                      | Bolt          | M6×1.0         | 2    | 0.7±0.2           | 7±2      |
| 14      | Straight screw plug                | Bolt          | M12×1.5        | 1    | 2.0±0.5           | 20±5     |
| 15      | Muffler assy (cylinder head)       | Bolt          | M6×1.0         | 2    | 1.0±0.2           | 10±2     |
| 16      | Muffler assy (body frame)          | Bolt          | M8×1.25        | 1    | 2.2±0.2           | 22±2     |
| 17      | Left and right crankcase           | Bolt          | M6×1.0         | 2    | 1.0±0.2           | 10±2     |
|         |                                    |               | M6×1.0         | 7    | 1.0±0.2           | 10±2     |
|         |                                    |               | M6×1.0         | 1    | 1.0±0.2           | 10±2     |
| 18      | Crankcase cover 1                  | Bolt          | M6×1.0         | 1    | 1.0±0.2           | 10±2     |
|         |                                    |               | M6×1.0         | 6    | 1.0±0.2           | 10±2     |
| 19      | Timing chain cover                 | Bolt          | M6×1.0         | 2    | 0.7±0.2           | 7±2      |
| 20      | Crankcase cover 2                  | Bolt          | M6×1.0         | 6    | 1.0±0.2           | 10±2     |
|         |                                    |               | M6×1.0         | 6    | 1.0±0.2           | 10±2     |
| 21      | Kick starter assy                  | Nut           | M12×1.0        | 1    | 5.0±1.0           | 50±10    |
| 22      | Driven gear pressure plate         | Bolt          | M6×1.0         | 2    | 0.7±0.2           | 7±2      |
| 23      | Starter motor assy                 | Bolt          | M6×1.0         | 2    | 1.0±0.2           | 10±2     |
| 24      | Starter clutch outer assy          | Bolt          | M8×1.25        | 3    | 3.0±0.3           | 30±3     |
| 25      | Main clutch gear                   | Nut           | M12×1.0        | 1    | 7.0±1.0           | 70±10    |
| 26      | Pressure plate 2                   | Elastic screw | M5×0.8         | 4    | 0.6±0.2           | 6±2      |
| 27      | Carrier clutch assy                | Nut           | M12×1.0        | 1    | 6.0±1.0           | 60±10    |

## Body frame

| Ser.<br>No | Locking component and location                 | Name | Size of<br>thread | Q'ty | Tightening torque |         |
|------------|------------------------------------------------|------|-------------------|------|-------------------|---------|
|            |                                                |      |                   |      | Kgf.m             | N.m     |
| 1          | Handlebar seat and inner tube                  | Bolt | M8×1.25           | 2    | 1.8—2.8           | 18—28   |
| 2          | Handlebar and steering column                  | Nut  | M22×1.0           | 1    | 10—12             | 100—120 |
| 3          | Lower holder and inner tube                    | Bolt | M10×1.25          | 2    | 2.3—3.5           | 23—35   |
| 4          | Steering column and adjust nut                 | Nut  | M25×1.0           | 2    | 3.0—3.5           | 30—35   |
| 5          | Handlebar and handlebar seat                   | Bolt | M8×1.25           | 4    | 1.8—2.8           | 18—28   |
| 6          | Caliper and front fork(disk brake)             | Bolt | M10×1.25          | 1    | 2.3—2.7           | 23—27   |
| 7          | Front main cylinder and handlebar (disk brake) | Bolt | M6×1.0            | 2    | 0.75—1.2          | 7.5—12  |
| 8          | Engine front part and engine bracket 2         | Bolt | M8×1.25           | 2    | 3.5—4.0           | 35—40   |
| 9          | Engine bracket 2 and body frame                | Bolt | M10×1.25          | 2    | 4.6—6.0           | 49—60   |
| 10         | Engine rear part and body frame                | Bolt | M8×1.25           | 1    | 3.5—4.0           | 35—40   |
| 11         | Engine upper part and engine bracket 3/4       | Bolt | M8×1.25           | 1    | 3.5—4.0           | 35—40   |
| 12         | Engine bracket 3/4 and body frame              | Bolt | M8×1.25           | 2    | 3.5—4.0           | 45—72   |
| 13         | Steering column and nut                        | Bolt | M12×1.25          | 1    | 4.5—7.2           | 24—39   |
| 14         | Rear shock absorber and rear arm               | Nut  | M10×1.25          | 2    | 2.4—3.9           | 15—23   |
| 15         | Rear shock absorber and body frame             | Nut  | M10×1.25          | 2    | 3.1—4.9           | 5—8     |
| 16         | Brake rod and rear arm                         | Bolt | M8×1.25           | 1    | 1.5—2.3           | 3—5     |
| 17         | Fuel tank and fuel cock                        | Bolt | M6×1.0            | 4    | 0.5—0.8           | 71—112  |
| 18         | Fuel sensor                                    | Bolt | M6×1.0            | 2    | 0.3—0.5           | 35—56   |
| 19         | Front wheel axle and nut (disk brake)          | Bolt | M14×1.25          | 1    | 7.1—11.2          | 71—111  |
| 20         | Front wheel axle and nut (drum brake)          | Bolt | M10×1.25          | 1    | 3.5—5.6           | 35—45   |
| 21         | Rear wheel axle and nut                        | Bolt | M14×1.5           | 1    | 7.1—11.1          | 15—23   |
| 22         | Driven sprocket and clutch hub                 | Bolt | M8×1.25           | 4    | 3.5—4.5           | 7.5—12  |
| 23         | Brake rod and rear brake cover                 | Bolt | M8×1.25           | 1    | 1.5—2.3           | 18—28   |
| 24         | Camshaft lever and camshaft                    | Bolt | M56×1.0           | 1    | 0.75—1.2          | 18—28   |
| 25         | Front disk plate and front wheel (disk brake)  | Bolt | M8×1.25           | 6    | 1.8—2.8           | 100—120 |

For general locking torque (except appointed locking torque), locking torque force is determined by thread diameter (two-face width) and thread pitch when fastening a screw and a screw cap.



| Screw diameter ( two-face width ) × Thread pitch | Lock                  |
|--------------------------------------------------|-----------------------|
| M5 ( 8mm ) × 0.8                                 | 3-4N.m(0.3-0.4kg.m)   |
| M6(10mm) × 1.0                                   | 5-8N.m(0.5-0.8kg.m)   |
| M8(12mm) × 1.25                                  | 12-19N.m(1.2-1.9kg.m) |
| M10(14mm) × 1.25                                 | 24-39N.m(2.4-3.9kg.m) |
| M12(17mm) × 1.5                                  | 45-72N.m(4.5-7.2kg.m) |

### Tightening order of steering system (dual toroidal nut)

- ※ 1. First, the nut (serial number ①) is fastened to 30~35N.m.
2. Then, the direction handle is turned from left to right 2~3 times. Clamping stagnation must not be occurred and the ball race is not flexible while the direction handle is turned.
3. After that, the nut (serial number ①) is unscrewed one-quarter turn, and then fastened. Its fastening torque is 20~24 N.m.
4. The nut (serial number ②) is turned to press against the nut (serial number ③).
5. Then a special gasket of the nut (serial number ④) is assembled, a retaining pawl should be jammed in the furrows of the nuts (serial number ③ and ④) in the meantime. If the furrows are not aligned, the nut (serial number ②) should be turned to guarantee alignment.

### Tightening order of steering system (securing nut with dustproof)







- ※ 1. First, the nut (serial number ①) is fastened to 30~35N.m.
2. Then, the direction handle is turned from left to right 2~3 times. Clamping stagnation must not be occurred and the ball race is not flexible while the direction handle is turned.
3. After that, the nut is unscrewed one-quarter turn, and then fastened. Its fastening torque is 20~24 N.

## Lubrication point and type of lubricants

### Engine

| Ser No. | Lubrication point (name of component)               | Marks                                                                                 |
|---------|-----------------------------------------------------|---------------------------------------------------------------------------------------|
| 1       | Lip of seal (full)                                  |    |
| 2       | Bearing lock plate                                  |    |
| 3       | Bolt (cylinder head)                                |    |
| 4       | Crank shaft pin                                     |    |
| 5       | Piston pin                                          |    |
| 6       | Timing chain/Cam sprocket                           |    |
| 7       | Piston / Piston ring                                |    |
| 8       | Valve rod /Valve guide pipe                         |    |
| 9       | Intake. Exhaust valve rod end surface               |    |
| 10      | Rocker arm shaft                                    |    |
| 11      | Cam and bearing (camshaft)                          |    |
| 12      | Rocker arm shaft inner surface                      |    |
| 13      | Crankcase right-left matching surface               | Yamaha                                                                                |
| 14      | O-ring (full)                                       |  |
| 15      | Kick starter lever gear (inner surface)             |  |
| 16      | Kick starter lever idle gear (inner surface)        |  |
| 17      | Crankshaft bush of Kick starter lever               |  |
| 18      | Starter idle gear axle surface                      |  |
| 19      | Starting clutch (external/rotary part)              |  |
| 20      | Starting wheel gear (inner surface)                 |  |
| 21      | Push rod                                            |  |
| 22      | Master drive gear (inner surface)                   |  |
| 23      | Push rod shaft                                      |  |
| 24      | Master shaft/drive gear (inner surface)             |  |
| 25      | Shifting fork/guide rod/shifting shaft/shifting cam |  |

## Body

| Ser No. | Lubrication point (name of component)          | Marks                                                                                   |
|---------|------------------------------------------------|-----------------------------------------------------------------------------------------|
| 1       | Rear wheel fork shaft                          |  LS  |
| 2       | Steering column (upper and lower end)          |  M   |
| 3       | Guide tube .handlebar (inner surface)          |  M   |
| 4       | Clutch cable and clutch lever contacting parts |  M   |
| 5       | Clutch lever and clutch bracket pivot surface  |  M   |
| 6       | Brake cable and brake lever contacting parts   |  M   |
| 7       | Brake lever and brake bracket pivot surface    |  M   |
| 8       | Brake pedal inner surface                      |  M   |
| 9       | Main stand and the pivot shaft                 |  M   |
| 10      | Side stand and the bracket pivot surface.      |  M  |
| 11      | Rear footrest pivot surface.                   |  M |
| 12      | Speedometer gear                               |  M |
| 13      | Camshaft                                       |  M |
| 14      | Brake shoes pin pivot parts                    |  M |
| 15      | Hub assy.clutch assy .brake cover oil seal lip |  M |



YAMAHA 4-Stroke engine oil




Light lithium base grease



Special grease

## Engine lubrication flow



① Valve arm (intake)

② Rocker shaft

③ Valve arm (exhaust)


④ Cam shaft

⑤ Fine oil filter

⑥ Oil pump

⑦ Push rod

⑧ Filter net



- ① Cam shaft
- ② Filter net assy
- ③ Crankshaft assy

- ④ Main axle
- ⑤ Drive axle
- ⑥ Clutch assy

# **CHAPTER 3**

## **PERIODIC INSPECTION AND ADJUSTMENT**

## Introduction

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable operation and a longer service life. In addition, the need for costly overhaul work will be greatly reduced. This information applies to machines already in service as well as new machines that are being prepared for sale. All service should be familiar with this entire chapter.

## Periodic maintenance/lubrication

| Item                            | Routine                                                                                                                          | Run-in<br>period<br>1,000(600)<br>or 1 month | Initial<br>3,000<br>(2,000)<br>or 3 month | every<br>3,000<br>(2,000)<br>or 3 month |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|-------------------------------------------|-----------------------------------------|
| Valves*                         | Check valve clearance. Adjust if necessary                                                                                       | ○                                            | ○                                         | ○                                       |
| Spark plug                      | Check condition. Clean or replace if necessary                                                                                   | ○                                            | ○                                         | ○                                       |
| Air filter                      | Clean. Replace if necessary                                                                                                      | ○                                            | ○                                         | ○                                       |
| carburetor*                     | Check idle speed/starter operation. Adjust if necessary                                                                          |                                              | ○                                         | ○                                       |
| Fuel pipe*                      | Check fuel hose for cracks or damage. Replace if necessary                                                                       |                                              | ○                                         | ○                                       |
| Engine oil                      | Replace(Warm engine before draining)                                                                                             | ○                                            | ○                                         | ○                                       |
| Engine oil filter<br>net falls  | Clean or replace                                                                                                                 |                                              | ○                                         |                                         |
| Front brake*                    | Check operation drum brake/disk brake fluid leakage/refer to the remarks. Adjust if necessary.                                   |                                              | ○                                         | ○                                       |
| Rear brake                      | Check operation. Adjust if necessary                                                                                             |                                              | ○                                         | ○                                       |
| Clutch                          | Check operation. Adjust if necessary                                                                                             |                                              | ○                                         | ○                                       |
| Rear arm<br>fulcrum*            | Check rear arm whether looseness or not. Screw down it if necessary. Disassemble and repair if properly.                         | ○                                            | ○                                         | ○                                       |
| Rear suspension<br>arm fulcrum* | Check operation. Disassemble and repair it properly.                                                                             | ○                                            | ○                                         | ○                                       |
| Wheel *                         | Check bearing whether looseness or not. Adjust if necessary. Disassemble and repair wheels every 12,000km(8,000km) or 12 months. |                                              | ○                                         | ○                                       |

| Item                   | Routine                                                                                                             | Run-in<br>period<br>1,000(600)<br>or 1 month | Initial<br>3,000<br>(2,000)<br>or 3 month | every<br>3,000<br>(2,000)<br>or 3 month |
|------------------------|---------------------------------------------------------------------------------------------------------------------|----------------------------------------------|-------------------------------------------|-----------------------------------------|
| Wheel bearing*         | Check bearing assembly for looseness/damage.<br>Replace if damaged.                                                 |                                              | ○                                         | ○                                       |
| Steering<br>bearing*   | Check balance state/damage/swing tolerance/<br>screw down spoke, repair if necessary.                               | ○                                            |                                           | ○                                       |
| Front fork*            | Check operation/oil leakage. Repair if necessary                                                                    |                                              | ○                                         | ○                                       |
| Rear shock<br>absorber | Check operation/oil leakage. Repair if necessary                                                                    |                                              | ○                                         | ○                                       |
| Drive chain            | Check tension/alignment. Adjust if necessary.<br>Clean and lubricate                                                | ○                                            | ○                                         | ○                                       |
| Fittings/fasters*      | Check all fittings and fasters, adjust if necessary                                                                 | ○                                            | ○                                         | ○                                       |
| Main stand             | Check operation. Repair if necessary                                                                                | ○                                            | ○                                         | ○                                       |
| Storage battery        | Check the specific gravity of electrolyte fluid.<br>Check breath pipe for proper operation.<br>Correct if necessary |                                              | ○                                         | ○                                       |

\* : It is recommended that these items be serviced by a Jianshe Service station.

\* \*: Heavy-duty or medium truck wheel bearing grease.

\* \* \*: Lithium soap base grease.

### Remark

#### Replace brake fluid:


1. If disassembling brake master cylinder, the brake fluid must be replaced. Check the fluid level under normal condition and refill if necessary.
2. The oil seal of brake master cylinder must be replaced every two years.
3. The brake pipe must be replaced every 4 years or immediately if any crack or damage is found.

## Disassemble and install the seat cushion, oil tank and cover types

### Disassemble


#### 1. Disassemble the side cover (left)

- Open ① with a key
- Pull out the fixed pin of side cover (serial number ②)
- Take out the side cover on the direction of the arrow (serial number ③) points.




#### 2. Disassemble the side cover (right)


- Take out the bolt (serial number ①) with screwdriver
- Pull out the fixed pin of side cover (serial number ②)
- Take out the side cover on the direction of the arrow (serial number ③) points.



#### 3. Disassemble the seat cushion

- Take out the bolts (see the left figure), one on the left and right sides.






#### 4. Disassemble the fuel cock

- Close the fuel cock

#### Note

First close the fuel cock to a position of “●”, and then the fuel pipe.



#### 5. Disassemble the fuel tank

- Bolt ①
- Spacer ②
- Rubber pad ③
- Fuel tank ④

### Install

This installment steps is the reverse of disassembling steps.

#### 1. Install

- Fuel tank
- Torque



Bolt torque (see above figure)  
2 kgf.m (20 N.m)

#### 2. Install


- Seat cushion

#### Note

The parts of lobes located in the rear of the seat cushion are inserted into the pin holes of the frame, and the bolts of the seat cushion are load into every hole respectively, and then screw down the nuts.



Bolt torque (see the left figure)  
1 kgf.m (10 N.m)



## Check and adjust valve clearance


### Note

The valve clearance must not be checked and adjusted until the engine is cool. It can be adjusted when the piston locates T.D.C.

#### 1. Disassemble the parts as fellows


- Side cover (left and right)
- Seat cushion
- Fuel tank

(Refer to disassembling and installment of the seat cushion, fuel tank and cover types)




#### 2. Disassemble the parts as fellows

- the side cover of cylinder head ② and bolt ①
- Spark plug
- Rocker arm cover ③ (intake)
- Rocker arm cover ④ (exhaust)




#### 3. Disassemble the parts as fellows

- Screw cap ① (with o-ring)
- Screw cap ② (with o-ring)



4. Turn around the rotor in counter clockwise direction, and turn the mark **a** of top dead center of the rotor to a place, which is in alignment with the mark **b** of top dead center of the crankcase cover.



5. Check

- Valve clearance



Standard valve clearance  
IN (intake): 0.08~0.12 mm  
EX (exhaust): 0.10~0.14 mm

Below standard value → adjust

\*\*\*\*\*

### Adjustment steps

- Loosen the fixed nut **①**
- Insert a feeler gauge **a**
- Install the valve adjusting tool **③** on the adjuster **②**



Valve adjusting tool



- Turn the adjuster to a standard value. In order to avoid it turn round together, the fixed screw cap is fixed with the adjusting tool and then locked.




Lock torque of the fixed screw cap  
0.75kgf.m (7.5 N.m)

- Confirm the valve clearance, if it is not in line with the standard value, adjusts it once more.

\*\*\*\*\*






## Adjust idle speed


1. Start and warm the engine
2. Install the parts as fellows
  - Engine speedometer
  - Install the engine tachometer on a high-pressure wire (park plug).



3. Confirm items
  - Turnover number of standard idle speed



Out of standard value → Adjust



4. Adjustment
  - Turnover number of standard idle speed

\*\*\*\*\*

### Adjustment order

- Screw down P.S adjusting screw ① lightly

#### Note

Don't lock tightly

- Turn out it to standard number of turns


Standard number of turns of P.S adjusting screw:  
2.0 circle


- Start engine
- Turn the adjusting screw from left to right until standard number of turns.

Turn in → Engine speed is increase  
Turn out → Engine speed is decrease

\*\*\*\*\*

5. Disassemble the parts as fellows
  - Engine tachometer





### Adjust CO content under idle speed condition


1. Install the measuring instrument as follows  
The measuring instrument with the measure-normal-temperature probe and the engine tachometer.
2. Start engine to warm until oil temperature up to the specification.

|                                                                                   |                              |
|-----------------------------------------------------------------------------------|------------------------------|
|  | Given measurement<br>55~65°C |
|-----------------------------------------------------------------------------------|------------------------------|

3. Confirm idle speed value:
4. install CO content measuring instrument ①
5. Check CO consistency value

|                                                                                   |                                            |
|-----------------------------------------------------------------------------------|--------------------------------------------|
|  | Standard CO consistency value<br>1.5%~4.5% |
|-----------------------------------------------------------------------------------|--------------------------------------------|

Exceed standard value → Adjust P.S adjusting screw  
(work in with adjustment of the idle speed screw)



### Check/adjust the free play of the throttle cable

1. Check
  - Check free play ① of extent part of the throttle handle

|                                                                                     |                                                          |
|-------------------------------------------------------------------------------------|----------------------------------------------------------|
|  | Free play ① of extent part of the throttle handle: 3~7mm |
|-------------------------------------------------------------------------------------|----------------------------------------------------------|

Out of specification → Adjust

2. Adjust
  - Free play ① of extent part of the throttle handle

\*\*\*\*\*


### Adjusting orders


#### The first step (the throttle cable)

- Loosen the lock screw cap ②
- Adjust the adjuster ①

|                                                                               |
|-------------------------------------------------------------------------------|
| Turn in → The clearance is increased<br>Turn out → The clearance is decreased |
|-------------------------------------------------------------------------------|

- Tighten the lock screw cap ②





**Note**

When unable to adjust the cable on the throttle handle, adjust the adjuster on the carburetor.

**The second step (carburetor)**

- Loosen the lock screw cap ③
- Adjust the adjuster ④

Turn in → The clearance is increased  
Turn out → The clearance is decreased

- Tighten the lock screw cap ③

\*\*\*\*\*

**Warning**

After adjusted, start the engine, turn the steering bar from the left to the right, and confirm the engine idle speed will not rise.


**Check the spark plug**

1. Check

Check electrode, insulation pollution, burning loss, deposit loss → Replace

Pollution, deposit → Clean it with some spark plug detergent and a wire brush.

2. Measure the clearance of the central electric pole ① and the side electric pole ②.



The clearance between the electric poles  
0.6~0.7mm


Out of specification → Adjust side the electric pole

Standard spark plug: A6RTC/CR6HSA

## Inspect compression pressure

### Note

Insufficient compressure will bring about performance degradation.



#### 1. Check

- Valve clearance

Out of specification → Adjust clearance

Refer to “Valve clearance adjustment”

#### 2. Start the engine, and pre-warm it for several minutes.

#### 3. Stop the engine

#### 4. Disassemble: spark plug

#### 5. Install

- Pressure indicator
- Connector



The Connector of the pressure indicator

#### 6. Check

- Compressure

\*\*\*\*\*

### Checking steps

• Start the engine with the kick starting device or the electric starter when the throttle is opened fully until the reading of the pressure indicator reaches a maximum value, and then read it.

- Check the reading by the specification.



Standard compressure value:  
1200kPa (12kg/cm<sup>2</sup>)

\*\*\*\*\*

#### 7. Install

- Spark plug, spark plug cap

- Too lower compressure

A. The throttle joints badly, which gives rise to compressive leak.

B. Bad adjustment of the throttle clearance.

C. Wear the piston, cylinder and piston ring

- Too higher compressure

A. Carbon deposit of the cylinder head chamber

B. Carbon deposit of the piston head

## Check engine oil



### Note

Must be in a level place, and maintain the body in vertical position.


#### 1. Check

- Engine oil capacity

After two-to-three minutes idle running, the engine is stopped from 2 to 3 minutes so as to make the body in vertical position. Take out the fuel gauge ①.



- Check the oil level of the fuel gauge to make sure it is between ① and ②.



## Engine oil capacity \* recommendatory lubrication oil



When replace in general: 1.0L (1000ml)  
When check the engine: 1.2L (1200ml)


Refer to the left figure, and choose a viscosity number of engine oil suits to the local.

Recommendatory lubrication oil: Yamaha four-stroke lubrication oil

## Replace engine oil

### Note


Must not super-add any chemical additive. Engine oil is able to lubricate a clutch, but the additive might cause clutch slipping. Take care of not to have foreign matters into the crankcase.



1. Put the motorcycle on a flat place.
2. Pre-warm the engine for several minutes, and then stop it. Put an oil container under the outage cock.
3. Disassemble
  - pour oil into the cock
  - Outage cock ①
  - Gasket (be fixed on the outage cock)
4. Oil drain
5. Charge oil from the place where oil is poured into the cock
6. Install
  - Pour oil into the cock
  - Gasket (be fixed on the outage cock)
  - Outage cock ①



Outage cock torque  
2kgfm(20N.m)




### Check oil pressure

1. Disassemble: oil pressure check bolt ①
  2. Start engine, rotate several minutes at idle speed
  3. Check
    - Oil state around the spoil hole
- Oil outflow → Oil pressure is normal  
Oil don't outflow → Oil pressure is lacking

### Note

If no oil outflows after 1 minute, the engine should be stopped to avoid damaging it.

## Adjust clutch



### 1. Check

- The free play of the clutch cable **a**



Free play: 10~15mm  
Measure at the clutch handle end

Exceed specification range → Adjust

### 2. Adjust


- The free play of the clutch cable

\*\*\*\*\*

### Adjusting steps

1. Confirm the adjustor **②** and the locknut **①** to be tightened thoroughly.
2. Loosen the locknut **①**.
3. Turn in or turn back adjusting nut **②** until it reaches given free play.

Turn in → Free play is increased  
Turn out → Free play is decreased




### 4. Tighten the locknut **①**

#### Note

If a free play is incorrect, using the adjustor (one of the part of the clutch handle) to adjust the free play of the clutch cable.


5. Loosen the locknut **③**
6. Turn in or turn back adjustor **④** until it reaches a correct free play.

Turn in → Free play is increased  
Turn out → Free play is decreased



### 7. Tighten the locknut **③**


\*\*\*\*\*



## Clean the air cleaner


### Note

There is a flexible tube ① on the air cleaner housing bottom. If dust and water gather in the flexible tube, cleaning the filter element and the housing is need.



### 1. Disassemble


- Side cover (right)
- Seat cushion
- Air cleaner housing cover ①



### 2. Disassemble


- Filter element ①

Air filter element 2 assemble  
into the air filter element 1



### Note

Starting the engine is strictly forbidden when the air cleaner has been disassembled, or unfiltered air may be enters into the engine result in quick wear of the parts and the damage of the engine. Besides, operating at the state of no filter filling can influence the carburetor operation, and may be lead to an over-heating engine.



### 3. Check

- Filter element

Damage → Replace

Dust → Remove the dust on the filter net with compressed air

① Remove the filter element 1 and 2, blowing wash them with high-pressure air.

② If the dust on the filter element 2 is excessive, cleaning it with neutral solution, after finishing, it must be dried by blowing.

#### Warning


Be mustn't add oil onto the filter element 2.

#### Warning

Be should confirm the filter element has been fixed in the air cleaner housing.

#### Warning

If the filter element is not installed yet, the engine mustn't be operated to avoid over wearing the piston/cylinder.



## Adjust front brake


### 1. Check

- Brake handle free play **a**

Out of specification → Adjust

### 2. Adjust

- Brake handle free play



### Adjusting steps (handle side)


- Loosen the locknut ①
- Turn in or turn out the adjusting nut ② until it reaches the defined free play.

Turn in → Free play is increased  
Turn out → Free play is decreased

- Tighten locknut

#### Note


After adjusting, should make sure the brake has no brake drag.



### Adjust (brake drum side)

- Turn in or turn out the adjusting nut ① until it reaches the defined free play

Turn in → Free play is decreased  
Turn out → Free play is increased



### Check front brake shoes

#### 1. Check

- Clock hand (wear indicating panel) ①
- Clock hand has reached limited scale mark ② of the wear indicating panel → Replace the brake shoes

## Check front brake (disk)


### Warning

If hand feeling is soft in brake, maybe because of oil leak or entry of air, the amount of brake fluid should be checked.

#### 1. Check

- Right-left steering or vibration under drive, should check whether the brake hose touches the other part or not, if touch → Adjust.

2. Check the free play amount of the brake handle front end.



The free play amount of the brake handle front end ② 5.5~10.5 mm

### Note


Manufacture guarantees the clearance, and needn't to be adjusted.

## Check brake lining

#### 1. Check

- Amount of wear of the brake lining

When the wear indicator ① almost touches the brake disc ② → Replace the whole group of brake linings




## Check the amount of brake fluid

#### 1. Check

- Brake fluid level

- Make the brake fluid in a level place, check the fluid level should on the figure 2.

- Beneath the lower limit position, supplement the fluid to the above of it.



Recommended brake fluid: special brake fluid  
DOT3 or DOT4

### Note

Don't mix different brand brake fluids. The brake fluid can erode painting surface or plastic parts. Therefore the leaked fluid must be wiped off immediately.

## Exhaust

### Warning

When the parts related to the brake fluid are disassembled, must make sure that the other parts is locked and sealed, and then conduct the exhaust operation.

\*\*\*\*\*

### Exhaust orders

1. Disassemble the brake fluid cylinder cover.
2. Disassemble the brake fluid cylinder diaphragm.
3. Install a rubber hose ② at the front end of the oil drain screw ①, and put an oil tray in front of the front end of the rubber hose.
4. After braking several times, the brake handle is held tightened, loosening the oil drain screw about one-half cycle, and then tightened it rapidly.

### Note

Mustn't the brake handle before re-newly tighten the oil drain screw.

5. Repeat above procedures, until the oil drain screw let off bubbles completely.

### Note


Supplement brake fluid in the meantime, mustn't make it below the lower limit position.


### Warning

Hold the brake handle, check whether brake fluid leaks or not, wiping off the brake fluid splashed on the brake disc, the tyres and the wheel rim.

- 6.Reinstall the brake fluid cylinder diaphragm.
- 7.Reinstall the brake fluid cylinder cover.

\*\*\*\*\*





## Replace brake fluid

1. Make the master cylinder in a level position, disassemble the brake fluid cover.
2. Fit the front end of the oil drain screw ① with rubber hose ②, putting an oil tray in front of the front end of the rubber hose, loosening the oil drain screw, repeat it until the oil drain screw do not drain brake fluid no longer.


### Warning

Wipe off the brake fluid splashed on the brake disc, the tyres and the wheel rim.

3. Lock the oil drain screw



Oil drain screw: 0.6kg.m (6N.m)



4. Disassemble the brake fluid cylinder diaphragm ③.
5. Pour brake fluid into the above of the lower limit position.

Recommended brake fluid: special brake fluid  
DOT3 or DOT4


### Note

Don't mix different brand brake fluids.

6. Pull the brake handle until the brake fluid hose is full of brake fluid.

### Note

Supplement brake fluid in the meantime, mustn't make it below the lower limit position.



7. Slowly operate the brake handle until the brake cylinder lets off bubbles from small hole, and feel the brake handle strong.
8. Exhaust air
9. After adjusting, install it by the reverse orders of disassemble.

## Check and adjust the rear brake

### 1. Check

- Check the brake and the free play of the front end of the brake pedal.



The brake and the free play of the front end of the brake pedal: 20~30mm

Out of specification → Adjust

### 2. Adjust



- The amount of the brake pedal free play

### Adjustment orders

- Turn the adjuster until the free play is in specified range.

Turn in → Decrease

Turn out → Increase



## Check the rear brake shoes


### 1. Check

- Clock hand (wear indicator board) ①

The clock hand has reached a wear limit reticle of indicator board ② → Replace the brake shoes.

#### Note

Must replace the tension spring when replace the brake shoes.



## Check the rear brake switch

### 1. Check


- Brake light



Check whether the brake light is lightened up or not push on the brake pedal to 20~30mm.

The brake light is gone → Adjust

### 2. Adjust

- Turn the adjusting nut ①
- Rear brake light switch ②





## Check and adjust the drive chain

### 1. Check

- Put the motorcycle on the main stand.
- Check drive chain slack ①



Drive chain slack: 20~30 mm

### 2. Adjust the drive chain

\*\*\*\*\*

#### Adjust steps

- Loosen the axle locknut ①
- Loosen the locknut of adjuster ②
- Turn in or turn back the adjusting advice ③ until the defined slack is obtained.

Turn in → The slack is decreased.

Turn out → The slack is increased.

#### Note

There are scale marks on the chain adjuster. Guarantee the mark numbers of the chain adjusters on the both sides of the rear arm are united when adjust. After adjusting correctly, tighten the adjuster locknut ② and the axle locknut.



Axle locknut: 9.1kgf.m(91N.m)

\*\*\*\*\*


## Transmission chain lubrication

The drive chain includes lot of parts to jointly work. If maintain improperly, the parts will be worn rapidly. So, periodic repair should be conducted. If a motorcycle is running under rich dust condition, this repair is very important.

1. Any brand of spray lubrication oil can be used. Remove all the mud and dirt attached to the drive chain with brush or rag, and then spray the lubrication oil.
2. When the drive chain is needed to be clean, remove it from motorcycle and immerse it into solvent and clean. Then take it out, dry and lubricate it immediately to prevent it from rusting.

#### Note

The chain mustn't be lubricated with lubricating grease.



## Check front fork

1. Place the machine in a level place


2. Check

- Front fork vertical rod

Scratch or damage → Replace

- Oil seal

Serious leakage → Replace



3. Maintain the machine in vertical position, catching the front brake.

4. Check

- Operation

Slide the front fork up and down several times.

Stuck → Repair

Refer to “Front fork” in chapter 6

## Adjust rear shock absorber

### Warning



• Must adjust each absorber's preloaded values to uniform set value to avoid worsening operability and reducing stability.

• Support the machine firmly to prevent it from turn over.

1. Adjust

- Spring preload

Turn adjusting advice ① to the direction **a** or **b**.



Turn to the direction **a** → The spring preloaded value is increased.

Turn to the direction **b** → The spring preloaded value is decreased.




Adjusting advice:  
Standard: 3 Min : 1 Max : 5

### Caution

The adjusting advice mustn't turn to a minimum position or a maximum position.

## Check Tire

### 1. Measure the tire pressure




| Load                    | Front wheel                          | Rear wheel                          |
|-------------------------|--------------------------------------|-------------------------------------|
| Load below<br>0~90kg*   | 175KPa<br>(1.75kgf/cm <sup>2</sup> ) | 196KPa<br>(2.0kgf/cm <sup>2</sup> ) |
| Maximum<br>load 100kg * | 196KPa<br>(2.0kgf/cm <sup>2</sup> )  | 245KPa<br>(2.5kgf/cm <sup>2</sup> ) |

\* Load includes total weight of cargo, driver, passenger and accessories.

Out of specification → adjust

|                          |                |
|--------------------------|----------------|
| Front tire specification | 2.75-18 (42P)  |
| Rear tire specification  | 90/90-18 (51P) |




### 2. Check the tire surface

- Tire tread ①
- Side wall ②
- Wear indicator ③


|                                                                                     |                                         |
|-------------------------------------------------------------------------------------|-----------------------------------------|
|  | Tire wear limit (front and rear): 1.0mm |
|-------------------------------------------------------------------------------------|-----------------------------------------|

Wear/damage → Replace



### Warning

- It is dangerous to ride with a worn out tire. When a tire is out of specification, replace the tire immediately.
- Pay attention not to pick the tubed tire when repair.




## Check steering device

### 1. Check

Set up the front wheel, shaking the lower part of the front fork with hands to check whether the steering column loosen or not. Check whether the direction handle bar can be turn left and right smoothly. Shake to loosen, turn roughly → Adjust the steering column screw cap.

### 2. Steering nut

- Steering screw cap



### Adjusting steps (double ring locknut)


- Disassemble the steering handle

(Refer to “Steering handle” in Chapter 6)

- Disassemble the steering handle seat

Lock the nut with the steering nut spanner

(The lock orders and methods refer to page 20)




### Adjust steps (dust cap locknut)


- Disassemble steering handle

(Refer to “Steering handle” in Chapter 6)

- Disassemble the steering handle seat


(The lock orders and methods refer to page 20)






## Ring locknut

- Install the steering handle seat
- Install the steering handle



## Dust cap locknut

- Install the steering handle seat
- Install the steering handle



## Check battery

### 1. Disassemble

- Side cover

Refer to “Disassemble side cover”

### 2. Check

- Electrolyte level
- The level must be kept between upper level ① and lower level ② marks.

Lower → Fill

### Caution

Refill with distilled water only. Tap water contains minerals harmful to a battery.

### 3. Check

- Battery terminal

Dirty → Clean with wire brush

Improper connection → Correct

#### Caution

After cleaning the terminals, apply grease lightly to the terminals.

### 4. Check


- Breather hose

Obstruction → Remove

Damage → Replace

#### Caution

When inspecting the battery, be sure the breather hose is routed correctly. If the breather hose touches the frame or exists in such a way as to cause battery electrolyte or gas to exit onto the frame, structural or cosmetic damage to the machine can occur.



### 5. Connect

- Breather hose

Be sure the breather hose is connected.

### 6. Check

- Specified gravity

Charging current: 0.5A/10h  
Specified gravity: 1.280 at 20°C (68°F)


Less than 1.08 → Charge

#### Replace the battery if:

- Battery voltage will not rise to a specific value.
- Sulfurization of one or more cells occurs. (As indicated by the plates turning white, if the cell).
- Specific gravity readings after a long, slow charge indicate one cell to be lower than the rest.
- Warpage or buckling of plates or insulators is evident.

#### Caution

Always charge a new battery before using it to ensure maximum performance.



### Warning

- Battery electrolyte is dangerous: it contains sulfuric acid and therefore is poisonous and highly caustic. Always follow these preventive measures.
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or work near batteries.

### Warning

#### Antidote (External):

Skin--Flush with water.

Eyes--Flush with water for 15 minutes and get immediate medical care.

#### Antidote(Internal)

Drink large quantity of water or milk of magnesia, beaten egg, or vegetable oil. Get immediate medical attention.

### Battery also generate explosive hydrogen gas. You should always follow these preventive measures.

- ① Charge batteries in a well-ventilated area.
- ② Keep batteries away from fire, spark, or open flames (e.g. welding equipment, lighted cigarettes, etc.) Do not smoke when charging or handling batteries.
- ③ Keep batteries and electrolyte out of reach of children.

# **CHAPTER 4**

## **ENGINE**


## Disassemble the engine

### Ready to disassemble the engine

#### 1. Disassemble

- Side cover
- Seat cushion
- Fuel tank

Refer to “Disassemble seat cushion, fuel tank and side cover”



#### 2. Engine oil

- Drain oil


Refer “Replace engine oil”

#### 3. Disassemble the exhaust tube

- Exhaust tube ①
- Fixed bolt ②③


#### 4. Disassemble the carburetor

- Carburetor



#### 5. Disassemble the cable and wire

- Socket connector ①
- Socket connector ②
- Battery positive and negative pole wires
- Starter motor wire
- Clutch cable



## 6. Disassemble the shifting pedal and drive chain

### 1) Loosen

- Rear wheel axle nut

### Note

Loosen the chain adjuster nut, and increase the chain slack.

### 2) Disassemble

- Shifting pedal ①


### 3) Disassemble

- Small chain sprocket cover
- Drive chain

## 7. Disassemble the kick starting rod

- Nut
- Kick starting rod

## Disassemble the engine



### 1. Place proper a bracket underneath the engine and the frame (or place the main stand in a level position, make it steady)

### 2. Disassemble

- Install the bolt ① (front side lower support and the engine)
- Install the bolt ② and ③ (front side lower support and the frame)

### 3. Disassemble





- Install the bolt ④ and nut ⑤(lower side)

### 4. Disassemble

- Install the bolt (the rear part of the engine and the frame) ⑥

### 5. Disassemble

- Install the bolt (the engine top and the bracket) ⑦, Install the bolt (the top support and the frame) ⑧



## Disconnect the engine

### Cylinder head, cylinder and piston

1. Disassemble
  - Spark plug
2. Disassemble
  - Intake tube (the connecting hose joint the cylinder and the carburetor)
3. Disassemble
  - Hole cover ①, ②
4. Disassemble
  - Valve cover (intake) ①
  - Valve cover (exhaust) ②
5. Disassemble
  - The side cover of the cylinder head
6. Timing adjustment
  - Aim “ | ” mark on the rotor at the fixed needle pointer on the crankcase cover.

\*\*\*\*\*

### Timing adjustment steps


Turn the crankcase anticlockwise with spanner.

Aim “ | ” mark ① on the rotor at the fixed needle pointer ② on the crankcase. When “ | ” mark is in alignment with the fixed needle pointer, the piston locates at the top dead center (T, D, C).

In the meantime, the calibration mark ③ on the cam chain sprocket is in alignment with the one ④ on the fixed needle pointer, the rock arm on both side must form a valve clearance.

If no valve clearance, turn the crankcase anticlockwise to meet above requirements.

\*\*\*\*\*




7. Loosen

- Cap bolt ① (cam chain tensioner)

8. Disassemble

- Cam chain tensioner ②




9. Disassemble

- Bolt ①
- Cam chain sprocket ②

**Note**

The timing chain is fixed by a protecting cable ③ to avoid dropping into the crankcase.




10. Disassemble

- Bolt ①②③④⑤⑥
- Cylinder head


**Note**

Each bolt is loosened quarter turn in advance, and is twisted off when all of them is loose. Loosen them from the minimum number. The opposite numbers countermarked on the cylinder head is the orders to turn the bolt.




11. Disassemble

- Chain guide plate ①
- Dowel pin ②
- Cylinder gasket
- Cylinder



## 12. Disassemble

- Dowel pin ①
- Gasket ③




## 13. Disassemble

- Elastic circlip of piston pin ①
- Piston pin ②
- Piston ③

### Note

- Before disassembling the circlip of piston pin, the crankcase should be covered a piece of clean cloth ④ to prevent the circlip from falling into the crankcase.
- Before disassembling piston, the groove of circlip and the pin hole should be cleaned. If they have been cleaned, but the piston pin is still disassembled difficultly, the remover for piston pin should be used.

## Left crankcase cover and starter motor



## 1. Remove


- Neutral light switch ①

## 2. Disassemble

- Left crankcase cover ②
- Dowel pin
- Gasket

## 3. Disassemble


- Starter motor



## Clutch and oil pump

### 1. Disassemble

- Kick starter rod




### 2. Disassemble

- Crankcase cover (right)
- Gasket ①
- Dowel pin

#### Note

First, loosen each bolt quarter turn by the order of cross wire, and then turn off all the bolts.




### 3. Disassemble

- Bolt ①
- Clutch spring ②
- Pressure plate ③
- Friction lining ④
- Clutch lining ⑤
- Push rod 1 ⑥
- Steel ball ⑦

#### Note

First, loosen each bolt quarter turn by the order of across corners, and then turn off all the bolts.



#### 4. Straightening

Level the tongue of lock washer

#### 5. Loosen


- Nut ①

#### Note

When loosen nut (clutch scab), the clutch hub is fixed with the clutch clamp.




Universal clutch clamp




#### 6. Disassemble

- Nut ①
- Lock washer ②
- Clutch hub ③
- Spline washer ④
- Driven gear ⑤
- Washer ⑥
- Elastic washer ⑦




#### 7. Disassemble

- Primary driven gear nut ①




#### Note

- Strap, aluminium plate and copper strip can not be put into the place between the driven gear and the primary driven gear.
- Should use the sleeve to fix the nut at the place where the rotor fixes the nut, and then disassemble the primary driven gear nut ①.



#### 8. Disassemble


- Primary driven gear nut ①
- Key ②
- Oil filter ③



### Oil pump

#### 1. Disassemble


- Bolt ①
- Oil pump ②
- Gasket ③
- Oil pump driven gear ④



### Starting shaft and idle gear


#### 1. Disassemble

- Circlip ①
- Flat washer ②
- Idle gear ③
- Flat washer ④
- Circlip ⑤




#### 2. Disassemble

- Torsion spring ①
- Starting shaft assy ②



## Shift shaft

1. Disassemble
  - Shifting lever ①
  - Torsion spring ②
  - Bolt ③
  - Stopper ④



## Rotor


1. Disassemble
  - Nut ①

### Note

Fix the rotor with a rotor clamp, and then loosen the nut.



Rotor clamp




2. Disassemble
  - Rotor ①
  - Woodruff key

### Note


A fly wheel remover ② pushes the fly wheel backwards to disassemble the rotor ①.




Fly wheel remover



3. Disassemble
  - Starting idle gear 1
  - Washer
4. Disassemble
  - Gear pressure plate ②
  - Starting idle gear 2 ①



5. Disassemble
  - Chain guide plate ①
  - Timing chain ②





## Crankcase (right)

1. Disassemble
  - Screw (crankcase)

2. Disassemble
  - Star gear
  - Dowel pin

### Note

- The crankcase should be separated from the right side.
- Disassemble the star gear.
- Be careful not to damage the mating surface of the crankcase.






## Balancing device, transmission and shifting rod

1. Disassemble
  - Shifting fork guide rod ① (short)
  - Shifting fork guide rod ② (long)
  - Shifting fork C ④
  - Shifting fork R ⑤
  - Shifting fork L ⑥
  - Shifting cam ③

2. Disassemble
  - Main shaft ①
  - Clutch inner push bar 2
  - Drive shaft ②
  - Washer
  - Clutch push bar ③

3. Disassemble
  - Neutral switch ①





## Crankshaft and counterbalance


### 1. Disassemble

- Counterbalance
- Crankshaft ①

Disassemble them with a crankshaft remover ②.

#### Note


- Tighten the strutting bolt of the separating tool, but make sure that the tool shell is perpendicular to the crankshaft. If necessary, one screw can be turned back a little to calibrate the state of the stool shell.



## Rocker arm and camshaft

### 1. Disassemble

- Lock pressure plate ①




### 2. Disassemble

- Camshaft (with bearing ②) ①

#### Note

The camshaft is disassembled with bolt of 8mm 3




### 3. Disassemble

- . Rocker arm shaft
- . Rocker arm

#### Note

The rocker arm shaft is disassembled with the slide hammer bolt and the weight ①.

Slide hammer bolt  
Weight



## Valve

### Note

Before disassembling the inner parts of the cylinder head (for example valve, valve spring, valve seat), check the valve seal before hand.

### 1. Check

- Valve sealer

Leakage at valve seat → Check the working face of the valve

- Valve seat and valve seat width


Refer to “Valve seat check and maintenance”

\*\*\*\*\*

### Check steps

- Pour the clean solvent ① in the intake valve and the exhaust valve.
- Check the valve seal.
- No leakage around the valve seat ②

\*\*\*\*\*



### 2. Disassemble


- Valve lock ①

### Note

When disassemble the valve lock, use the valve spring compression tool to compress the compression valve spring.



Valve spring compression tool



### 3. Disassemble

- Valve spring upper seat ①
- Valve spring ②
- Valve ③
- Valve seal ④
- Valve spring lower seat ⑤

### Note

Mark positions of every parts to install it on the original position once more.

## Check and repair

### Cylinder head


#### 1. Clean

- Carbon deposit

(Eliminate from combustion chamber)

#### Note

Don't use sharp tool to avoid damaging or scoring spark plug thread and valve seat.



#### 2. Check


- Cylinder head

Scratches or damage → Replace

#### 3. Measurement

- Cylinder skew

Check whether the 6 directions of the junction surface of the cylinder head is skew or not.



Skewness: less than 0.03mm

#### 4. Reshape surface

- Cylinder head

\*\*\*\*\*


#### Reshape surface steps:


Place a piece of wet sandpaper of 400~600# onto a platform, and use it to grind the cylinder head by figure eight.

\*\*\*\*\*

#### Note

Move the cylinder head several times to avoid grinding some side excessively





## Valve seat

### 1. Clean

- Carbon deposit

(Eliminate from valve face and the valve seat)

### 2. Check

- Valve seat

Pit corrosion or wear → Repair valve seat once more

### 3. Measurement

- Valve seat width **a**



Valve seat width **a**

Intake: 0.9~1.1mm

Exhaust: 0.9~1.1mm



Out of specification → Repair valve seat once more

\*\*\*\*\*

## Measuring steps

- Smear blue dyes (Dykem) onto the working surface **b** of the valve when overhaul.
- Install the valve into the cylinder head.
- The valve is push onto the valve seat through the valve guide, and then got a clear trace.
- Measure the width of the trace, that is, the width of the valve seat. No matter how the valve seat and valve face contact anywhere, the blue don't disappear.
- If the valve seat is too wide, narrow or don't locate in the center, must repair it once more.

\*\*\*\*\*



### 4. Grind

- Working surface of valve
- Valve seat

#### Note

After replacing the valve and the valve guide, must grind the valve seat and valve face.

\*\*\*\*\*

### Grinding steps

- Smear rough grinding sand on valve face.

#### Note

Don't make grinding sand into the gap between the valve stem and the valve guide.

- Smear molybdenum-bearing disulfide oil on the valve stem surface.
- Install the valve into the cylinder head
- Turn the valve till valve face and the valve seat are polished evenly, and then eliminate all grinding agents.

#### Note

For good effective, knock the valve seat lightly while turning the valve back and forth with two hands.


- Smear fine grinding agent on valve face, and then repeat the above steps.


#### Note

After grinding each time, wipe the grinding agent on valve face and the valve seat clean.

- Measure the width of the valve seat again.
- If the width is out of specification, repair and grind the valve seat once more.

\*\*\*\*\*





## Valve and valve guide


### 1. Measure

- Gap between valve stem and guide

Gap between valve stem and guide = guide inside diameter - valve stem diameter

Out of specification → Replace valve guide

Gap between valve stem and guide:  
 Intake: 0.01~0.037 mm limit value: 0.08mm  
 Exhaust: 0.025~0.052 mm limit value: 0.10mm



|               | Valve guide inside diameter standard value | Used limits |
|---------------|--------------------------------------------|-------------|
| Intake valve  | 5.000~5.012mm                              | 5.042mm     |
| Exhaust valve | 5.000~5.012mm                              | 5.042mm     |

### Note

After replacing the valve guide, repair the valve seat face once more.

### 2. Clean

- Carbon deposit  
(Eliminate from valve face)

### 3. Check

- Valve face

Pit corrosion or wear → Polish surface

- Valve stem end

Mushroom shape or the diameter is more than the other parts of the valve stem → Replace


### 4. Measurement


- Swing tolerance (valve stem)



Swing tolerance:  
less than 0.01 mm

Out of specification → Replace






## Valve spring

### 1. Measurement

- Free length (a) (valve spring)

|  |                                                             |
|--|-------------------------------------------------------------|
|  | Valve spring free length:<br>Standard:32.28mm Limit:31.90mm |
|--|-------------------------------------------------------------|


Out of specification → Replace



### 2. Check

- Valve spring verticality

|  |                              |
|--|------------------------------|
|  | Side angle limit (a): 1.2 mm |
|--|------------------------------|



### 3. Check

- Valve spring contact surface

More than 2/3 of peripheral region is horizontal contact → Replace


## Camshaft

### 1. Cam heave

Pit corrosion, scratching, bluing → Replace

### 2. Measurement

- Cam heave A and B





Cam heave length

**Intake:**

A standard: 25.881-25.981mm

Limit: 25.851mm

B standard: 21.195-21.295

Limit: 21.165

**Exhaust:**

A standard: 25.841-25.941

Limit: 25.811

B standard: 21.050-21.150

Limit: 21.02 mm

Out of specification → Replace

3. Check

- Bearing


Clamping stagnation, shake → Replace

## Rocker arm and rocker arm shaft

1. Check

- Rocker arm and cam heave contact surface ①
- Valve adjusting screw face ②

Wear, pit corrosion, scratching, bluing → Replace, and then check lubrication system



2. Measurement


Rocker arm inside diameter ①



Rocker arm inside diameter standard:

10.000-10.015mm Used limit: 10.030mm

Out of specification → Replace




3. Measurement


- Rocker arm shaft outside diameter ①



Rocker shaft outside diameter Standard

value: 9.981-9.991mm Limit: 9.95mm






## Timing chain, sprocket, chain guide plate and chain tensioner

### 1. Check

- Timing chain

Hardening or crack → Replace timing chain and sprocket completely




### 2. Check

- Sprocket

Hardening or crack → Replace timing chain and sprocket completely


- Quarter gear ①
- Correct combination ②
- Rotor ③
- Sprocket ④



### 3. Check

- Chain guide plate ① (exhaust side)
- Chain guide plate ② (intake side)

Wear or damage → Replace



### 4. Check





- Timing chain tensioner free play

\*\*\*\*\*

### Checking steps

- Press the tensioner rod lightly with a finger, and turn the tensioner rod to the end with a small screw driver.
- When press and loosen the screw driver, should make sure that the tensioner can go out smoothly.
- If not, the tensioner assy must be replaced.

\*\*\*\*\*



## Cylinder and piston

### 1. Clean

- Carbon deposit

(From the top of piston ① and ring groove ②)

### 2. Check

- Piston side wall

Wear, scratching and damage → Replace

### 3. Check

- Cylinder wall

Wear or scuffing → Bore cylinder once more or replace

### 4. Measurement

- Piston-to-cylinder clearance

\*\*\*\*\*

## Measuring steps

### 1. Measure the cylinder bore C with a bore gauge.

The position of D3,D4 (40mm distance from the top of cylinder)

### Note

Measure the cylinder bore in the two directions, one parallels to the crankcase, one squares to the crankcase, and then demand an average value.



Cylinder inside diameter standard:  
54.024~54.056 mm

Out of specification → Replace


### 2. Measure the piston

- Measure the piston skirt diameter with micrometer calipers, and measure it at the distance of 5.0 mm away from the bottom margin of the piston.



Piston outside diameter standard:  
53.997~54.029 mm

\*\*\*\*\*



### 5. Piston-to cylinder clearance

Cylinder inside diameter-piston outside diameter =  
clearance



Standard piston-to-cylinder clearance:  
0.020~0.034mm


Out of specification → Replace

## Piston pin

### 1. Check

- Piston pin

Bluing or form groove → Replace, and then check  
lubrication system




### 2. Measurement

- Piston pin outside diameter ①



Piston pin outside diameter:  
14.991~15.000mm Limit: 14.969mm

Out of specification → Replace




### 3. Measurement

- Piston pin hole inside diameter ②



Piston pin hole inside diameter:  
15.002-15.013mm Used limit: 15.043mm

Out of limit → Replace



## Piston ring

### 1. Measurement

- Side clearance

Out of specification → Replace piston-ring groove and piston ring completely

#### Note

During measuring side clearance, carbon deposit on the piston-ring groove and the every ring should be eliminated.




Side clearance:

1 ring: 0.03~0.07mm

Used limit: 0.12mm

2 ring: 0.02~0.06mm

Used limit: 0.12mm



### 2. Measurement

- Push the piston ring **a** into the cylinder (the position of 5 mm away from the top)

#### Note

Use the piston top to push the piston ring to make the ring verticality to cylinder bore.

### 3. Measurement

- End gap

#### Note

The end gap of the oil ring can not be measured at the expander-ring septum of the oil ring, and only measure the end gap between upper and below barriers. If the gap is too large, then there are 3 rings must all be replaced.



End gap:


1 ring: 0.15~0.30mm

Used limit: 0.4mm

2 ring: 0.30~0.45mm

Used limit: 0.55mm

Oil ring: 0.2~0.7mm



## Crankshaft

### 1. Check

- Crankshaft swing tolerance

|  |                                       |
|--|---------------------------------------|
|  | Crankshaft swing tolerance:<br>0.03mm |
|--|---------------------------------------|

Out of limit → Replace

#### Note


Turn the crankshaft slowly for the measurement.

### 2. Check

- Big-end side clearance

|  |                                                           |
|--|-----------------------------------------------------------|
|  | Standard side clearance: 0.15-0.45mm<br>Used limit: 0.8mm |
|--|-----------------------------------------------------------|

Out of limit → Replace




### 3. Measurement

- Crankshaft width (measure it with a vernier caliper)

|  |                                  |
|--|----------------------------------|
|  | Standard width:<br>46.95~47.00mm |
|--|----------------------------------|

Out of standard → Replace




### 4. Check

- Crankshaft sprocket ①

Damage, wear → Replace crankshaft

- Bearing ②


Abnormal noise, instable rotation, loose → Replace




### 5. Check

- Crankshaft oil-way

Blockage → Clean it through compressed air






## Balancing device

### 1. Check

- Crankshaft driving gear ①
- Crankshaft driven gear ②


Wear, damage → Replace



### 2. Check

- Balancer

Wear, damage → Replace



### 1. Check


- Driving gear ①
- Driven gear ②

Wear, damage → Replace 2 gears

### 2. Check

- Friction lining

High noise when operating → Replace friction lining completely




### 3. Measurement

- Friction lining thick

|                                                                                     |                                                   |
|-------------------------------------------------------------------------------------|---------------------------------------------------|
|  | Friction lining thick: 3.0mm<br>Used limit: 2.8mm |
|-------------------------------------------------------------------------------------|---------------------------------------------------|

Out of specification → Replace friction lining completely, measure it at the 4 point of the upper, the lower, the right and the left.



4. Check

- Clutch lining

Damage → Replace clutch lining completely

5. Measurement


- Clutch warp

Out of specification → Replace clutch lining completely

- Use plate and caliper gauge ①



Friction limit value:  
less than 0.05mm




6. Measurement

- Clutch spring length ①

Damage → Replace clutch spring completely



Clutch spring length: 33.0mm  
Limit: 31.0mm




7. Check

- Main driven gear ① stopper

Scrape, wear, damage → Barbing or replace

- Clutch hub ②

Scrape, wear, damage → Replace




8. Check

- Steel ball ①

- Push rod 1 ②

- Pressure plate ③

Wear, damage → Replace




## Transmission and shift lever

### 1. Check

- Cam follower of shifter fork ①
- Shift fork claw ②


Scuffing, bend, damage → Replace



### 2. Check

- Shifting cam groove


Damage or wear → Replac



### 3. Check

- Fork guide rod (short left, long right) ①
- Shifting cam ②

Distortion, scuffing, bend, damage → Replace




### 4. Check

- Shifting fork action

Unfavorable action → Replace shifting fork or guide rod

### Warning

Be mustn't straighten the curving guide rod.




### 5. Measurement

- swing tolerance (driving shaft and main shaft)

Out of specification → Replace

### Warning

Be mustn't straighten the curving shaft.




#### 6. Check

- Gear tooth

Bluing, pit corrosion, wear → Replace mating gear

End land become round, crack and disalignment →

Replace



#### 7. Check

- Shifting shaft ①

Damage, bend, wear → Replace

- Torsion spring (stopper lever) ②

- Return spring (shifting shaft) ③


Damage → Replace

### Kick starter

#### 1. Check

- Kick starter gear tooth ①
- Kick starter pinion tooth ②

Damage or wear → Replace 2 gears in couples




#### 2. Measurement


- Kick starter collar tension

Use spring balance ①

|  |                                           |
|--|-------------------------------------------|
|  | Kick starter collar tension:<br>0.2-1.2kg |
|--|-------------------------------------------|

Out of specification → Replace






## Oil pump and oil filter

### 1. Measurement

- Gear tip clearance A  
(Between inside rotor ① and outside rotor ②)
- Side clearance B  
(Between outside rotor ② and pump housing ③)
- Clearance C between inside-and-outside rotor and pump housing  
(Thickness difference of inside rotor ①, outside rotor ② and pump housing ③)




Gear tip clearance A: 0.15mm  
Side clearance B: 0.06-0.10 mm  
Thickness difference C: 0.06-0.10 mm



### 2. Check

- Centrifugal oil filter
- Chap, damage → Replace  
Have the dirt → Clean



### 3. Check

- Oil filter net
- Chap damage → Replace  
Have the dirt → Clean

## Crankcase

1. Thoroughly wash the contact face of crankcase with a sort of hot solvent.
2. Thoroughly wash the matching faces of sealing gasket and crankcase with a sort of hot solvent.
3. Check
  - CrankcaseCrack or damage → Replace
  - Oil holeBlockage → Blow out with compressed air

## Bearing and oil seal

1. Check
  - BearingClean and lubricate, whirl the inner race with a finger.  
Unevenness → Replace

|             |
|-------------|
| <b>Note</b> |
|-------------|

Must not dry them by blow in compressed air, or can lead to a damage of the bearing face.


2. Check
  - Oil sealingDamage or wear → Replace

## Circlip and washer


1. Check
  - Circlip
  - WasherDamage, loosen, bend → Replace

## Engine assembly and adjustment

### Valve, rocker arm and cam shaft




- |                           |                            |                  |
|---------------------------|----------------------------|------------------|
| ① Valve lock              | ⑦ Valve stem (intake)      | ⑬ O-ring         |
| ② Valve spring upper seat | ⑧ Lock nut                 | ⑭ Valve guide    |
| ③ Valve stem oil seal     | ⑨ Adjusting bolt           | ⑮ Cam shaft      |
| ④ Valve spring            | ⑩ Rocker arm               | ⑯ Pressure plate |
| ⑤ Valve spring seat       | ⑪ Rocker arm pin (intake)  |                  |
| ⑥ Valve stem (exhaust)    | ⑫ Rocker arm pin (exhaust) |                  |



## Engine assembly and valve adjustment


### 1. Eliminate burr

- Valve stem end
- Polish valve stem end with oilstone



### 2. Smear

- Molybdenum sulfide base lubricant  
(Smear it on the valve stem and valve oil seal)
- Four stroke engine oil  
(Smear on the valve stem top)




### 3. Install

- Valve spring seat ①
- Valve oil seal ②
- Valve ③
- Valve spring ④
- Valve upper seat ⑤

#### Note

Upturn the side to make the spring pitch **a** big, install the valve spring. **b** is small pitch.



### 4. Install


- Valve lock ①

#### Note

When install the valve lock, compress the valve spring with the valve spring compressed tool.




Valve spring compressed tool



5. Ham the valve lock with a hammer to fix it on the valve stem.

#### Note


Don't ham it too hard to avoid damaging the valve.



### Rocker arm and cam shaft

#### 1. Lubrication

- Supramoly sulfide base lubricant  
(Smear the contact face of the rocker arm hole and the cam shaft)
- Four stroke engine oil  
(Smear rocker arm shaft and O-ring seals)




#### 2. Install

- Rocker arm
- Rocker arm shaft ①
- Align the screw hole of cylinder head to install until the rocker arm is invisible.


#### Note

The screw hole is toward outside while installing.



#### 3. Install


- Cam shaft ①



#### 4. Install

- Pressure plate ①
- Bolt ②

## Crankshaft and balance device



① Crank pin

② Crank

③ Connecting rod


④ Big-end needle bearing

⑤ Crankshaft bearing

⑥ Woodruff key

⑦ Balancer

⑧ Balancer bearing



## Install crankshaft and balancing shaft

### 1. Install


- Crankshaft



Distance bushing install  
The crankshaft spanner  
The crank shaft bolt  
Reducing coupling

### Note


- Maintain the connecting rod in the position of upper dead center, when installing, do not touch the crankcase.
- Do not ham the crankshaft with a hammer.



### 2. Install


- Balance shaft
- Align the mark (a) on the crank driving gear with the mark (b) on the balance shaft gear, and then install them.

## Transmission



- |                    |                  |                   |                  |
|--------------------|------------------|-------------------|------------------|
| ① Driving sprocket | ⑥ 2nd wheel gear | ⑪ Bearing         | ⑯ Main shaft     |
| ② Oil seal         | ⑦ 3rd wheel gear | ⑫ 5th pinion gear | ⑰ Retaining ring |
| ③ Bearing          | ⑧ 4th wheel gear | ⑬ 2nd pinion gear | ⑱ Bearing        |
| ④ 5th wheel gear   | ⑨ 1st wheel gear | ⑭ 3rd pinion gear |                  |
| ⑤ Driving shaft    | ⑩ Bearing        | ⑮ 4th pinion gear |                  |

## Gear shift cam and fork



① Fork guide rod 1

② Fork 3

③ Fork 1

④ Cam


⑤ Star gear

⑥ Fork guide rod 2 (short)

## Install transmission system, gear-shift cam, gear-shift fork

### 1. Install

- Clutch push rod 2 ①




### 2. Install

- Main shaft

#### Note

- First, the clutch inside push rod is installed in main shaft inside hole. Then install the main shaft.




### 3. Check

- The installing width of the main shaft gear ④



Standard installing width of the main shaft: 82.25-83.45mm




### 4. Install

- Washer ①
- O-ring ②

Install the O-ring in the mounting groove of the fixed bracket of the driving shaft sprocket. After installing the driving shaft, take off the O-ring.

- Driving shaft ③



#### 5. Install

- Gear shift cam

(Align the salient point on the gear shift cam with the contact point of neutral switch on the crankcase)

- Gear shift fork "L" ①

(One side marked L towards the clutch)

- Gear shift fork "R" ②


(One side marked R towards the clutch)

- Gear shift fork "C" ③

(One side marked C towards the clutch)

- Gear shift fork guide rod 2 ④

- Gear shift fork guide rod 1 ⑤



#### 6. Check

- Gear shift cam operation



Rough operation → Re-installment

#### Note

- Turn the gear shift cam to confirm drive and fork operation smoothly with hands.

## Crankcase

Tightening order




① Left crankcase

② Dowel pin

③ Air pipe

④ Right crankcase

⑤ Clutch fixing clip



### Crankcase (right)

#### 1. Smear


- Sealant

(Smear on the contact surface of left or right crankcase)



#### Note

Be must not let any Sealant into lubricating hole. See figure, the place of **a** and **b**.



#### 2. Install


- Dowel pin ①

#### 3. Install

- Install the right crankcase on the left crankcase.

#### Note

Before installing and tightening the fixed screw of crankcase, the gear shift cam must be turned with hands to check the transmission in normal operation.



#### 4. Tighten

- Bolt ①②③④⑤⑥⑦⑧⑨⑩(crankcase)

#### Note

Tighten the bolts one by one, beginning from the minimum number.

#### 5. Smear

- Four stroke engine oil


(Smear on the crankshaft pin, bearing and crank hole.)

#### 6. Check


- Crankshaft and transmission actions

Tough operation → Repair

## Shift shaft, kick starter axle and kick starter idle gear




- |                       |             |
|-----------------------|-------------|
| ① Shift shaft         | ⑦ Circlip   |
| ② Return spring       | ⑧ Washer    |
| ③ Stopper             | ⑨ Idle gear |
| ④ Torsion spring      | ⑩ Washer    |
| ⑤ Star gear           | ⑪ Circlip   |
| ⑥ Starting shaft assy |             |



### Shifting cam

#### 1. Install

- Dowel pin ①




#### 2. Install

- Star gear ①

#### Note

When install the star gear, the pin hole on the star gear and the pin hole (a) on the cam must be installed on the right position.



#### 3. Install


- Stopper ①
- Spring ②



Bolt (stopper): 1.0kgf.m(10 N.m)

#### Note

Make the stopper mesh with the shift star gear.




#### 4. Install

- Shift shaft ③

#### Note

When install the shift shaft, the torsion spring on the shift shaft must be jammed into the dowel pin ④.




### Kick starter axle and kick starter idle gear

#### 1. Install

- Starting shaft ①
- Clamp ②
- Spring ③

#### Note


The projection of spring ③ must be installed on the place ① of the case, and the spring can not be fixed till it rotates one lap.




#### 2. Install

- Circlip ①
- Washer ②
- Idle gear ③
- Washer ④
- Circlip ⑤

## Clutch, oil pump



- |                   |                    |                 |                              |
|-------------------|--------------------|-----------------|------------------------------|
| ① Spring          | ⑥ Clutch lining    | ⑪ Push rod      | ⑮ Oil pump transmission gear |
| ② Pressure plate  | ⑦ Clutch hub       | ⑫ Push rod assy | ⑯ Oil pump driving gear      |
| ③ Push plate      | ⑧ Stop washer      | ⑬ Driving gear  | ⑰ Oil pump housing           |
| ④ Push rod 1      | ⑨ Main driven gear | ⑭ Oil filter    | ⑱ Oil pump gasket            |
| ⑤ Friction lining | ⑩ Steel ball       | ⑮ Dowel pin     |                              |



### Oil pump


#### 1. Oil charge

- Four stroke engine oil

(Charge into the oil holes in the crankcase and the oil pump)

#### 2. Install

- Oil pump




### Oil filter

#### 1. Install

- Oil pump driving gear
- Centrifugal filter

#### Note

Install the dowel pin (a) of the centrifugal filter in the stop groove of the crankshaft.




### Main driving gear

#### 1. Install

- Main driving gear ①
- Dowel pin
- Washer ②
- Nut ③

#### Note


When lock the nut, the rotor must be fixed not to make crankshaft turn. The prohibition against placing aluminium flakes, stripes or copper sheets among the gears to make the crankshaft stop turning.



## Clutch

### 1. Install

- Main driven gear ①
- Thrust washer ②
- Clutch hub ③
- Lock washer ④
- Nut ⑤



### 2. Install

- Nut ②

#### Note


Fix the clutch hub with a clutch clamp ③, locking the nut, and bending the lock washer ①.



Clutch clamp



nut torque:  
6.0 kgf.m(60N.m)




### 3. Install

- Four friction linings ①
- Three clutch plate ②


#### Note

- Smear the clutch plates with four stroke engine oil, and then install it.
- Install the clutch plate and friction lining on the clutch hub alternately, beginning with the friction lining, ending with the friction lining.




4. Install

- Steel ball



5. Install

- Push rod ①
- Push plate ②
- Washer ③
- Nut ④



6. Install


- Pressure plate ①
- Spring ②
- Bolt ③



Mounting torque of the bolt:  
0.6kgf.m(6N.m)

**Note**


Tighten the bolts by diagonal order.



7. Confirm

- Alignment mark of the push rod assy and the crankcase
- Turn the push rod assy anticlockwise thoroughly, confirming whether the objection (a) of the push rod aligns with the one (b) of the alignment mark of the crankcase or not.

Unaligned → Adjust




#### 8. Adjustment

- Alignment mark of the push rod ③ and the crankcase
- Loosen the nut ①, turn the push rod anticlockwise thoroughly
- Turn the push rod ② right and left for adjusting until a aligns with b.
- Lock the nut after adjusting.



Lock torque of the nut:  
0.8kgf.m(8N.m)




#### 9. Install

- Gasket (new)
- Right case cover



Mounting torque of the case cover:  
1.0kgf.m(10 N.m)




#### 10. Install

- Kick-starting rod




Mounting torque of the kick-starting rod:  
5.0kgf.m(50 N.m)

## Timing system



- |                        |                   |                   |
|------------------------|-------------------|-------------------|
| ① Timing chain         | ⑥ Washer          | ⑪ Gasket          |
| ② Chain guide plate    | ⑦ Starting gear 2 | ⑫ Dowel pin       |
| ③ Dowel shaft          | ⑧ Woodruff key    | ⑬ Left case cover |
| ④ Idle starting gear 1 | ⑨ Rotor           |                   |
| ⑤ Pressure plate       | ⑩ Stator          |                   |



### Rotor and starting mechanism

#### 1. Check

- Check the gear condition (a) (b) (c) of starting gear 1 and 2.

Burr, Scraps, out-of-flatness, wear → Replace

#### 2. Check

Starting gear 2 (contact surface)


Pit corrosion, wear, damage → Replace

\*\*\*\*\*

### Check steps

- Install the starter gear in the clutch of the starter, and hold the clutch.
- When turn the starter gear clockwise (A), the clutch of the starter mesh with its gear, or the clutch of the starter goes wrong and be replaced.
- When turn the starter gear anticlockwise (B), the clutch gear of the starter should be turned freely, or the clutch of the starter goes wrong and be replaced.

\*\*\*\*\*



### Chain guide plate and idle gear

#### 1. Install

- Timing chain
- Chain guide plate

|                                                                                     |                                     |
|-------------------------------------------------------------------------------------|-------------------------------------|
|  | Mounting torque<br>1.0kgf.m(10 N.m) |
|-------------------------------------------------------------------------------------|-------------------------------------|


#### Note

First, the timing chain must be installed, and then the guide plate is fixed.

#### 2. Install

- Starting idle gear (1)
- Pressure plate (2)


|                                                                                     |                                   |
|-------------------------------------------------------------------------------------|-----------------------------------|
|  | Mounting torque<br>0.7kgf.m(7N.m) |
|-------------------------------------------------------------------------------------|-----------------------------------|



### 3. Smear

- Four-stroke engine oil

(Smear shaft collar and starter drive mechanism)



### 4. Install


- Washer ①
- Starting gear ②

### 5. Install

- Woodruff key
- Rotor

#### Note

Eliminate foreign materials and the dirt on the rotor, and then fixed it.



### 6. Lock

- Nut



Locking torque  
7.0kgf.m(70 N.m)

#### Note

Fix the rotor with sliding stopping tool ③, lock the rotor ② with the nut with the washer.



Sliding stopping tool

### 7. Install


- Dowel pin
- Gasket **NEW**
- Left case cover



Case cover locking torque  
1.0kgf.m(10 N.m)

#### Note

The left case cover must be installed after the main driving gear lock nut of the right case is installed.




## Piston and piston ring

### 1. Piston installment

- Oil-bearing baffle ②
- Scraper baffle ②
- Second ring ③
- First ring ④

#### Note

- When install the first ring and second ring, dividing top and bottom. The mark toward the top.
- When install the oil ring, the scraper baffle should be installed first ②, and then install the Oil-bearing baffle, finally install the scraper baffle.
- After assembling, make sure that the piston ring can turn smoothly.
- The connecting place among each ring should have 120° of angle difference.




### 2. Install

- Piston ①
- Piston pin ②
- Piston pin circlip ③ **NEW**

#### Note


- The arrow mark (a) must toward the front of engine.
- Before installing the piston pin circlip, the crankcase is covered with clean towel or cloth.



### 3. Install

- Dowel pin ①
- Gasket ② **NEW**


## Cylinder and piston



- ① Cylinder
- ② O-ring
- ③ Gasket
- ④ Dowel pin


- ⑤ Piston ring
- ⑥ Piston pin circlip
- ⑦ Piston
- ⑧ Piston pin

## Cylinder head



- |                         |                            |
|-------------------------|----------------------------|
| ① Bolt                  | ⑦ Cylinder head            |
| ② Copper washer         | ⑧ Dowel pin                |
| ③ Inner hexagon bolt    | ⑨ Steel gasket             |
| ④ Valve cover (intake)  | ⑩ O-ring                   |
| ⑤ O-ring                | ⑪ Cylinder head side cover |
| ⑥ Valve cover (exhaust) | ⑫ spark plug               |


## Cam shaft and dowel pin




- |                              |                               |
|------------------------------|-------------------------------|
| ① Gasket                     | ④ Timing sprocket             |
| ② Tensioner                  | ⑤ Timing chain                |
| ③ Chain guide plate (intake) | ⑥ Chain guide plate (exhaust) |

## Intake and exhaust system

### Carburetor



- |                                     |                   |                      |                 |
|-------------------------------------|-------------------|----------------------|-----------------|
| ① Adjusting screw of throttle cable | ⑭ Carburetor body | ⑳ O-ring             | ㉒ Float unit    |
| ② Rubber cover                      | ⑮ Idle screw      | ㉓ Rubber washer      | ㉑ Float pin     |
| ③ Guide tube of throttle cable      | ⑯ Spring          | ㉔ Washer             | ㉒ Seal shim     |
| ④ Rubber washer.                    | ⑰ Washer          | ㉕ Spring             | ㉓ Floater cover |
| ⑤ Top cover cap                     | ⑱ Rubber washer   | ㉖ Ps adjusting screw | ㉔ Bolt          |
| ⑥ circlip                           | ⑲ Choke lever     | ㉗ Idling fuel jet    | ㉕ Spring        |
| ⑦ Rubber washer                     | ⑳ Wave washer     | ㉘ Main nozzle        | ㉖ O-ring        |
| ⑧ plunger spring                    | ㉑ Screw           | ㉙ Main jet           |                 |
| ⑨ Needle pressure plate             | ㉒ Rubber cap      | ㉚ O-ring             |                 |
| ⑩ Elastic clamp ring                | ㉓ Guide holder    | ㉛ Needle valve seat  |                 |
| ⑪ Needle washer                     | ㉔ Choke valve     | ㉜ Needle valve       |                 |
| ⑫ Fuel needle                       | ㉕ Spring piece    | ㉝ Fixing catch       |                 |
| ⑬ Throttle valve                    | ㉖ Fixed plate     | ㉞ Bolt               |                 |



## Disassemble

### 1. Disassemble

- Guide tube of throttle cable
- Carburetor body


## Disconnect

### 1. Loosen

Drain screw

### 2. Disassemble

- Throttle valve ①




### 3. Disassemble

- Choke lever ①
- Choke valve ②


### 4. Disassemble

- Float chamber




### 5. Disassemble

- Float pin ①
- Floater ②
- Needle valve
- Needle valve seating



#### 6. Disassemble

- Main jet ①
- Main nozzle
- O-ring



#### 7. Disassemble

- Idle fuel jet ②

#### 8. Disassemble

- P.S adjusting screw ①

### Check

#### 1. Check


- Carburetor mixing chamber

Pollution → Clean

#### 2. Check

- Floater

Damage → Replace




#### 3. Check

- Needle valve ①
- Needle valve seating ② O-ring ③

Wear → Replace

### Note

The needle and the needle valve seating must be replaced.



#### 4. Check

- Main nozzle ①
- Main jet ②
- O-ring ③
- Idle fuel jet ④

Pollution → Clean

#### Note


Blow down each jet with compress air.

### Assemble

Assemble them contrary to disassemble steps.

#### Note

Clean all the parts with clean gasoline before assembling once more.



### Adjust fuel level

#### 1. Measurement

- Fuel level (a)



Fuel level (a): 6.6-7.6mm

\*Be should locate the middle position of the float chamber below the edge of carburetor housing.

Out of specification → Adjustment

\*\*\*\*\*

### Measure fuel level and adjusting steps

- Place the motorcycle in the position of level, and made sure that the carburetor maintain in verticality
- Connect the fuel liquidometer ① to the drain oil tube.




Fuel liquidometer

- Loosen drain-hole screw ③, warming the engine for several minutes.
- Maintain the fuel liquidometer in verticality, making it approach the reticle of the float chamber.
- Measure the fuel level with fuel liquidometer

**Note**

The readings on the pipeline of the two sides of the carburetor are equal.


\*\*\*\*\*



2. If the fuel level is not correct, adjusting:

- Disassemble the carburetor
- Check valve seating and needle valve
- If both of them are normal, the floater tail④ should be bended to adjust fuel level.
- Check the fuel level once more.

## Intake, exhaust system




- ① Negative pressure pipe
- ② Wire clip
- ③ Complementary gas valve
- ④ Circlip
- ⑤ Complementary gas 1 pipe
- ⑥ Syphon assy
- ⑦ Washer plate
- ⑧ Muffler assy

- ⑨ Engine assy
- ⑩ wire clip
- ⑪ Exhaust gas cycle tube
- ⑫ Air filter assy
- ⑬ Complementary gas 2 pipe
- ⑭ Bolt M6 × 16
- ⑮ Screw M6 × 16

# **CHAPTER 5**

## **CHASSIS**


## Front wheel



- ① Lock nut
- ② Instrument gears
- ③ Front wheel axle
- ④ Spacer

- ⑤ Front wheel assy
- ⑥ Spacer assy
- ⑦ Front wheel assy

## Front brake



- ① Brake shoes assy
- ② Oil seal
- ③ Speedometer clutch
- ④ Drive gear
- ⑤ Cam shaft lever
- ⑥ Indicator plate

- ⑦ Cam shaft
- ⑧ Spacer
- ⑨ Washer
- ⑩ Meter gear
- ⑪ O-ring
- ⑫ Oil seal

## Removal

### Warning

- Place the machine on a level place
- Place the machine on main stand
- Elevate the front wheels by placing suitable stand under the frame or engine.

#### 1. Disconnect:

- Front brake cable ①

### Note

Be sure to relax the brake before disconnet

#### 2. Remove

- Speedometer cable ②

### Note





Be sure to remove circlip first


#### 3. Remove

- Lock nut ②

#### 4. Remove

- Front wheel axle ①
- Front brake assy ②
- Spacer ③
- Front wheel assy ④





## Inspection

### 1. Inspection:

- Front wheel shaft (check with dial indicator)

Crooked → Replace

#### Warning

Be sure not to straighten the crooked front wheel shaft



Crook limit: 0.25mm


### 2. Inspection:

- Tire

Wear/Damage → Replace

#### Warning

Never try to repair the tire by yourself



### 3. Measure:

- Wheel runout



Rim runout limit:

Vertical: 1.0mm Lateral: 0.5mm

Over specified limit → Replace



### 4. Inspection:


- Wheel bearing

The bearing moving in the hub or rotating unstably

→ Replace

- Oil seal


Wear/Damage → Replace



### Speedometer gear assy

#### 1. Install

- Speedometer cable ①
- Driven gear ②
- Do not crooked the speedometer cable ③




### Instrumentation clutch


#### 1. Inspection

- Instrumentation clutch

Wear/Damage → Replace



- Instrumentation driven gear ①
- Instrumentation meter gear ②



### Front brake

#### 1. Inspection


- Brake shoe lining surface

Smooth side → Grinding

- Sand with coarse sand paper

#### Note

Wipe off the grinding material pellet before sanding



2. Measure:


- Brake shoe lining thickness **a**

|  |                                                               |
|--|---------------------------------------------------------------|
|  | Brake shoe thickness <b>a</b> : 4mm<br>Limited <b>a</b> : 2mm |
|--|---------------------------------------------------------------|

Out off specification → Replace

**Note**

Be sure to replace the whole brake shoes if any one of them is out of specification.




3. Measure

- Brake drum inside diameter **a**

|  |                                                           |
|--|-----------------------------------------------------------|
|  | Brake drum inside diameter:<br>standard:130mm limit:131mm |
|--|-----------------------------------------------------------|

Over specified limit → Replace




4. Inspect:

- Brake drum inner surface

Oil/scratched → Remove

Oil: use a rag soaked in lacquer thinner or a solvent.

Scratched: use a emery cloth (lightly and evenly polishing)




5. Inspect

- Camshaft

Damage → Replace

**Warning**

Install the camshaft and the pivot lightly greased. Wipe off the excess grease.




## Assembly

### 1.Install

- Camshaft ①
- Indicator ②

### Install steps

- When install the wear indicator (b), place its convex part into slot of camshaft (a)
- Aim the needle at the wear indicator.




### 2.Install

- Camshaft rod ①



Install torque: 1.0Kgf.m




### 3.Install

- Brake shoe ①
- Brake shoe spring ②


### Note

- Don't use plier when installing which may cause disshape and damage of hooks and rings of spring.
- Don't grease the brake shoe lining.



### 4. Install

- Instruments driven gear ①
- Speedometer cable ②
- Speedometer cable end ③



5.Install

- Brake assy ①

**Note**

Make the slot face the wear indicator when install brake assy.

Pull and press braked shoe in direction of arrow, making pivot and brake camshaft rod as fulcrum, when installing brake shoe.

## Install

1.Install


- Front brake cable
- Speedometer cable
- Front wheel axle nut

2.Install

- Front wheel

**Note**

The convex seat of the left front shock absorber must bite with the locating slot of gear assy correctly.




3.Cable

- Brake shoe

The brake shoe moving in the hub or rotating unstably  
→ Replace

|  |                         |
|--|-------------------------|
|  | Nut torque: 3.5-5.6Kgfm |
|--|-------------------------|




4.Install

- Speedometer cable
- circlip

Be sure not to flex the speedometer cable


## Rear wheel



- ① Adjusting nut
- ② pin
- ③ Compression spring
- ④ split pin
- ⑤ Tension rod
- ⑥ Lock nut
- ⑦ Chain adjuster assy

- ⑧ Sprocket shaft
- ⑨ Rear wheel
- ⑩ Rear brake
- ⑪ Damper
- ⑫ Oil seal
- ⑬ Spacer
- ⑭ Bearing

## Rear brake





- ① Brake shoes
- ② Camshaft lever

- ③ Indicator plate
- ④ Brake camshaft

## Removal


### Warning

Support the motorcycle firmly to avoid falling over.



1. Remove;

- Adjuster ①
- Tension rod ②
- Nut ③
- Compressing spring ④
- Brake rod ⑤
- Rear wheel shaft nut ⑥




2. Remove

- Rear wheel shaft ①
- Spacer ②

### Note

When removing the wheel shaft, Spacer will drop down. Be careful not to lose it.




3. Remove

- Rear wheel
- Rear brake

### Note

When removing the rear wheel, be care for of the dropping clutch hub.



#### 4.Remove

- Damper

Cracks/Damage → Replace

### Rear wheel hub


#### 1.Inspect

- Brake drum inner surface

Oil/Scratches → Remove

Oil: use a rag soaked in lacquer thinner or a solvent

Scratches: use a emery cloth (lightly and evenly polishing)



#### 2. Measure

- Brake drum inside surface **a**

|                                                                                     |                                                             |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------|
|  | Brake drum inside diameter:<br>Standard: 130mm Limit: 131mm |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------|


Out of specification → Replace

#### 3. Install

- Rear wheel

#### Note


Be sure to engage the convex part of clutch hub with slot of damper




#### 4. Install

- Axle nut

|                                                                                     |                           |
|-------------------------------------------------------------------------------------|---------------------------|
|  | Axle nut :9.1kgf.m(91N.m) |
|-------------------------------------------------------------------------------------|---------------------------|



## Diving chain



- ① Sprocket cover
- ② Slave sprocket
- ③ Link plate
- ④ Chain adapter
- ⑤ Chain connect

- ⑥ Main drive sprocket
- ⑦ Adjuster
- ⑧ Circlip
- ⑨ Stop washer

## Disassembly

### Warning

Stand the motorcycle firmly and avoid turning.

1.Put the motorcycle on the main stand

2.Disassembly:

- Sprocket cover

3.Screwing-down

- Small sprocket


4.Disassembly

- Chain connect snap ring ①

- Link plate ②

- Chain connect

- Driving sprocket




## Inspection

1.Inspection

- The driving chain stuck

Get stuck → Clean and lubricate or replace it




2. Inspection


- Driving chain ①

- driving sprocket ②

The clearance that is pressed to right side must not excess 1/2 of the gear.

Overran → Replace





### 3. Measure

- The length of 10 chain elements **a** (driving chain)




The max length of 10 chain elements:  
119.5mm

Excess the stipulated scope → Replace

#### Note

Stretch the chain with fingers first, then measure the length.

- As shown in the figure, measure the length of 10 chain elements from the internal side of the roller ① to the roller ⑪
- Measure the length of 10 chain elements in different sections two or three times.




### 4. Clear:

- Clean with neutral detergent
- Oiled with lubricant or SAE10W-30W YAMAHA motor oil.

#### Warning

Be sure not to clean with volatile substance, such as gasoline, stream, etc.




### Inspect clutch hub

#### 1. Inspection

- Clutch hub

Wear, chap → Replace



#### 2. Install


- Driving sprocket ①
- Antiloosen washer ② **NEW**
- Nut ③



Nut: 2.6kgf.m(26N.m)

#### Note

Screw up the bolts following the cross curve.




### 3. Install

- Install as the illustration shows
- Stretch the convex tongue of the antiloosen pad straight, screw down the construction bolt, then disassemble the driving sprocket.

## Install

### 1.Install

- Driving chain ①
- Driving chain cutter ②
- Link plate ③



### 2.Assembly

- Chain connect work carrier

#### Note

Pay attention to the assembling direction of the work carrier of the carrier of the chain connect

### 3.Adjustment:

- Loose degree of driving chain

Please refer to the section of loose degree adjustment of driving chain in part III.


#### Note

Overloading of engine and other main parts will occur if the driving chain is too tight. The loose degree of the chain should be kept within the stipulated scope.

### 4. Screwing-up

- Sprocket shaft nut
- Bolt

## Front fork



① Front fender

② Plug

③ Bolt

④ O-ring

⑤ Collar

⑥ Spring seat

⑦ Spring

⑧ Dust-preventative cap

⑨ Circlip

⑩ Bolt

⑪ Washer

⑫ Button valve

⑬ Resistance device

⑭ Inner tube

⑮ Spring


⑯ Oil seal

⑰ Outer tube

## Remove

### Warning


Securely support the machine to avoid falling over.



1. Place the machine on a level place.
2. Elevate the front wheels by placing the suitable stand under the frame and engine.

### 3. Remove

- Front wheel ①
- Front fender ②



### 4. Loose

- Bolt ①
- Cap bolt ②


### Note

Be sure to loose the two bolts of the front fork before remove.


## Dissassemble

### 1. Remove

- Cap bolt and O-ring ①




### 2 Oil-drain



### 3. Disassemble

- Collar ①
- Spring seat ②
- Spring ③




#### 4. Disassemble

- Dust-preventative cap ①
- Circlip ②

#### Note

Be careful not to damage the surface of inner tube




#### 5. Remove

- Bolt ①
- Hold the shock absorber rod, and loosen the bolt shock absorber rod, with “T” spanner ② and shock absorber rod fixture



“T” spanner



#### 6. Remove

- Bolt ①
- Washer ②

#### 7. Remove

- Oil seal

#### Note

Be careful no the scratch the outer tube of front fork when removing oil seal.

## Inspect

#### 1. Inspect:


- Inner tube of front fork




The angularity of inner fork  
Angularity limit: 0.2mm

#### Warning

Don't try to straighten the crooked inner tube of front fork, otherwise will damage the tube seriously.






## 2. Measure

- Free length of front fork spring ①

|                                                                                   |                                                                     |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------|
|  | Free length of front fork spring: 339.9mm<br>Min free length: 330mm |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------|

Out of specification → Replace



## 3. Inspect:

- Resistance device rod ①
- Absorber piston ②

Wear /Cracked /Damage → Replace

- Spring ③
- Button valve ④

Wear/Cracks/Damage → Replace

Dirt → Blow and clean all oil hole with compressed air

### Note

Don't try to straighten crooked resistance device rod, otherwise it will be damaged seriously.

## Assemble


Reverse the “REMOVAL” procedures. Note the following points.

### Note

Be sure to use following components before assembly.

- Oil seal
- Dust-preventative seal part

Ensure the clean state of all components before assemble.



1. Install


- Spring ①
- Absorber piston ②

2. Lubricate:

- Inner tube of front fork (outer surface)




Front fork oil 10w or equal substitute




3. Install

- Resistance device ①
- Button valve ②
- Inner tube of front fork ③
- Outer tube of front fork ④



4. Install

- Washer ① **NEW**
- Bolt (shock absorber rod) ②



5. Tighten:

Bolt (Resistance device rod) ①




Bolt (Resistance device rod):  
2.3kgf.m(23N.m)

**Note**

Lock the shock absorber rod with “T” spanner ① and shock absorber rod fixture ②




“T” spanner:  
Shock absorber rod fixture



6. Install


Oil seal ① **NEW**



7. Install

Circlip ① **NEW**


Outer tube of front fork ②



8. Inspect

- Inner tube extension

Re-inspect if can not extension freely.




9. Inject

- Measuring cup ①



Every front fork tube: 156ml  
10W shock absorber oil

10. Move the front fork up and down slowly after injection to make the oil all over the tube.




11. Install

- Front fork spring ①

**Note**

Make the end with shorter pitch of spring up ward to install the spring.



12. Install
- Cap bolt
  - O-ring

**Note**

Be careful not to damage the outer surface of inner tube.

## Intall



Reverse the “REMOVE” procedure

1. Install
- Front fork ①

Tighten the bolt temporary

**Note**


Be sure to justify the inner tube port and bolt port.



2. Tighten
- Bolt ①
  - Bolt ②
  - Cap bolt ③




Bolt ① :2.8kgf.m(28N.m)  
 Bolt ②: 2.3kgf.m(23N.m)  
 Cap bolt ③: 2.3lbf/(23N.m)




## Steering seat and handlebar

### Circle lock nut




- |                           |                                    |
|---------------------------|------------------------------------|
| ① Handlebar clamp         | ⑨ Dust - preventative cap          |
| ② Handlebar               | ⑩ Steering seat                    |
| ③ Right holder lever assy | ⑪ Upper ball bearing race (upper)  |
| ④ Handlebar seat          | ⑫ Upper Steel ball                 |
| ⑤ Thimble                 | ⑬ Lower steel ball                 |
| ⑥ Ring Nut                | ⑭ Upper ball bearing race (middle) |
| ⑦ Ring washer             | ⑮ Lower ball bearing race          |
| ⑧ Ring nut                |                                    |

# Dust-preventative cap nut




- ① Handlebar clamp
- ② Handlebar
- ③ Right holder lever assy
- ④ Handlebar seat
- ⑤ Dust-preventative cap nut
- ⑥ Steering seat

- ⑦ Upper ball bearing race (upper)
- ⑧ Upper Steel ball
- ⑨ Lower steel ball
- ⑩ Upper ball bearing race (middle)
- ⑪ Lower ball bearing race




## Removal

1. Remove
  - Remove the switch of left and right handle




2. Remove
  - Handlebar clamp
  - Handlebar
  - Handlebar throttle seat

3. Remove
  - Front wheel




4. Remove
  - Front fork



## Ring lock nut

5. Remove
  - Thimble ①
  - Ring nut ②
  - Ring washer ③



6. Remove


- Ring nut ①
- Remove the ring nut with steering nut wrench ②



Steering nut wrench


**Warning**

Never remove the nut with any other instruments except steering nut wrench.



7. Remove

- Ball bearing race cover ①
- Upper ball bearing race (upper) ②
- Steel ball (upper) ③
- Steering seat ④
- Steel ball (lower) ⑤



**Dust-preventative cap lock nut**

5. Remove


- Dust-preventative cap lock nut
- Remove with steering nut wrench



Steering nut wrench


**Warning**

Never remove the nut with any other instruments except steering nut wrench.



6. Remove

- Ball bearing race cover ①
- Upper ball bearing race (upper) ②
- Steering seat ③
- Steel ball (lower) ④



## Inspect

### Inspect handlebar

- handlebar

Bent、Cracks、Damage → Replace

#### Warning

Do not attempt to straighten a bent handlebar, this may weaken the strength of handlebar and cause danger



### Inspect front steering column

1. Clean out the ball bearing race and steel ball

2. Inspect

- Ball bearing race
- Steel ball

Wear、Corrosive pitting、Damage → Replace as a set



\*\*\*\*\*

### Replace step:

- Shown as illustration, the ball bearing race with a long rod and hand hammer, and take it out of the convex slot of frame tube.

- Shown as illustration, remove the ball bearing race of steering of steering seat with plain chisel and hand hammer.


- Install the new dust-preventative seal part, bearing an ball bearing race.

\*\*\*\*\*

#### Note

- Steel ball race and dust-preventative part should be always be replaced as a set.

- The slant ball bearing race may polish the frame. So be careful to install the race in level state, be sure not to strike the surface of ball and race.



## Install

### Steering bar

Reverse the “REMOVAL” procedure

#### 1. Lubrication


- Steel ball (lower, upper)
- Bearing race

|                                                                                   |                      |
|-----------------------------------------------------------------------------------|----------------------|
|  | Lithium based grease |
|-----------------------------------------------------------------------------------|----------------------|

#### 2. Assembly:

- Ring-nut (lower)
- Ring-washer
- Ring-nut (upper)
- Thimble

After assembly, make adjustment according to the steps of Part III.



### Dust-preventative cap lock nut

Reverse the “REMOVAL” procedure

#### 1. Lubrication


- Steel ball
- Bearing race

|                                                                                     |                      |
|-------------------------------------------------------------------------------------|----------------------|
|  | Lithium based grease |
|-------------------------------------------------------------------------------------|----------------------|

#### 2. Install

- Dust-preventative cap lock nut

After assembly, make adjustment according to the steps of Part III.



## Handlebar

### 1. Assembly:



- Handlebar ①
- Handlebar clamp ②



Tighten torque:  
2.3kgf.m(23 N.m)

### Note


- Make sure to flexible the front face bolt
- Make the difference handlebar clamp ② from front to rear to assemble the front face.



### 2. Assembly

Front brake lever ①

Clutch holder lever ②




### 3. Install

- Handlebar switch

Be sure to insert the dowel ② to dowel hole ③.

## Rear shock absorber and rear arm




- ① Rear shock-absorber
- ② Nut
- ③ Rear arm

- ④ Connection rod
- ⑤ Chain cover

## Disassembly


### Warning

Stand the motorcycle firmly avoid turning over.



1. Rear shock absorber
2. Disassembly
  - Left and right and rear shock absorber
3. Disassembly
  - Rear wheel
4. Disassembly
  - Chain
5. Disassembly
  - Nut
  - Connection rod
  - Chain cover
  - Rear arm

## Inspect




1. Inspect
  - The free play of rear arm

If obvious lateral gap is found the internal ferrule should be checked

- Check the free move from upward to downward of rear arm

If the vertical shift is found too tight, clipped or unstable then replace.



2. Inspect
    - Rear shock absorber
- Leakage, deformation → Replace




# **CHAPTER 6**

## **CABLE AND ELECTRIC APPLIANCE SYSTEM**

## Cable /harness wire/tube diagram


### Drum brake with cowling



- |                              |                     |                        |                          |
|------------------------------|---------------------|------------------------|--------------------------|
| ① Clutch cable               | ⑤ Fuel sensor       | ⑨ Fuse                 | ⑬ Overflow pipe          |
| ② Left handlebar switch wire | ⑥ Front brake cable | ⑩ Start electric relay | ⑭ Positive wire          |
| ③ Wire clamp                 | ⑦ Speedometer cable | ⑪ Flasher relay        | ⑮ Harness wire           |
| ④ CDI                        | ⑧ Fuel pipe         | ⑫ Carburetor vent pipe | ⑯ Negative pressure pipe |

- A. The harness wire must pass the wire clamp
- B. The harness wire and various leads must passed through the back hole of front headlight.and connect in the inside front headlight
- C. Tighten the white mark of wire by the frame wire clamp
- D. Insert the carburetor vent pipe in the storage battery box clamp
- E. The starter motor wire must pass through the inner side of battery
- F. Storage battery vent pipe must pass through the inner side of storage battery
- G. Magneto lead and brake switch lead must be fixed in here
- H. The front brake cable and speedometer cable must pass through the guide
- I. Harness wire must pass through this tube

## Drum with cowling




- |                               |                            |                           |
|-------------------------------|----------------------------|---------------------------|
| ① Throttle cable              | ⑦ Carburetor vent pipe     | ⑬ Negative pressure pipe  |
| ② Ignition coil               | ⑧ Exhaust gas cycle tube   | ⑭ Complementary gas pipe1 |
| ③ Ignition coil wire          | ⑨ Carburetor overflow pipe | ⑮ Syphon assy             |
| ④ Clutch cable                | ⑩ Battery vent pipe        | ⑯ Washer                  |
| ⑤ Rear brake switch           | ⑪ Complementary gas pipe 2 |                           |
| ⑥ Rear brake switch lead wire | ⑫ Complementary gas valve  |                           |

A. Tighten the ground wire and ignition coil together.

B. Carburetor overflow pipe and Storage battery vent pipe must pass through between the upside of crankcase and engine support.


C. Clutch cable must pass between the right side of engine cylinder and muffler.

### Drum with cowling




- |                          |                                                                                                 |
|--------------------------|-------------------------------------------------------------------------------------------------|
| ① Left handlebar switch  | A. Trottle cable brake cable and handbar switch lead wire, must pass through the guide frame    |
| ② Clutch switch          | B. Clutch cable, handlebar switch wire and clutch switch wire must pass through the guide frame |
| ③ Front brake switch     | C. Be sure to tighten left handlebar switch and clutch switch wire with shell ring.             |
| ④ Right handlebar switch | D. Be sure to tighten right handlebar and brake switch wire with shell ring.                    |

### Drum with cowling




- |                |                                                                        |
|----------------|------------------------------------------------------------------------|
| ① Clutch cable | A. Speedometer cable and brake cable must pass through the guide frame |
| ② Harness wire |                                                                        |



### Disk brake with cowling

- ① Handlebar switch lead-wire
- ② Front brake switch wire
- ③ Throttle cable
- ④ Throttle cable guide frame
- ⑤ Front brake cable
- ⑥ Front brake cable fixture clamp


A. Connect with horn




- ① Speedometer cable
- ② Cable guide frame
- ③ Harness wire guide frame

A. Tighten the handlebar switch and clutch switch wire

## Disk brake with cowling




- |                      |                                                                                            |
|----------------------|--------------------------------------------------------------------------------------------|
| ① Right flasher wire | A. To front headlight                                                                      |
| ② Left flasher wire  | B. After connect the wire, strap it up with shell ring at this place and cut off the rest. |
|                      | C. Harness wire and cowling cover at this place and cut off the rest.                      |



- |                           |                               |                              |
|---------------------------|-------------------------------|------------------------------|
| ① Front brake switch wire | ④ Throttle cable              | ⑦ Clutch switch wire         |
| ② Brake cable             | ⑤ Right handlebar switch wire | ⑧ Left handlebar switch wire |
| ③ Right flasher wire      | ⑥ Left flasher wire           | ⑨ Clutch cable               |

## Drum without cowling



- |                              |                     |                            |
|------------------------------|---------------------|----------------------------|
| ① Clutch cable               | ⑥ Front brake cable | ⑪ Flasher relay            |
| ② Left handlebar switch wire | ⑦ Speedometer cable | ⑫ Carburetor vent pipe     |
| ③ Wire clamp                 | ⑧ Fuel pipe         | ⑬ Carburetor overflow pipe |
| ④ CDI                        | ⑨ Fuse              | ⑭ Positive wire            |
| ⑤ Fuel sensor                | ⑩ Starter relay     | ⑮ Harness wire             |

A. The harness must pass the wire clamp

B. Harness wire and various leads must be passed through the back hole of front light, and connect in the inside front headlight

C. Tighten the white mark of wire by the frame wire clamp

D. Insert the carburetor vent pipe in the storage battery box clamp


E. The starting motor lead must pass through the inner side of storage battery

F. Storage battery vent pipe must pass through the inner side of storage battery

G. Magneto lead and brake switch lead must be fixed in here

H. Brake cable and speedometer cable must pass through the guide

## Drum without cowling




- |                      |                                |
|----------------------|--------------------------------|
| ① Throttle cable     | ⑥ Rear brake switch lead wire  |
| ② Ignition coil      | ⑦ Carburetor vent pipe         |
| ③ Ignition coil wire | ⑧ Exhaust gas circulation pipe |
| ④ Clutch cable       | ⑨ Carburetor overflow pipe     |
| ⑤ Rear brake switch  | ⑩ Storage battery vent pipe    |

A. Tighten the ground wire and ignition coil together.


B. Carburetor overflow pipe and Storage battery vent pipe must pass through between the upside of crankcase and engine support.

### Drum without cowling




- |                          |                                                                                                                   |
|--------------------------|-------------------------------------------------------------------------------------------------------------------|
| ① Left handlebar switch  | A. Throttle cable ,brake cable and brake switch lead wire,handlebar switch wire must pass through the guide frame |
| ② Clutch switch          | B. Clutch cable, handlebar switch wire and clutch switch wire must pass through the guide frame                   |
| ③ Front brake switch     | C. Be sure to tighten left handlebar switch and clutch switch wire with shell ring.                               |
| ④ Right handlebar switch | D. Be sure to tighten right handlebar and brake switch wire with shell ring.                                      |

### Drum without cowling




- |                |                                                                        |
|----------------|------------------------------------------------------------------------|
| ① Clutch cable | A. Speedometer cable and brake cable must pass through the guide frame |
| ② Harness wire |                                                                        |

## Electric device principle




## Electric appliance






## Components of electric appliance



- ① Storage battery
- ② Rear brake switch
- ③ Starting relay
- ④ safety assy

- ⑤ Rectifier regulator
- ⑥ Oil sensor
- ⑦ Key sets
- ⑧ Harness wire

## Components of electric appliance



① Ignition coil


② Spark plug cap

③ Shift switch

④ Flasher relay

⑤ CDI

⑥ Horn




### Socket connector inspection

Clean away the dirt, rust and moisture on the socket connectors

1. Disconnect:

- Socket connectors


2. Dry every binding post with bowing device



3. Connect and disconnect every socket connector 2~3 times

4. Stretch the wires to check if the wire is disconnected.


5. If the binding post is drawn out, the pin should be cranked. Insert the binding post into the socket connectors.



6. Connection


- Socket connectors

7. Check if the socket connectors are powered on with a multimeter.



#### Note

- If the circuit is found not powered, then clean the binding poles.
- Repeat the inspection noted in the above 1~7 procedures after check the wires.
- Do inspect the socket connectors after replacing the CDI device.
- Check the socket connectors with a multimeter as shown in the figure.



### Switch inspection

Inspect if the circuit between wire end is on with pocket multi meter.


If there is any failure, replace the switch.



Pocket tester

#### Note

- Should turn on and off the switch many times when inspecting.
- Adjust the multi meter to inspecting
- Adjust the multi meter to O before when inspecting the circuit



The manual explains how to inspect the switch, The left figure indicate the wire and position of switch. The vertical line indicates switch position. The first row indicates color of switch wire. To every switch O-O indicates the circuit between the wire ends is on. When the switch is adjusted to on the “red” and “brown” wire are on.

The diagram illustrates the electrical system of a motorcycle. Key components and their terminal connections are as follows:

- Main switch:** A switch with terminals labeled OFF, ON, Br, and R.
- Spark:** A spark plug with terminals labeled Br and R.
- Ignition coil:** A coil with terminals labeled Or and Br.
- CDI (Capacitor Discharge Ignition):** A box with terminals labeled R, L/Y, Or, W, B, and Br.
- Magneto:** A circular component with terminals labeled Sb, W, and R.
- Rectifier regulator:** A box with terminals labeled R, Br, B, W, Br, W, R, and B.
- Battery:** A battery symbol with a terminal labeled Fuse.

The wiring connections are as follows:

- The **Br** terminal of the Main switch is connected to the **Br** terminal of the Spark plug.
- The **R** terminal of the Main switch is connected to the **R** terminal of the CDI.
- The **Or** terminal of the Ignition coil is connected to the **Or** terminal of the CDI.
- The **Br** terminal of the CDI is connected to the **Br** terminal of the Rectifier regulator.
- The **R** terminal of the CDI is connected to the **R** terminal of the Rectifier regulator.
- The **W** terminal of the CDI is connected to the **W** terminal of the Rectifier regulator.
- The **B** terminal of the CDI is connected to the **B** terminal of the Rectifier regulator.
- The **L/Y** terminal of the CDI is connected to the **L/Y** terminal of the Rectifier regulator.
- The **Sb** terminal of the Magneto is connected to the **Sb** terminal of the Rectifier regulator.
- The **W** terminal of the Magneto is connected to the **W** terminal of the Rectifier regulator.
- The **R** terminal of the Magneto is connected to the **R** terminal of the Rectifier regulator.
- The **Fuse** terminal of the Battery is connected to the **Fuse** terminal of the Rectifier regulator.

## Fault obvation

Ignition system inefficiency  
(no spark or interrupted spark)

### Check steps


1. Spark plug
2. Check the spark
3. Spark plug cap resistance
4. Ignition wire
5. Pulse wire resistance
6. Ignition charging resistance
7. Main switch
8. Ignition system circuit

### Note

The following components should be disassembled before all fault is obviated

- ① Side cover ② Seat cushion ③ Fuel tank

The following special tools should be used to obviate the fault





**3. Spark plug cap resistance**

Disassemble the cap of the spark plug  
Connect a small-size( $\Omega \times 1K$ ) to the spark plug cap

**Note**  
Do not pull off the spark plug from the high tension wire  
Disassemble in an anticlockwise way  
Install in a clockwise way  
Before assemble the spark plug cap, check the high-tension wire firstly.  
Cut off 5mm of high-tension wire before assembly.

Multimeter $\oplus$  lead  $\rightarrow$  Side of spark plug ①  
Multimeter $\ominus$  lead  $\rightarrow$  High tension wire ②

 Spark plug cap resistance:  
 $5K \Omega \pm 20\% (20^{\circ}C)$



**4. Ignition coil first resistance**

Disassemble the wire of the coil away from the wire harness.  
Connect a small-size( $\Omega \times 1K$ ) to the spark plug cap  
AC.CDI Ignition

 primary coil resistance:  
 $0.3 \Omega \pm 10\% (20^{\circ}C)$



Out of stipulation  
The spark plug cap is faulty and should be replace.

Multimeter $\oplus$  lead  $\rightarrow$  Orange spark plug wire ①  
Multimeter $\ominus$  lead  $\rightarrow$  Ground wire ②

### 5. Ignition coil secondary resistance

Disassemble the wire of the coil away from the wire harness.


Connect a small-size( $\Omega \times 1K$ ) to the spark plug cap  
AC.CDI Ignition



primary coil resistance:  
 $3.16K \Omega \pm 10\% (20^{\circ}C)$

Check if the resistance of  
two coils work normally

Multimeter  $\oplus$  lead  $\rightarrow$  Orange spark plug wire  
Multimeter  $\ominus$  lead  $\rightarrow$  Ground wire



Abnormal


The ignition coil is faulty and should be replaced.

### 6. Source coil resistance

- Disassemble the socket connector of source coil and ignitor away from the wire.
- Connect the small-size multimeter( $\Omega \times 1000$ ) to the socket connector of source coil, and the ignition coil.

Multimeter  $\oplus$  lead  $\rightarrow$  red

Multimeter  $\ominus$  lead  $\rightarrow$  white




Regulation resistance:  
 $310K \Omega \pm 20\% (20^{\circ}C)$

Out of stipulation

Replace Source coil

## Electric start system



## Troubleshooting

### Starter motor doesn't run

#### Inspection steps

- |                    |                   |
|--------------------|-------------------|
| 1. Storage battery | 5. Starter relay  |
| 2. Fuse            | 6. Starter switch |
| 3. Starter motor   | 7. Neutral switch |
| 4. Main switch     | 8. Clutch switch  |

#### Note

The following parts should be disassembled before troubleshooting

- ① Side cover    ② Seat

The following special tools should be used to troubleshoot



Small-size multimeter

#### 1. Protecting Device

- Disassemble the protecting device
- Connect a small size multimeter ( $\Omega \times 1$ ) to the protecting pipe
- Check if the protecting pipe is powered on

No electrification

The fuse has blown

electrification

#### 2. Storage battery

- Check the storage battery condition
- Please refer to the part III of "Storage battery"


Abnormal

Voltage: 12.5V

Specific gravity of electrolyte: 1.280, 20°C

- Refill distilled water
- Clear the binding pole of storage battery
- Charge the battery or replace it

Normal




**Warning**

The cross-bond should have an equal or more capacity than the wire of the storage battery, otherwise the cross-bond will be fused.

Error spark may occur in the inspection, inflame gas or liquid should be kept away from the around area.

Faulty

The starter motor is faulty and should be checked or replaced.




Faulty work

The starter relay is fault and should be replaced

### 5. Main switch

- Disassemble the socket connectors of the main switch away from the wire harness.
- Check if the switch can connect to “Red / Brown ”





Normal

Abnormal

The main switch is faulty, and should be replaced.

### 6. Neutral switch

Disassemble the socket connectors of the neutral switch away from the lead wire.  
Check if the switch can connect to “light blue ① / ground wire”.



Normal



Abnormal

The neutral switch is faulty, and should be replaced.

### 7. Clutch switch

Disassemble the socket connectors of the clutch switch away from the lead wire.

Check if the switch can connect to “red black ① / black ②”.



Normal

Abnormal

The clutch switch is faulty, and should be replaced.


### 8. Wire connection condition

Please refer to the section of “Electric circuit”.

Poor connection


Adjust or replace.

## Starting motor



- ① Starting motor assy
- ② Rear bracket
- ③ Brush spring
- ④ Brush assy
- ⑤ O-ring

- ⑥ Magnetic yoke
- ⑦ Armature
- ⑧ Adjusting washer
- ⑨ Front bracket
- ⑩ O-ring



### Remove

#### 1.Remove

- Starting motor wire
- Starting motor assy

### Discharge


1.Before discharge, sign some marks on the front and rear brockets, so that it can easy to check.

#### 2.Remove

- Front brocket
- Washer
- Rear brocket

#### 3.Remove

- Armature
- magnetic yoke
- Brush



### Inspection and repairment

#### 1. Check:

- Commutator

Dirt → Polish with 600# sand paper

#### 2. Measure:

- Diameter of commutator <sup>(a)</sup>



Wear limit of commutator: 21mm

Out of specification → Replace starting motor

#### 3. Measure:

- Depth of mica sheet undercut<sup>(a)</sup>




Depth of mica sheet undercut:  
1.5mm

Out of specification → Repair mica sheet with hand-saw blade to make meet specification.

### Note

In order to ensure the normal work of commutator , the isolation mica sheet of commutator must have undercut.



#### 4. Check

- Armature coil (insulation/continuity)

Defects → Replace starting motor

\*\*\*\*\*

#### Inspection steps:

Connect the pocket tester for the continuity checking

① and insulation checking ②

Measure the armature resistance.



Armature coil resistance:

Continuity checking ①


0.017~0.021 Ω 20°C

Insulation checking ②

More than: 1M Ω 20°C

If the resistance is incorrect, replace the starting motor.

\*\*\*\*\*



#### 5. Measure:

- Brush length ①




Brush length limit value: 3.5mm

Out of specification → Replace the brush

#### Note

When replacing brush, pay attention to its side which swentched




#### 6. Measure

- Brush spring force



Brush spring force: 560~840g

Fatigue / Out of specification → Replace as a set.



## Mount

Mount as the reserves steps as “remove”

1. Mount:

- Brush spring ①
- Brush ②

### Note

- When mounting brush the brush wire should round over the projection outside of brush spring clip.
- When mounting brush, make the brush terminal touch slightly the projection of brush spring clip side.

2. Mount

Armature ①

### Note

When mounting the armature, press the brush with small screwdriver to avoid damaging it.

3. Install

- O-ring

### Note

Replace a new one.

4. Install

- Magnetic yoke

### Note


Aimed the marks to the rear brocket' s matching mark and then install.

5. Install

- Washer
- Front brocket

### Note

- Aimed the boss of washer to the groove of front brocket, and then install.
- Make the marks of gear and front and rear brockets matching.




|                                                                                     |                         |
|-------------------------------------------------------------------------------------|-------------------------|
|  | Bolt:<br>0.5Kgf.m(5N.m) |
|-------------------------------------------------------------------------------------|-------------------------|

## Install

- Starting motor
- Starting motor wire

|                                                                                     |                         |
|-------------------------------------------------------------------------------------|-------------------------|
|  | Bolt:<br>0.7Kgf.m(7N.m) |
|-------------------------------------------------------------------------------------|-------------------------|

## Charging system



## Troubleshooting

The battery is not charged

- |                     |                               |
|---------------------|-------------------------------|
| 1. Fuse             | 4. Light switch               |
| 2. Stratage battery | 5. high and lower beam switch |
| 3. Main switch      |                               |

### Note

Before troubleshooting, the following components should be taken off

- ① Side cover ② Seats

When troubleshooting, the following special tool should be used.



Pocket tester

1. Fuse

Check if the fuse tube is electrified.

No continuity

The fuse tube is broken, replace it.

continuity

2. Battery

Check the battery condition.

Voltage: 12.5V


Electrolyte specific gravity:

1.280 20°C


Abnormal

Normal

Replenish distilled water  
Clean battery terminal  
Charge or replace battery



## Lighting system



## Troubleshooting

The headlamp, indicator light, tail lamp and /pr instrument lamp fail to come on

### Note


Remove the following parts before troubleshooting


① Side cover    ② Seats    ③ Front light cover

Use the following special tools for troubleshooting:




Pocket tester







## Lighting system check

1. If the headlamp and “high beam” indicator lamp fail to come on.




2. The instrument lamp fails to come on





## Signal system



## The troubleshooting

Flasher, brake lamp / or indicator lamp fail to come on. The horn doesn't work

Check steps:

1. Fuse

2. Battery

3. Main switch

4. Wiring connection

### Note

Discharge the following parts before troubleshooting

① Side cover    ② Seats

Use the following special tools for trouble shooting:



Pocket tester

1. Fuse

Tale off the fuse

Check the fuse tuber (  $\Omega \times 1$  ) to the fuse tube for

continuity

No continuity

The fuse tube is broken replace it.

2. Battery

Check the battery condition

Eletrolyte specific gravity: 1.280 20°C

Correct

Incorrect

Replenish distilled water  
Clean battery terminal  
Charge or replace it

3. Main switch

Discharge the main switch coupler form wire harness

Check the continuity between “red and brown” on  
main switch

Correct

Incorrect

The main switch is failure, replace it

4. Wiring connections

Check the entire signal system coupler

Refer to “Circuit Diagram” section

Correct


Poor connection

Repair it


Check each circuit condition of signal system  
Refer to “signal system check” section.

## Inspection of signal system

### 1. The horn doesn't work



## 2. The brake lamp fails to come on



3. Turn lamp / or “Turn signal lamp” indicator fails to come on

1. Bulb and bulb socket

Check the bulb and the bulb socket for continuity

No continuity

Replace bulb / or bulb socket

Continuity

2. Flasher switch

Discharge handlebar switch (left) coupler from wire harness. Check the continuity between “brown/white and dark green” and “brown/white and dark brown” on the switch.

Incorrect

“Turn signal lamp” switch is failure, replace the handlebar switch (left).

Continuity

3. Voltage

Connect the pocket tester (DC20V) to the flashing relay.

Tester ⊕ lead → Brown terminal

Tester ⊖ lead → Ground wire of frame.

Turn the main switch to “ON”

Check the voltage (12V) of “black” terminal on flashing relay terminal

Out of specification

The circuit from the main switch to the flashing relay terminal is poor, repair it.

Meets specification

4. Flashing relay

Connect the pocket tester (DC 20V) to the bulb socket coupler. The connection of right turn lamp:

Tester ⊕ lead → Brown / white terminal

Tester ⊖ lead → Ground wire of frame

Turn the main switch to “ON”. Turn the “Turn signal lamp” switch to “L” or “R”. Check the voltage (12V) of brown / white terminal


Out of specification

Replace flashing relay

Pocket tester connecting the flasher relay

Tester ⊕ lead → Black terminal

Tester ⊖ lead → Ground wire of frame



#### 5. Turn lamp indicator

Connect the pocket tester (DC 20V) to the bulb socket coupler.

The connection of left turn lamp:

Tester ⊕ lead → Dark Brown terminal

Tester ⊖ lead → Ground wire of frame

The connection of right turn lamp:


Tester ⊕ lead → Dark green terminal

Tester ⊖ lead → Ground wire of frame

Turn the main switch to “ON”

Turn the “Turn signal lamp” switch to “L” or “R”

Check the voltage (12V) of dark brown /dark green terminal



Meets specification

Signal system is correct

Out of specification

#### 6. Wire terminal

Check weather the return wire meets broken.

Refer to the signal system return connection.

#### 4. Shift indicator fails to come on

##### 1. Bulb and bulb socket

Check the bulb and bulb socket for continuity

No continuity

Replace the bulb / or bulb socket

continuity

##### 2. Neutral switch


Discharge the neutral switch coupler from the wire neutral.

Check the continuity between“ light blue and ground wire” on the shift switch.



Incorrect


If the neutral switch is failure, replace it

Normal



#### 5. Fuel gauge needle fails to work









# **CHAPTER 7**

## **TROUBLESHOOTING**


## Electric Appliance System



## Compression System



## Intake \ Exhaust System





***JS*** 125-6B

