

OWNER'S MANUAL 2009

690 ENDURO EU

690 ENDURO AUS/UK

ART. NO. 3211357en



KTM

DEAR KTM CUSTOMER

1

Congratulations on your decision to buy a KTM motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it accordingly.

We wish you great pleasure riding the vehicle!

Enter the serial numbers of your vehicle below.

Chassis number (☛ p. 16)	Dealer's stamp
Engine number (☛ p. 17)	
Key number (☛ p. 17)	

The owner's manual corresponded to the latest state of this series at the time of printing. Slight deviations resulting from continuing development and design of our motorcycles cannot however be completely excluded.

All specifications are non-binding. KTM Sportmotorcycle AG specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

DEAR KTM CUSTOMER

2

© 2008 by KTM-Sportmotorcycle AG, Mattighofen Austria

All rights reserved

Reproduction, even in part, is permitted only with the express written permission of the copyright owner.



REG.NO. 12 100 6061

ISO 9001(12 100 6061)

According to the international quality management standard ISO 9001, KTM uses quality assurance processes that lead to the maximum possible quality of the products.

Issued by: TÜV Management Service

KTM-Sportmotorcycle AG
5230 Mattighofen, Austria

CONTENTS

3

MEANS OF REPRESENTATION	6	Setting the clock	27
IMPORTANT NOTES	7	Combination instrument - display ODO	28
VIEW OF VEHICLE	12	Combination instrument - setting/resetting TRIP 1	28
View of vehicle, front left side	12	Combination instrument - setting/resetting TRIP 2	29
View of vehicle, rear right	14	Combination instrument - TRIP F display	30
LOCATION OF SERIAL NUMBERS	16	Combination instrument - coolant temperature indicator	30
Chassis number	16	Opening filler cap	31
Type label	16	Closing filler cap	31
Key number	17	Handrails	32
Engine number	17	Seat release	32
Fork part number	18	Passenger footrests	33
Shock absorber part number	18	Shift lever	33
CONTROLS	19	Foot brake pedal	34
Clutch lever	19	Side stand	35
Hand brake lever	19	GENERAL TIPS AND HINTS ON PUTTING INTO	
Light switch	20	OPERATION	36
Flasher switch	20	Advice on first use	36
Horn button	21	Running in the engine	37
Emergency OFF switch	21	Loading the vehicle	38
Electric starter button	22	RIDING INSTRUCTIONS	40
Ignition/steering lock	22	Checks before putting into operation	40
Combination instrument	23	Starting	41
Combination instrument - function buttons	23	Starting up	43
Combination instrument - tachometer	24	Shifting, riding	43
Combination instrument - control lamps	24	Braking	46
Combination instrument - Display	25	Stopping, parking	47
Combination instrument - speedometer	26	Refueling	49
Setting kilometers or miles	26		
Combination instrument - time	27		

CONTENTS

4

SERVICE SCHEDULE.....	51	Checking rear sprocket / engine sprocket for wear.....	72
Important maintenance work to be carried out by an authorized KTM workshop.	51	Checking chain wear.....	73
Important maintenance work to be carried out by an authorized KTM workshop. (as additional order).....	53	Adjusting chain guide 🛠️.....	74
MAINTENANCE WORK ON CHASSIS AND ENGINE.....	55	Checking brake discs.....	74
Jacking up the motorcycle.....	55	Checking free play of hand brake lever.....	75
Removing the motorcycle from the work stand.....	55	Adjusting free travel of handbrake lever.....	76
Fork/shock absorber.....	56	Checking the front brake fluid level.....	77
Adjusting the compression damping of the fork.....	56	Adding front brake fluid 🛠️.....	77
Adjusting the rebound damping of the fork.....	57	Checking the front brake linings.....	79
Compression damping of the shock absorber.....	58	Changing the front brake linings 🛠️.....	80
Adjusting the low-speed compression damping of the shock absorber.....	58	Checking free play of foot brake lever.....	83
Adjusting the high-speed compression damping of the shock absorber.....	60	Adjusting basic position of foot brake pedal 🛠️.....	84
Adjusting the rebound damping of the shock absorber.....	61	Checking rear brake fluid level.....	85
Bleeding fork legs.....	62	Adding rear brake fluid 🛠️.....	85
Cleaning the dust boots of the fork legs.....	63	Checking the rear brake linings.....	87
Loosening the fork protection.....	64	Changing the rear brake linings 🛠️.....	87
Positioning the fork protection.....	64	Removing the front wheel 🛠️.....	90
Checking play of steering head bearing 🛠️.....	65	Installing the front wheel 🛠️.....	92
Adjusting play of steering head bearing 🛠️.....	66	Removing rear wheel 🛠️.....	93
Handlebar position.....	67	Installing the rear wheel 🛠️.....	94
Adjusting handlebar position 🛠️.....	67	Checking the rear hub rubber dampers 🛠️.....	95
Checking chain dirt.....	68	Checking the tire condition.....	96
Cleaning the chain.....	68	Checking tire air pressure.....	98
Checking the chain tension.....	69	Checking spoke tension.....	99
Adjusting the chain tension.....	70	Removing the seat.....	100
		Mounting the seat.....	101
		Removing the battery 🛠️.....	101
		Installing the battery 🛠️.....	102

CONTENTS

5

Recharging the battery 	103	Installing the oil filter 	135
Changing the main fuse	105	Cleaning the oil screens 	135
Changing the fuses of power consumers.....	107	Filling up with engine oil 	137
Adjusting the engine characteristic.....	109	Topping up engine oil	138
Removing the headlight mask with the headlight	111	TROUBLESHOOTING.....	140
Refitting the headlight mask with the headlight.....	112	FLASHING CODE	143
Changing the headlight bulb.....	113	CLEANING.....	148
Changing the parking light bulb	114	Cleaning motorcycle	148
Changing the flasher bulb	115	CONSERVING FOR WINTER OPERATION	150
Checking headlamp setting.....	116	Conservation for winter operation	150
Adjusting the headlight range	117	STORAGE	151
Removing the air filter 	117	Storage.....	151
Installing the air filter 	118	Putting into operation after storage	152
Cooling system	119	TECHNICAL DATA - ENGINE	153
Checking the antifreeze and coolant level	120	Capacity- engine oil	154
Checking the coolant level.....	122	Capacity - coolant.....	154
Draining the coolant 	124	TECHNICAL DATA - ENGINE TIGHTENING TORQUES.....	155
Filling the cooling system 	125	TECHNICAL DATA - CHASSIS	158
Adjusting basic position of clutch lever.....	127	Lighting equipment	159
Checking/rectifying the fluid level of the hydraulic clutch ...	127	Capacity - fuel.....	160
Checking play in gas Bowden cable	128	TECHNICAL DATA - FORK.....	161
Adjusting the play in the gas Bowden cable 	129	TECHNICAL DATA - SHOCK ABSORBER	162
Removing the engine guard	130	TECHNICAL DATA - CHASSIS TIGHTENING TORQUES	164
Installing the engine guard	130	SUBSTANCES.....	167
Checking engine oil level.....	131	AUXILIARY SUBSTANCES.....	171
Changing the engine oil and filter, cleaning the oil screens 	131	STANDARDS.....	173
Draining the engine oil 	132	INDEX	174
Removing the oil filter 	133		

MEANS OF REPRESENTATION

6

Symbols used

The meaning of specific symbols is described below.



Indicates an expected reaction (e.g. of a work step or a function).



Indicates an unexpected reaction (e.g. of a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. In the interest of your own safety, have these jobs done in an authorized KTM workshop! There, your motorcycle will be serviced optimally by specially trained experts using the specialist tools required.



Identifies a page reference (more information is provided on the specified page).

Formats used

The typographical and other formats used are explained in the following.

Specific name	Identifies a proprietary name.
----------------------	--------------------------------

Name®	Identifies a protected name.
--------------	------------------------------

Brand™	Identifies a trademark.
---------------	-------------------------

IMPORTANT NOTES

7

Use definition

KTM sport motorcycles are designed and constructed to meet the normal demands of regular road and light offroad operation (dirt roads), but not for use on race courses.



Info

The motorcycle is authorized for public road traffic in the homologous version only.

Maintenance

A prerequisite for perfect operation and prevention of wear is that the engine and chassis maintenance and adjustment work described in the owner's manual are properly carried out. Poor adjustment and tuning of the engine and chassis can lead to damage and breakage of components.

Using the motorcycle in extreme conditions such as very muddy or wet roads can lead to above-average wear of components such as the transmission train or the brakes. For this reason, it may be necessary to service or replace worn parts before the limit specified in the service schedule is reached.

Pay careful attention to the prescribed running-in period, inspection and maintenance intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

Warranty

The work prescribed in the service plan must only be carried out in an authorized KTM workshop and confirmed in the service record; otherwise all warranty claims will be disregarded. No warranty claim can be met for damage resulting from manipulation and/or other changes to the vehicle.

Fuel, oils, etc.

You should use the fuels, oils and greases according to specifications as listed in the owner's manual.

IMPORTANT NOTES

8

Spare parts, accessories

In the interests of your own safety, use only spare parts and accessories approved and/or recommended by KTM, and have these fitted in an authorized KTM workshop. KTM accepts no liability for other products and any resulting damage.

The current **KTM PowerParts** for your vehicle can be found on the KTM website.
International KTM Website: <http://www.ktm.com>

Work rules

During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.

If a thread lock (e.g. **Loctite®**) is used for screw connections, be sure to comply with the manufacturer's specific advice on its usage. Parts that you want to reuse following repairs and servicing should be cleaned and checked for damage and wear. Change damaged or worn parts.

Following repairs or servicing, the vehicle must be checked for roadworthiness.

Transport

Note

Danger of damage The parked vehicle can roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components get very hot when the machine is driven.

- Do not place the vehicle where there are flammable or explosive substances. Do not place objects over the vehicle while it is still warm from being run. Always let the vehicle cool first.

- Switch off the engine and remove the ignition key.
- Use straps or other suitable devices to secure the motorcycle against accidents or falling over.

IMPORTANT NOTES

9

Environment

Offroad motorcycling is a wonderful sport and we naturally hope that you will be able to enjoy it to the fullest. However, it is a potential problem for the environment and can lead to conflicts with other persons. But if you use your motorcycle responsibly, you can ensure that such problems and conflicts do not have to occur. To protect the future of motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

Notes/warnings

Pay close attention to the notes/warning.



Info

Various information and warning labels are affixed to the vehicle. Do not remove information/warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

IMPORTANT NOTES

10

Grades of risks



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that will possibly lead to light injury if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Warning

Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

Owner's manual

- It is important that you read this owner's manual carefully and completely before making your first trip. It contains useful information and tips to help you operate and handle your motorcycle. Only then will you find out how to customize the motorcycle ideally for your own use and how you can protect yourself from injury. The owner's manual also contains important information on servicing the motorcycle.
- The owner's manual is an important component of the motorcycle and should be handed over to the new owner if the vehicle is sold.

VIEW OF VEHICLE

12

View of vehicle, front left side



800070-10

VIEW OF VEHICLE

13

1	Hand brake lever
2	Clutch lever
3	Handrail
4	Filler cap
5	Seat
6	Front brake caliper
7	Shift lever
8	Engine number
9	Side stand
10	Footrest
11	Seat release strap

VIEW OF VEHICLE

14

View of vehicle, rear right



800071-10

VIEW OF VEHICLE


15

1	Ignition/steering lock
2	Rear mirror
3	Light switch, flasher switch, horn button
4	Combination instrument
5	Emergency OFF switch, electric starter button
6	Throttle grip
7	Chassis number
8	Brake caliper, rear
9	Passenger footrest
10	Shock absorber, rebound damping
11	Foot brake pedal
12	Level viewer, engine oil

LOCATION OF SERIAL NUMBERS


16

Chassis number



The chassis number ❶ is stamped on the steering head on the right.

Type label



Type label ❶ is located on the upper right frame tube below the seat.

LOCATION OF SERIAL NUMBERS

17

Key number



100179-10


The key number ❶ can be found on the **KEYCODECARD**.



Info

You need the key number to order a spare key. Keep the **KEYCODECARD** in a safe place.

Engine number




100211-10

The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

LOCATION OF SERIAL NUMBERS

18

Fork part number




The fork part number ❶ is stamped on the inner side of the fork stub.

Shock absorber part number




The shock absorber part number ❶ is on the right of the shock absorber.

Clutch lever



The clutch lever ❶ is fitted on the left side of the handlebar.
The clutch is hydraulically operated and self-adjusting.

Hand brake lever



The hand break lever ❶ is fitted on the right side of the handlebar.
The hand brake lever operates the front brake.

Light switch




The light switch ❶ is fitted on the left side of the handlebar.

Possible states

	Low beam on – Light switch is turned downwards. In this position, the low beam and tail light are switched on.
	High beam on – Light switch is turned upwards. In this position, the high beam and the tail light are switched on.

Flasher switch




The flasher switch ❶ is fitted on the left side of the handlebar.

Possible states

	Flasher light off
	Flasher light, left, on – Flasher switch pressed to the right. The flasher switch returns automatically to the central position after use.
	Flasher light, right, on – Flasher switch pressed to the left. The flasher switch returns automatically to the central position after use.

To switch off the flasher light, press the flasher switch towards the switch case.

Horn button



The horn button ❶ is fitted on the left side of the handlebar.

Possible states

- Horn button ❶ in neutral position
- Horn button ❶ pressed – The horn is operated in this position.

Emergency OFF switch



The emergency OFF switch ❶ is fitted on the left side of the handlebar.

Possible states

	Emergency OFF switch off – In this position, the ignition circuit is interrupted, a running engine stops, and the engine cannot be started.
	Emergency OFF switch on – This position is necessary for operation as the ignition circuit is closed.

Electric starter button




The electric starter button ❶ is fitted on the right side of the handlebar.

Possible states



- Electric starter button ❸ in basic position
- Electric starter button ❸ pressed – In this position, the electric starter is actuated.

Ignition/steering lock




The ignition/steering lock ❶ is in front of the upper triple clamp.

Possible states

	Ignition OFF – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start. The ignition key can be removed.
	Ignition ON – In this position, the ignition circuit is closed and the engine can be started.
	Steering locked – In this position, the ignition circuit is broken and the steering locked. The ignition key can be removed.


Combination instrument



The combination instrument is installed in front of the handlebar. The combination instrument is divided into 4 function areas.

- 1 Function buttons
- 2 Tachometer
- 3 Indicator lights
- 4 Display

Combination instrument - function buttons




You can change the display mode with the **MODE** button 1.

Possible display modes are distance traveled (**ODO**), trip master 1 (**TRIP 1**) and trip master 2 (**TRIP 2**).

Press the **SET** button 2 to reset the trip master 1 function (**TRIP 1**) and trip master 2 function (**TRIP 2**) to **0.0**.


Button 3 has no function.

Combination instrument - tachometer



The tachometer ❶ shows the engine speed in revolutions per minute.
The red marking ❷ shows the excess speed range of the engine.

Combination instrument - control lamps




The control lamps offer additional information about the operating state of the motorcycle.

Possible states


	The flasher control lamp flashes green simultaneously with the flashers – Flasher light is switched on.
	The idle speed indicator lamp lights up green – The transmission is switched to idle.
	High beam indicator lamp lights up blue – High beam is switched on.
	Temperature warning lamp shows red – Coolant has reached a critical value.
	Fuel level warning lamp shows orange – Fuel level has reached the reserve mark. Display switched to TRIP F .

	FI warning lamp (MIL) lights/flashes orange – The OBD has detected an emission- or safety-critical fault.
	Battery warning lamp shows red – Voltage in vehicle system too low.

Combination instrument - Display



When you switch on the ignition, all display segments light up for a second as a function test.




LEnGth
Following the display function test, the wheel circumference **LEnGth** is shown for one second.



Info
2205 mm equals the circumference of the 21" front wheel with a series production tire.

The display then changes to the last selected mode.

Combination instrument - speedometer



The speed ❶ is shown in kilometers per hour **km/h** or in miles per hour **Mph**.

Setting kilometers or miles




Info

If you change the unit, the value **ODO** is retained and converted accordingly.
Making the setting according to the country.

Condition

The motorcycle is standing.




- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **MODE** button repeatedly until the **ODO** mode is active.
- Keep the **MODE** button pressed until the display mode changes from **Km/h** to **Mph** or from **Mph** to **Km/h**.

Guideline

Activation duration of MODE button	10 s
---	------

Combination instrument - time




The time is shown in area **1** of the display.

**Info**

The time has to be reset after the battery is reconnected or when the fuse is changed.


Setting the clock

Condition
The motorcycle is standing.



- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **MODE** button repeatedly until the **ODO** mode is active.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
 - ✓ The time display begins to flash.
- Press the **MODE** button to set the hour.
- Press the **SET** button to set the minute.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
 - ✓ The time is set.

Combination instrument - display ODO



In the **ODO** display mode, the total distance traveled is shown in kilometers or miles.



Info

This value is retained, even if the battery is disconnected and/or the fuse blows.


Combination instrument - setting/resetting TRIP 1



Info

The **TRIP 1** trip counter is always running and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **MODE** button repeatedly until the **TRIP 1** mode is active.
- Keep the **SET** button pressed.
- ✓ The **TRIP 1** display is set to **0.0**.


Combination instrument - setting/resetting TRIP 2



Info


The **TRIP 2** trip counter is always running and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **MODE** button repeatedly until the **TRIP 2** mode is active.
- Keep the **SET** button pressed.
- ✓ The **TRIP 2** display is set to **0.0**.

Combination instrument - TRIP F display




If the fuel level drops to the reserve mark, the display automatically changes to **TRIP F** and starts to count from **0.0**, regardless of the previous display mode.



Info

Parallel to the **TRIP F** display, the fuel warning light switches on.

Combination instrument - coolant temperature indicator



The temperature display consists of 12 bars. The more bars showing, the hotter the coolant. When the top bar lights up, all bars begin to flash and the temperature warning light starts to show.

Possible states

- Engine cold – Up to four bars light up.
- Engine at operating temperature – Five to eleven bars light up.
- Engine hot – All twelve bars flash.

Opening filler cap



- Lift the cover of the filler cap ❶ and insert the ignition key.
- Turn the ignition key 90° counterclockwise and remove the filler cap.



Info


The filler cap has a tank air vent system.

Closing filler cap



- Put the filler cap back on and turn the ignition key 90° clockwise.
- Remove the ignition key and fold down the cover.

Handrails



The handrails ❶ are used for moving the motorcycle around.
When you have a passenger, the passenger can hold on the handrails during the journey.

Seat release



The seat can be released using strap ❶.

Passenger footrests




The passenger footrests can be folded up and down.


Possible states

- Passenger footrests folded up – For operation without a passenger.
- Passenger footrests folded down – For operation with a passenger.

Shift lever



The shift lever ❶ is mounted on the left side of the engine.




The gear positions can be seen in the photograph.
The neutral or idle position is between the first and second gears.

Foot brake pedal



The footbrake pedal ❶ is located in front of the right footrest.
The footbrake pedal operates the rear brake.

Side stand



The side stand ❶ is coupled with the safety electric starter system - see the riding instructions.

Possible states

- Side stand folded out – The vehicle can be supported on the side stand. The safety electric starter system is active.
- Side stand folded in – This position is mandatory for all journeys. The safety electric starter system is inactive.

Advice on first use



Danger

Danger of accidents Danger from insufficient traffic competence.

- Do not use the vehicle if you are not fit to deal with traffic or if you have consumed alcohol and/or medicaments or drugs.



Warning

Risk of injury Missing or insufficient protective clothing increases the risk of injury.

- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing, which must be in perfect condition and meet legal requirements.



Warning

Danger of crashing Impairment of riding behavior due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



Warning

Danger of accidents Uncontrollable handling characteristics due to non-approved and/or non-recommended tires/wheels.

- Only tires/wheels approved by KTM and with the corresponding speed index should be used.



Warning

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth roll surface and therefore cannot provide full road grip. The entire roll surface must be roughened in the first 200 kilometers (124.3 miles) by moderate driving at alternating angles. The full grip is not reached until the vehicle has been run in.



Warning

Danger of accidents Brake system failure.

- If the foot brake pedal is not released, the brake linings drag permanently. The rear brake can fail due to overheating. Take your foot off the foot brake pedal if you do not want to brake.

GENERAL TIPS AND HINTS ON PUTTING INTO OPERATION

37



Info

When using your vehicle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized KTM workshop. You receive a delivery certificate and the service record at vehicle handover.
- Before your first trip, read the entire operating instructions carefully.
- Get to know the controls.
- adjust the basic position of clutch lever. (☛ p. 127)
- Adjust the free travel of the handbrake lever. (☛ p. 76)
- Adjust the basic position of the foot brake pedal. ☛ (☛ p. 84)
- Get used to handling the motorcycle on a suitable piece of land before making a longer trip. Try also to ride as slowly as possible and in a standing position to get a better feeling for the vehicle.
- Do not make any offroad trips that over-stress your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
- Run the engine in.

Running in the engine

- During the running-in phase, do not exceed the specified engine speed and engine performance.

Guideline

Maximum engine speed	
During the first: 1,000 km (621.4 mi)	6,000 rpm
After the first: 1,000 km (621.4 mi)	7,800 rpm

- Avoid fully opening the throttle!

Loading the vehicle



Warning

Danger of accidents Unstable riding behavior.

- Do not exceed the maximum permitted weight and axle loads. The overall weight consists of: motorcycle operational and with a full tank, driver and passenger with protective clothing and helmet, baggage.



Warning

Danger of accidents Unstable handling characteristics due to incorrect mounting of suitcase and/or tank rucksack.

- Mount and secure suitcase and tank rucksack according to the manufacturer's instructions.



Warning

Danger of accidents Unstable handling characteristics at high speed.

- Adapt your speed according to your payload. Ride more slowly if your motorcycle is loaded with cases or other baggage.
Maximum speed with baggage 130 km/h (80.8 mph)



Warning

Danger of accidents Risk of breakage of suitcase system.

- If you have fitted suitcases on your motorcycle, read the manufacturer's specifications concerning the maximum payload.



Warning

Danger of accidents Poor visibility for other road users due to slipped baggage.

- If the tail light is covered, you are less visible to following traffic, especially in the dark. Check the way your baggage is fixed regularly.



Warning

Danger of accidents Changed handling characteristics and longer stopping distance with excessive payload.

- Adapt your speed according to your payload.

GENERAL TIPS AND HINTS ON PUTTING INTO OPERATION

39



Warning

Danger of accidents Unstable handling characteristics due to slipped baggage.

- Check the way your baggage is fixed regularly.



Warning

Danger of burns A hot exhaust system can burn baggage.

- Fasten your baggage in such a way that it cannot be burned or singed by the hot exhaust system.

-
- If you carry any baggage, make sure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.
 - Do not exceed the overall maximum permitted weight and the axle loads.

Guideline

Maximum permissible overall weight	350 kg (772 lb.)
Maximum permissible front axle load	150 kg (331 lb.)
Maximum permissible rear axle load	200 kg (441 lb.)

Checks before putting into operation



Info

Make sure that the motorcycle is in a perfect technical condition before use.
In the interests of riding safety, make a habit of making a general check before you ride.

- Check the engine oil level. (🔧 p. 131)
- Check the engine for loss of oil.
- Check the fuel level.
- Bleed fork legs. (🔧 p. 62)

Guideline

all	1,000 km (621.4 mi)
-----	---------------------

- Check the chain tension. (🔧 p. 69)
- Clean the chain. (🔧 p. 68)
- Check the tire condition. (🔧 p. 96)
- Check the tire air pressure. (🔧 p. 98)
- Check the front brake fluid level. (🔧 p. 77)
- Check the rear brake fluid level. (🔧 p. 85)
- Check the front brake linings. (🔧 p. 79)
- Check the rear brake linings. (🔧 p. 87)
- Check brake system function.
- Check the coolant level. (🔧 p. 122)
- Check that all operating elements are correctly adjusted and free to move.
- Check the functioning of the electrical equipment.
- Check that baggage is correctly secured.
- Sit on the motorcycle and check the rear mirror setting.

Starting



Danger

Danger of poisoning Exhaust gases are poisonous and can result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in a closed space without an effective exhaust extraction system.



Caution


Danger of accidents If the vehicle is operated with a discharged battery or without a battery, electronic components and safety equipment may be damaged.

- Never operate the vehicle with a discharged battery or without a battery.

Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



- Turn the emergency OFF switch to the position .
- Switch on the ignition by turning the ignition key to position **ON** .
- ✓ After you switch on the ignition, you can hear the fuel pump working for about 2 seconds. At the same time, the function test of the combination instrument is run.
- Shift gear to neutral.
- ✓ The green idling speed indicator lamp **N 1** lights up.
- Press the electric starter button .

i Info

Do not press the electric starter button until the function test of the combination instrument is finished.

When starting, **DO NOT** open the throttle. If you open the throttle during the starting procedure, no fuel is injected by the engine management, and so the engine cannot start.

Press the starter for a maximum of 5 seconds. Wait for a least 5 seconds until trying again.

This motorcycle is equipped with a safety start system. You can only start the engine if the gearbox is in neutral or if the clutch is pulled. If the sidestand is folded out and you shift into gear and release the clutch, the engine stops.

- Take the weight off the side stand and swing it back up with your foot as far as it will go.

Starting up

- Pull the clutch lever, engage 1st gear, release the clutch lever slowly and simultaneously open the throttle carefully.

Shifting, riding



Warning

Danger of accidents An abrupt load alterations can cause the vehicle to get out of control.

- Avoid abrupt load alterations and sudden braking actions, and adapt your speed to the road conditions.



Warning

Danger of accidents If you change down at high engine speed, the rear wheel can lock up.

- Do not change into a low gear at high engine speed. The engine races and the rear wheel can block.



Warning

Danger of accidents Malfunctions caused by incorrect ignition key position.

- Do not change the ignition key position during a journey.



Warning

Danger of accidents Distraction from traffic activity by adjustments to the vehicle.

- Make all adjustments when the vehicle is at a standstill.



Warning

Risk of injury The passenger must be capable of sitting correctly on the passenger seat.

- The passenger must hold on to the rider or the handrails and place his feet on the passenger footrests. Note the regulations governing the minimum age of passengers in your country.



Warning

Danger of accidents Danger of accidents caused by dangerous driving.

- Observe the traffic regulations and ride defensively and with foresight in order to recognize danger as early as possible.

**Warning**

Danger of accidents Reduced road grip with cold tires.

- On every journey, take the first miles carefully at moderate speed until the tires reach operating temperature and optimal road grip is ensured.

**Warning**

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth roll surface and therefore cannot provide full road grip. The entire roll surface must be roughened in the first 200 kilometers (124.3 miles) by moderate driving at alternating angles. The full grip is not reached until the vehicle has been run in.

**Warning**

Danger of accidents Unstable riding behavior.

- Do not exceed the maximum permitted weight and axle loads. The overall weight consists of: motorcycle operational and with a full tank, driver and passenger with protective clothing and helmet, baggage.

**Warning**

Danger of accidents Unstable handling characteristics due to slipped baggage.

- Check the way your baggage is fixed regularly.

**Warning**

Danger of accidents After a fall, check the vehicle.

- After a fall, check the vehicle as usual before putting it into operation.

Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.


Note

Engine failure Overheating of engine.

- If the coolant temperature warning lamp lights up, stop and switch off the engine. Allow the engine to cool down and check the coolant level in the radiator, and top up if necessary. If you continue with the coolant temperature warning lamp alight, you may have engine failure.

i Info

If you hear unusual noises while riding, stop immediately, switch off the engine and contact an authorized KTM workshop.



- When conditions allow (incline, road situation, etc.), you can shift into a higher gear.
- Release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch and open the throttle.

i Info

You can see the positions of the 6 forward gears in the figure. The neutral or idle position is between the first and second gears. First gear is used for starting off or for steep inclines.

The operating temperature is reached when 5 bars of the temperature indicator light up.

- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is $\frac{3}{4}$ open. This will barely reduce the speed but fuel consumption will be considerably lower.
- Accelerate only up to a speed suitable for the road surface and weather conditions. Particularly in bends, do not shift, and accelerate very carefully.
- To shift down, brake if necessary and close the throttle at the same time.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly and open the throttle or shift again.

- If the engine stalls (e.g. at a crossroads), just pull the clutch lever and press the starter button. You do not have to shift into neutral.
- Switch off the engine if you expect to be standing for a long time.
- Avoid frequent and longer slipping of the clutch. This heats the engine oil, the engine and the cooling system.
- Ride with a lower engine speed instead of with a high engine speed and a slipping clutch.
- If the **FI** warning lamp (**MIL**) lights up during a journey, stop immediately. When you shift to neutral, the **FI** warning lamp (**MIL**) starts to flash.

**Info**

From the flashing rhythm, you can derive a two-digit number, the so-called flashing code. The flashing code tells you which component has a fault.

Braking**Warning**

Danger of accidents If you brake too hard, the wheels can lock.

- Adapt your braking to the traffic situation and the road conditions.

**Warning**

Danger of accidents Reduced braking due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.

**Warning**

Danger of accidents Reduced braking caused by spongy pressure point of front or rear brake.

- Have the brake system checked in an authorized KTM workshop, and do not ride any further.

**Warning****Danger of accidents** Brake system failure.

- If the foot brake pedal is not released, the brake linings drag permanently. The rear brake can fail due to overheating. Take your foot off the foot brake pedal if you do not want to brake.

**Warning****Danger of accidents** Longer stopping distance due to higher overall weight.

- Take the longer stopping distance into account when carrying a passenger and baggage.

**Warning****Danger of accidents** Delayed brake action on salted roads.

- Salt can be deposited on the brake discs. To achieve the normal braking effect, the brake discs must first be cleaned by braking.

-
- To brake, release the throttle and operate the front and rear brakes simultaneously.
 - On sandy, wet or slippery surfaces, use the rear brake.
 - Braking should always be completed before you go into a bend. Change down to a lower gear appropriate to your road speed.
 - On long downhill stretches, use the braking effect of the engine. Change down one or two gears, but do not overstress the engine. In this way, you have to brake far less and the brakes do not overheat.

Stopping, parking

**Warning****Risk of misappropriation** Usage by unauthorized persons.

- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons. If you leave the vehicle, lock the steering and remove the ignition key.

**Warning**

Danger of burns Some vehicle components get very hot when the machine is driven.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber and brakes. Allow these components to cool down before starting work on them.

Note

Danger of damage The parked vehicle can roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components get very hot when the machine is driven.

- Do not place the vehicle where there are flammable or explosive substances. Do not place objects over the vehicle while it is still warm from being run. Always let the vehicle cool first.

Note

Material damage Damage and destruction of components by excessive load.

- The side stand is designed for the weight of the motorcycle only. Do not sit on the motorcycle when it is supported by the side stand only. The side stand and/or the frame could be damaged and the motorcycle could fall over.

-
- Brake the motorcycle.
 - Shift gear to neutral.
 - Switch off the ignition by turning the ignition key to position **OFF** ☒.

**Info**

If the engine is switched off with the emergency OFF switch and the ignition remains switched on at the ignition lock, power continues to flow to most power consumers and the battery will discharge. You should therefore always switch off the engine with the ignition key - the emergency OFF switch is intended for emergencies only.

-
- Park the motorcycle on a hard surface.
 - Swing the side stand forward with your foot as far as it will go and lean the vehicle on it.

- Lock the steering by turning the handlebar fully to the left, pressing down the ignition key to position ☒ and turning it to position ☐. To make the steering lock engage more easily, move the handlebar a little to the left and right. Remove the ignition key.

Refueling



Danger

Fire hazard Fuel can easily catch fire.

- Never fill up the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See specifications on filling up with fuel.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel.



Warning



Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



Info

This motorcycle is equipped with a regulated catalyst. Leaded fuel will destroy the catalyst. You should therefore use unleaded fuel only.



- Switch off engine.
- Open the filler cap. (➡ p. 31)
- Fill the fuel tank with fuel up to measurement **A**.

Guideline

Measurement of A	20 mm (0.79 in)	
Total fuel tank capacity, approx.	12 l (3.2 US gal)	Super unleaded (ROZ 95 / RON 95 / PON 91) (➡ p. 170)

- Close the filler cap. (➡ p. 31)
 - Press the **SET** **2** function button for 2 seconds.
- ✓ The fuel level warning lamp **1** switches off. **TRIP F** is set to 0 and appears in the previous display mode.

 **Info**

If you do not press the **SET** **2** function button, the reset takes place automatically after about 3 minutes.

SERVICE SCHEDULE

51

Important maintenance work to be carried out by an authorized KTM workshop.

		K10N	K50A	K100A	J1A	J2A
Engine	Change the engine oil and filter, clean the oil screens.  (☞ p. 131)	•	•	•	•	•
	Check and adjust valve clearance. 			•		•
	Check engine mounting screws for tightness.	•	•	•	•	•
	Replace spark plug.			•		
	Check engine bolts accessible from outside for tightness.	•	•	•	•	•
Fuel injection	Check connection boots for cracks and leakage. 	•		•		•
	Read out the error memory with a KTM diagnostic tool. 	•	•	•	•	•
	Check fuel hoses, SLS hoses and vent hoses for damage, correct fitting and leaks. 	•	•	•	•	•
	Clean, check and grease the O-ring of the fuel hose connection. 		•	•	•	•
	Check the cable harness of the throttle valve body for damage and correct positioning. 	•		•		•
Attachments	Check the cooling system for leakage.	•	•	•	•	•
	Check the antifreeze and coolant level. (☞ p. 120)	•	•	•	•	•
	Check the functioning of the radiator fan. 	•	•	•	•	•
	Check the exhaust system for leaks and correct fitting and check that the exhaust holders are tight. 	•	•	•	•	•
	Check Bowden cables for damage, smooth operation, routing without sharp bends and setting.	•	•	•	•	•
	Check/rectify the fluid level of the hydraulic clutch. (☞ p. 127)		•	•	•	•
	Check air filter and change if necessary. Clean the air filter box. 		•	•	•	•
	Checking fuel tank for tightness.	•	•	•	•	•
	Check cables for damage and routing without sharp bends. 	•	•	•	•	•

SERVICE SCHEDULE

52

		K10N	K50A	K100A	J1A	J2A
Attachments	Check the headlamp setting. (🔧 p. 116)	•	•	•	•	•
	Check the functioning of the electrical equipment.	•	•	•	•	•
	Check screws and nuts for tightness.	•	•	•	•	•
Brakes	Check the front brake linings. (🔧 p. 79)	•	•	•	•	•
	Check the rear brake linings. (🔧 p. 87)	•	•	•	•	•
	Check the brake discs. (🔧 p. 74)	•	•	•	•	•
	Check the front brake fluid level. (🔧 p. 77)	•	•	•	•	•
	Check the rear brake fluid level. (🔧 p. 85)	•	•	•	•	•
	Change brake fluid. 🛢️					•
	Check brake lines for damage and leakage.	•	•	•	•	•
	Check the free play of the foot brake lever. (🔧 p. 83)	•	•	•	•	•
	Check braking.	•	•	•	•	•
	Check screws and guide bolts of brake system for tightness. 🛠️	•	•	•	•	•
Chassis	Check shock absorber and fork for leakage and functioning. 🛠️	•	•	•	•	•
	Clean the dust boots of the fork legs. (🔧 p. 63)		•	•	•	•
	Bleed fork legs. (🔧 p. 62)	•	•	•	•	•
	Check swingarm bearing. 🛠️	•	•	•	•	•
	Check play of steering head bearing. 🛠️ (🔧 p. 65)	•	•	•	•	•
	Check all screws to see if they are tight.	•	•	•	•	•
	Grease Pro-Lever deflector. 🛠️					•
Wheels	Check the spoke tension. (🔧 p. 99)	•	•	•	•	•
	Check rim run-out. 🛠️	•	•	•	•	•
	Check the tire condition. (🔧 p. 96)	•	•	•	•	•

SERVICE SCHEDULE

53

		K10N	K50A	K100A	J1A	J2A
Wheels	Check the tire air pressure. (🔧 p. 98)	•	•	•	•	•
	Check the chain wear. (🔧 p. 73)	•	•	•	•	•
	Check rear sprocket / engine sprocket for tightness.	•	•	•	•	•
	Check rear sprocket / engine sprocket for wear. (🔧 p. 72)	•	•	•	•	•
	Check the chain tension. (🔧 p. 69)	•	•	•	•	•
	Clean the chain. (🔧 p. 68)	•	•	•	•	•
	Check wheel bearing for play. 🛠		•	•	•	•
	Checking the rear hub rubber dampers. 🛠 (🔧 p. 95)		•	•	•	•

K10N: after 1,000 km (621.4 mi)

K50A: every 5,000 km (3,107 mi) / after every race

K100A: every 10,000 km (6,214 mi)

J1A: annually

J2A: every 2 years

Important maintenance work to be carried out by an authorized KTM workshop. (as additional order)

	K100A	J1A	J2A
Carry out a complete fork service. 🛠	•		•
Carry out a complete shock absorber service. 🛠	•		•
Clean and grease steering head bearing and sealing elements. 🛠			•
Treat electric contacts with contact spray.		•	•
Clean the battery terminals and treat them with contact grease.		•	•
Change coolant. 🛠			•

K100A: every 10,000 km (6,214 mi)

J1A: annually

SERVICE SCHEDULE

J2A: every 2 years

MAINTENANCE WORK ON CHASSIS AND ENGINE

55

Jacking up the motorcycle

Note

Danger of damage The parked vehicle can roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Jack up the motorcycle on the underride guard underneath the engine. The wheels must no longer touch the ground.
- Secure the motorcycle against falling over.


Removing the motorcycle from the work stand

Note

Danger of damage The parked vehicle can roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Remove the motorcycle from the work stand and rest it on its side stand.
- Remove the work stand.

Fork/shock absorber



The fork and the shock absorber offer many options of adapting the chassis to your riding style and the payload.



Info

To help you adapt the vehicle, we have summarized our findings in Table ❶. You can find the table on the underside of the seat.


These adjustments should be understood as a guideline and should always be the basis of your own personal chassis adaptation. Do not change the adjustments at random or by more than $\pm 40\%$, since otherwise the riding characteristics could deteriorate, particularly at high speeds.

Adjusting the compression damping of the fork



Info

The hydraulic compression damping determines the fork suspension behavior.



- Remove protection covers ❶.
- Turn adjusting screws ❷ clockwise until they stop.



Info

The adjusting screws are located at the bottom end of the fork legs. Make the same adjustment on both fork legs.

- Turn back counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

i

Info

Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.


– Mount protection covers ❶.

Adjusting the rebound damping of the fork

i

Info

The hydraulic rebound damping determines the fork rebound behavior.



- Turn adjusting screws ❶ clockwise until they stop.

i

Info

The adjusting screws are located at the top end of the fork legs. Make the same adjustment on both fork legs.

- Turn back counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks



Info

Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Compression damping of the shock absorber

The shock absorber can regulate compression damping in low- and high-speed range separately (Dual Compression Control). The term low speed and high speed refer to the movement of the shock absorber during compression and not the riding speed of the motorcycle.

Changes in the settings in the low-speed range have an impact on the high-speed range and vice versa.

Adjusting the low-speed compression damping of the shock absorber



Danger


Danger of accidents The shock absorber is under high pressure.

- The shock absorber is filled with highly compressed nitrogen, so never dismantle the shock absorber or carry out any maintenance on it yourself.



Info

The low-speed setting can be seen during the slow to normal compression of the shock absorber.



- Turn adjusting screw ❶ clockwise with a screwdriver as far as the last audible click.



Info

Do not loosen the nut ❷!

- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks



Info

Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Adjusting the high-speed compression damping of the shock absorber



Danger


Danger of accidents The shock absorber is under high pressure.

- The shock absorber is filled with highly compressed nitrogen, so never dismantle the shock absorber or carry out any maintenance on it yourself.



Info

The high-speed setting can be seen during the fast compression of the shock absorber.



- Turn adjusting screw ❶ clockwise as far as it will go using an open end wrench.

i

Info
Do not loosen the nut ❷!

- Turn back counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn

i

Info
Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.


Adjusting the rebound damping of the shock absorber

!

Danger

Danger of accidents The shock absorber is under high pressure.


- The shock absorber is filled with highly compressed nitrogen, so never dismantle the shock absorber or carry out any maintenance on it yourself.



- Turn adjusting screw ❶ clockwise to the last perceptible click.
 - Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.
- Guideline
- | | |
|-----------------|-----------|
| Rebound damping | |
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |
- i**

Info
Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Bleeding fork legs



- Lean the motorcycle on the side stand.
 - Remove bleeder screws ❶ briefly.
 - ✓ Any excess pressure escapes from the interior of the fork.
 - Mount and tighten bleeder screws.
- i**

Info
Carry out this action on both fork legs.

Cleaning the dust boots of the fork legs



- Jack up the motorcycle. (🔧 p. 55)
- Loosen the fork protection. (🔧 p. 64)
- Push dust boot ❶ of both fork legs downwards.



Info

The dust boots should remove dust and coarse dirt particles from the fork tubes. Over time, dirt can penetrate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Reduced braking due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean and oil the dust boots and inner fork tube of both fork legs.

Universal oil spray (🔧 p. 172)


- Press the dust boots back into their normal position.
- Remove excess oil.
- Position the fork protection. (🔧 p. 64)
- Remove the motorcycle from the work stand. (🔧 p. 55)

Loosening the fork protection



- Remove screws ❶ and take off clamp.
- Remove screws ❷ on left fork leg. Push the fork protection downwards.
- Remove the screws on the right fork leg. Push the fork protection downwards.

Positioning the fork protection



- Position the fork protection on the left fork leg. Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the brake line and cable harness. Put the clamp on, mount and tighten screws ❷.

- Position the fork protection on the right fork leg. Mount and tighten screws.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Checking play of steering head bearing 🛠️



Warning


Danger of accidents Unsafe riding behavior due to incorrect steering head bearing play.

- The steering head bearing play should be adjusted immediately in an authorized KTM workshop.



Info

If the bike is driven for a longer time with play in the steering head bearing, the bearing and the bearing seats in the frame can be damaged after time.



- Jack up the motorcycle. (🔧 p. 55)
- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

No play should be noticeable in the steering head bearing.

» If there is noticeable play present:


- Adjust play of the steering head bearing. 🛠️ (🔧 p. 66)
- Move the handlebar to and fro over the entire steering range.

The handlebar must be able to move easily over the entire steering range. No resting locations should be noticeable.

» If click positions are noticeable:

- Adjust play of the steering head bearing. 🛠️ (🔧 p. 66)
- Check the steering head bearing and change if necessary.
- Remove the motorcycle from the work stand. (🔧 p. 55)

Adjusting play of steering head bearing 🛠️



- Jack up the motorcycle. (🔧 p. 55)
- Loosen screw ❶. Remove screw ❷.
- Loosen and retighten screw ❸.

Guideline

Screw, top steering head	M20x1.5	10 Nm (7.4 lbf ft)
--------------------------	---------	--------------------

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Fully tighten screw ❶.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------


- Mount and tighten screw ❷.

Guideline

Screw, steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
----------------------	----	---------------------	---------------

- Check play of steering head bearing. 🛠️ (🔧 p. 65)
- Remove the motorcycle from the work stand. (🔧 p. 55)

Handlebar position



On the upper triple clamp, there are 2 holes at a distance **A** to each other.


Distance A between holes	15 mm (0.59 in)
---------------------------------	-----------------

The holes on the handlebar support are placed at a distance **B** from the center.

Distance B between holes	3.5 mm (0.138 in)
---------------------------------	-------------------

The handlebar can be mounted in 4 different positions. In this way, the handlebar can be installed in the position most comfortable for the rider.

Adjusting handlebar position



- Remove the four screws **1**. Remove the handlebar clamp. Remove the handlebar and lay it to one side.

 **Info**

Protect the motorcycle and its attachments from damage by covering them.
Do not bend the cables and lines.

- Remove the two screws **2**. Remove the handlebar support.
- Place the handlebar support in the required position. Fit and tighten the two screws **2**.

Guideline		
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)

 **Info**

Position the left and right handlebar supports evenly.

- Position the handlebar.



Info

Make sure cables and wiring are positioned correctly.

- Position the handlebar clamp. Fit and evenly tighten the four screws ❶.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
------------------------	----	------------------------	---------------

Checking chain dirt

- Check the chain for coarse dirt accumulation.
 - » If the chain is very dirty:
 - Clean the chain. (🔧 p. 68)

Cleaning the chain



Warning

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.



Warning

Danger of accidents Reduced braking due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.

**Info**

The service life of the chain depends largely on its maintenance.

- Clean the chain regularly.
- Rinse off loose dirt with a soft jet of water.
- Remove old grease remains with chain cleaner.

Chain cleaner (🔧 p. 171)

- After drying, apply chain spray.


Offroad chain spray (🔧 p. 172)

Checking the chain tension

**Warning**

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check for correct chain tension and adjust if necessary.



- Lean the motorcycle on the side stand.
- Shift gear to neutral.
- Push the chain upward at a distance **B** from the chain sliding guard and determine the chain tension **A**.

i

Info

The upper chain section **C** must be taut.

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	5 mm (0.2 in)
Distance to chain sliding guard	30 mm (1.18 in)

- » If the chain tension does not meet specifications:
 - Adjust the chain tension. (🔧 p. 70)


Adjusting the chain tension

!

Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check for correct chain tension and adjust if necessary.



- Check the chain tension. (🔧 p. 69)
- Loosen nut ❶.
- Loosen nuts ❷.
- Adjust the chain tension by turning adjusting screws ❸ on the left and right.

Guideline

Chain tension	5 mm (0.2 in)
Turn the left and right adjusting screws ❸ so that the markings on the left and right chain adjusters ❹ are in the same position relative to the reference marks ❷. The rear wheel is then correctly aligned.	

i

Info

The upper chain section must be taut.

Chain wear is not always even, so you should check this setting at different chain positions.

- Tighten nuts ❷.
- Make sure that the chain adjusters ❹ are installed correctly on adjusting screws ❸.
- Tighten nut ❶.

Guideline

Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)
-------------------------	---------	------------------------


i

Info

The wide adjustment range of the chain adjusters (30 mm (1.18 in)) enables different secondary transmissions with the same chain length.

The chain adjusters ❹ can be turned through 180°.

Checking rear sprocket / engine sprocket for wear



- Check rear sprocket / engine sprocket for wear.
 - » If the rear sprocket / engine sprocket are worn:
 - Replace rear sprocket / engine sprocket.




Info

The engine sprocket, rear sprocket and chain should always be replaced together.

For safety reasons, the chain has no chain joint. Always have the chain replaced in an authorized KTM workshop, where the necessary chain rivet tool is available.

- Check chain guides for tightness and wear.

Checking chain wear



- Shift into neutral, and pull the lower chain section with the specified weight **A**.

Guideline

Weight of chain wear measurement	15 kg (33 lb.)
----------------------------------	----------------

- Measure distance **B** of 18 chain segments of the lower chain section.

i

Info
Chain wear is not always even, so you should repeat this measurement at different chain positions.


Maximum distance B at the longest section of the chain	272 mm (10.71 in)
---	-------------------

- » If distance **B** is greater than the specified measurement:
 - Have the chain changed.

i

Info
When the chain is replaced, the rear sprocket and engine sprocket should be replaced at the same time.
A new chain will wear faster on an old, worn rear sprocket or engine sprocket.
For safety reasons, the chain has no chain joint. Always have the chain changed in an authorized KTM workshop, where they have the necessary special tools.

Adjusting chain guide



- Remove screws ❶ and ❷. Take off the chain guide.

Condition

Number of teeth: ≤ 44 teeth

- Insert nut ❸ in hole ❶. Position the chain guide.
- Mount and tighten screws ❶ and ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Condition

Number of teeth: ≥ 45 teeth

- Insert nut ❸ in hole ❷. Position the chain guide.
- Mount and tighten screws ❶ and ❷.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Checking brake discs

**Warning**

Danger of accidents Reduced braking due to worn brake discs.

- Worn brake discs should be replaced immediately in an authorized KTM workshop.



- Check the thickness of the front and rear brake discs in several places to ensure that it conforms to measurement **A**.

i Info

Wear reduces the thickness of the brake disc in the area **1** of the brake disc.

Brake discs - wear limit	
Front	4.5 mm (0.177 in)
Rear	3.5 mm (0.138 in)

- » If the brake disc thickness is less than the specified value:
 - Replace the brake disc.
- Check the front and rear brake discs for damage, cracks, and deformation.
 - » If damage, cracks, or deformation are visible on the brake disc:
 - Replace the brake disc.

Checking free play of hand brake lever

Warning
Danger of accidents Brake system failure.

- If there is no free travel on the hand brake lever, pressure builds up on the front brake in the brake system. The front brake can fail due to overheating. Adjust free travel on hand brake lever according to specifications.




- Push the hand brake to the handlebar and check free play **A**.

Free play of hand brake lever	$\geq 3 \text{ mm } (\geq 0.12 \text{ in})$
-------------------------------	---

- » If the free travel does not meet specifications:
 - Adjust the free travel of the handbrake lever. (🔧 p. 76)

Adjusting free travel of handbrake lever



- Adjust the free travel of the handbrake lever with the adjustment screw **1**.

i Info

Turn the adjustment screw clockwise to reduce free travel. The pressure point moves away from the handlebar.
 Turn the adjustment screw counterclockwise to increase free travel. The pressure point moves towards the handlebar.
 The range of adjustment is limited.
 Turn the adjusting screw by hand only, and do not apply any force.
 Do not make any adjustments while riding!

- Check the free play of the hand brake lever. (🔧 p. 75)

Checking the front brake fluid level



Warning

Danger of accidents Brake system failure.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Have the brake system checked in an authorized KTM workshop, and do not ride any further.



Warning

Danger of accidents Reduced braking due to old brake fluid.

- Have the front and rear brake fluid replaced according to the service plan in an authorized KTM workshop.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the viewer ❶.
 - » If the brake fluid level is below the **MIN** mark:
 - Add front brake fluid. 🛠️ (🔧 p. 77)

Adding front brake fluid 🛠️



Warning

Danger of accidents Brake system failure.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Have the brake system checked in an authorized KTM workshop, and do not ride any further.

**Warning**

Skin irritations Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.

**Warning**

Danger of accidents Reduced braking due to old brake fluid.

- Have the front and rear brake fluid replaced according to the service plan in an authorized KTM workshop.

**Warning**

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.


**Info**

Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container!

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.



- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Add brake fluid to level A.

Guideline

Level A	5 mm (0.2 in)
---------	---------------

Brake fluid DOT 4 / DOT 5.1 (🔧 p. 167)
--

- Position the cover with the membrane. Mount and tighten the screws.

Info

Clean up overflowed or spilt brake fluid immediately with water.

Checking the front brake linings

Warning


Danger of accidents Reduced braking due to worn brake linings.

- Worn brake linings should be replaced immediately in an authorized KTM workshop.

Note

Danger of accidents Reduced braking due to damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are destroyed.



- Check the brake linings for minimum thickness **A**.

Minimum thickness A	$\geq 1 \text{ mm } (\geq 0.04 \text{ in})$
----------------------------	---

- » If the minimum thickness is less than specified:
 - Change the front brake linings. (🔧 p. 80)

Changing the front brake linings



Warning

Danger of accidents Improper brake maintenance and repair.

- Always have your brake system maintained and repaired in an authorized KTM workshop.



Warning

Skin irritations Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



Warning

Danger of accidents Reduced braking due to old brake fluid.

- Have the front and rear brake fluid replaced according to the service plan in an authorized KTM workshop.



Warning

Danger of accidents Reduced braking due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents Reduced braking due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.



Warning

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.




Info

Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container!




- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Press the brake caliper by hand on to the brake disc in order to press back the brake pistons. Make sure that no brake fluid escapes from the brake fluid reservoir. If it does, clean it up.




Info

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.




- Remove the safety clip ④, knock the pin ⑤ out to the right, and remove the brake linings.
- Clean brake caliper and brake caliper support.



- Check that leaf spring ⑥ in the brake caliper and sliding plate ⑦ in the brake caliper support are seated correctly.



- Insert the brake pads, insert the bolt and mount the split pin.
- Operate the hand brake lever repeatedly until the brake linings lie on the brake disc and there is a tight spot.



- Add brake fluid level to A.

Guideline

Level A	5 mm (0.2 in)
---------	---------------

Brake fluid DOT 4 / DOT 5.1 (🔧 p. 167)
--

- Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilt brake fluid immediately with water.


Checking free play of foot brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake pedal, pressure builds up on the rear brake in the brake system. The rear brake can fail due to overheating. Adjust free travel on foot brake pedal according to specifications.



- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel A.

Guideline

Free play at foot brake lever	3... 5 mm (0.12... 0.2 in)
-------------------------------	----------------------------



Info


You will know that contact has been made with the foot brake cylinder piston when there is increased resistance when you activate the foot brake pedal.

- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake pedal. 🛠️ (🔧 p. 84)

Adjusting basic position of foot brake pedal

 **Warning**
Danger of accidents Brake system failure.

- If there is no free travel on the foot brake pedal, pressure builds up on the rear brake in the brake system. The rear brake can fail due to overheating. Adjust free travel on foot brake pedal according to specifications.



- Remove screw connection ③ on foot brake cylinder ④.
- To adjust the basic position of the foot brake pedal as needed, loosen nut ① and turn screw ② accordingly.

 **Info**
The range of adjustment is limited. The screw must be screwed into the footrest bracket by at least four turns.

- Position foot brake cylinder ④ so that the foot brake pedal has the necessary free travel. Hold screws ③ in place and tighten the nuts.

Guideline

Nut, foot brake cylinder screw	M6	10 Nm (7.4 lbf ft)
--------------------------------	----	--------------------

- Check the free play of the foot brake lever. ( p. 83)
- Tighten nut ①.

Checking rear brake fluid level



Warning

Danger of accidents Brake system failure.


- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Have the brake system checked in an authorized KTM workshop, and do not ride any further.



Warning

Danger of accidents Reduced braking due to old brake fluid.

- Have the front and rear brake fluid replaced according to the service plan in an authorized KTM workshop.



100258-10

- Stand the vehicle upright.
- Check the brake fluid level in the brake fluid reservoir.
 - » If the fluid level reaches the **MIN** marking ❶:
 - Add rear brake fluid. 🛠️ (🔧 p. 85)

Adding rear brake fluid 🛠️



Warning

Danger of accidents Brake system failure.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Have the brake system checked in an authorized KTM workshop, and do not ride any further.



Warning

Skin irritations Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



Warning

Danger of accidents Reduced braking due to old brake fluid.

- Have the front and rear brake fluid replaced according to the service plan in an authorized KTM workshop.



Warning

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.




Info

Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container!



- Stand the vehicle upright.
- Remove the screw cap ❶ with the membrane ❷.
- Add brake fluid to **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☛ p. 167)

- Mount the screw cap with the membrane.



Info

Clean up overflowed or spilt brake fluid immediately with water.

Checking the rear brake linings



Warning


Danger of accidents Reduced braking due to worn brake linings.

- Worn brake linings should be replaced immediately in an authorized KTM workshop.

Note

Danger of accidents Reduced braking due to damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are destroyed.



- Check the brake linings for minimum thickness **A**.

Minimum thickness A	$\geq 1 \text{ mm } (\geq 0.04 \text{ in})$
----------------------------	---

- » If the minimum thickness is less than specified:
 - Change the rear brake linings. 🛠️ (👉 p. 87)

Changing the rear brake linings 🛠️



Warning

Danger of accidents Improper brake maintenance and repair.

- Always have your brake system maintained and repaired in an authorized KTM workshop.



Warning

Skin irritations Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- If brake fluid gets into your eyes, rinse thoroughly with water and contact a doctor immediately.



Warning

Danger of accidents Reduced braking due to old brake fluid.

- Have the front and rear brake fluid replaced according to the service plan in an authorized KTM workshop.



Warning

Danger of accidents Reduced braking due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents Reduced braking due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.



Warning

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.




Info

Never use DOT 5 brake fluid! This is based on silicone oil and is colored purple. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container!




- Stand the vehicle upright.
- Remove the screw cap ❶ with the membrane ❷.
- Press the brake caliper by hand on to the brake disc in order to press back the brake piston. Make sure that no brake fluid escapes from the brake fluid reservoir. If it does, clean it up.




Info


Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.



- Remove the safety clip ❸, knock the pin ❹ out to the left, and remove the brake linings.
- Clean brake caliper and brake caliper support.



- Check that leaf spring ❺ in the brake caliper and sliding plate ❻ in the brake caliper support are seated correctly.



- Insert the brake pads, insert the bolt and mount the split pin.
- Operate the foot brake lever repeatedly until the brake linings lie on the brake disc and there is a tight spot.
- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☛ p. 167)

- Mount the screw cap with the membrane.




Info

Clean up overflowed or spilt brake fluid immediately with water.

Removing the front wheel 🛞



- Jack up the motorcycle. (☛ p. 55)
- Press the brake caliper by hand on to the brake disc in order to press back the brake pistons.




- Remove screw ❶.
- Loosen screw ❷.



- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.

i Info

Do not pull the hand brake lever when the front wheel is removed.
Always lay the wheel down in such a way that the brake disc is not damaged.




- Remove distance bushings ❸.


Installing the front wheel

Warning
Danger of accidents Reduced braking due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Clean and grease the shaft seal rings ❶ and bearing surface ❶ of the distance bushings.
- Long-life grease (🔧 p. 172)
- Insert the distance bushings.




- Lift the front wheel into the fork, position it, and insert the wheel spindle.
 - Mount and tighten screw ❷.
- Guideline
- | | | |
|----------------------------|---------|------------------------|
| Screw, front wheel spindle | M24x1.5 | 40 Nm
(29.5 lbf ft) |
|----------------------------|---------|------------------------|
- Operate the hand brake lever several times until the brake pads are lying correctly on the brake disc.
 - Remove the motorcycle from the work stand. (🔧 p. 55)
 - Pull the front wheel brake and push down hard on the fork several times to align the fork legs.

- Fully tighten the screws ❸.


Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	------------------------

Removing rear wheel 🛠



- Jack up the motorcycle. (🔧 p. 55)
- Press the brake caliper by hand on to the brake disc in order to press back the brake piston.
- Remove nut ❶. Remove chain adjuster ❷.
- Holding the rear wheel, withdraw the wheel spindle ❸.



- Push the rear wheel forwards as far as possible and take the chain off the rear sprocket.



Warning
Danger of accidents Reduced braking due to damaged brake discs.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Take the rear wheel out of the swing arm.



Info
Do not operate the foot brake when the rear wheel is removed.

Installing the rear wheel 🛠️



Warning

Danger of accidents Reduced braking due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents No braking effect when operating the rear brake.

- After installing the rear wheel, always operate the footbrake until the pressure point is reached.




- Checking the rear hub rubber dampers. 🛠️ (🔧 p. 95)
- Remove the bushing ❶. Clean and grease the working surfaces of the bushing and shaft seal ring ❷.

Long-life grease (🔧 p. 172)

- Clean and grease the thread of the wheel spindle and the nut ❸.

Long-life grease (🔧 p. 172)

- Install the rubber damper and rear sprocket carrier in the rear wheel.
- Place the rear wheel in the swingarm and bring the brake disc on the brake caliper into contact.



- Push the rear wheel forward as far as possible and lay the chain on the rear sprocket.
- Mount the wheel spindle, chain adjusters and nuts.

Guideline

In order that the rear wheel is correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to the reference marks **A**.

i Info
Mount the left and right chain adjusters **3** in the same position.

- Tighten nut **5**.

Guideline


Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)
-------------------------	---------	------------------------

- Operate the foot brake lever repeatedly until the brake linings lie on the brake disc and there is a tight spot.
- Remove the motorcycle from the work stand. (🔧 p. 55)


Checking the rear hub rubber dampers 🛠️

i Info
The engine power is transmitted from the rear sprocket to the rear wheel via 6 rubber dampers. They eventually wear out during operation. If the rubber dampers are not changed in time, the rear sprocket carrier and the rear hub will be damaged.

- Remove the rear wheel. 🛠️ (🔧 p. 93)



- Check rubber dampers ❶ of the rear hub for damage and wear.
 - » If the rubber dampers of the rear hub are damaged or worn:
 - Change all rubber dampers in the rear hub.



- Lay the read wheel on a workbench with the rear sprocket facing upwards and insert the wheel spindle in the hub.
- To check the play ❷, hold the rear wheel tight and try to rotate the rear sprocket.

i Info
Measure the play on the outside of the rear sprocket.

Play in rubber dampers, rear wheel	≤ 5 mm (≤ 0.2 in)
------------------------------------	-------------------

- » If the play ❷ is more than the specified value:
 - Change all rubber dampers in the rear hub.
- Install the rear wheel. 🛠️ (🔧 p. 94)

Checking the tire condition

Warning
Danger of accidents Uncontrollable handling behavior caused by a flat tire.

- For your own safety, have damaged tires changed immediately.

MAINTENANCE WORK ON CHASSIS AND ENGINE

97



Warning

Danger of crashing Impairment of riding behavior due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



Warning

Danger of accidents Uncontrollable handling characteristics due to non-approved and/or non-recommended tires/wheels.

- Only tires/wheels approved by KTM and with the corresponding speed index should be used.



Warning

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth roll surface and therefore cannot provide full road grip. The entire roll surface must be roughened in the first 200 kilometers (124.3 miles) by moderate driving at alternating angles. The full grip is not reached until the vehicle has been run in.



Info

The type, condition and air pressure of the tires all have an important impact on the riding behavior of the motorcycle. Worn tires have a negative effect on riding behavior, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects and other damage.
 - » If the tires exhibit cuts, run-in objects or other damage:
 - Change the tires.

- Check the depth of the tread.

**Info**

Note local national regulations concerning the minimum tread depth.

Minimum tread depth	$\geq 2 \text{ mm } (\geq 0.08 \text{ in})$
---------------------	---


- » If the tread depth is less than the minimum permissible depth:
 - Change the tires.

Checking tire air pressure

**Info**

Low tire air pressure leads to abnormal wear and overheating of the tire.
Correct tire air pressure ensures optimal riding comfort and maximum tire service life.

- Remove dust cap.



- Check tire air pressure when tires are cold.

Tire air pressure, offroad, single rider	
Front	1.5 bar (22 psi)
Rear	1.5 bar (22 psi)
Tire air pressure, road, solo	
Front	1.8 bar (26 psi)
Rear	1.8 bar (26 psi)
Tire air pressure with passenger / fully loaded	
front	2.0 bar (29 psi)
Rear	2.2 bar (32 psi)

- » If the tire pressure does not meet specifications:
 - Correct tire pressure.
- Mount dust cap.

Checking spoke tension



Warning


Danger of accidents Unstable riding behavior due to loose spokes.

- If you ride with loose spokes, the spokes can break. Have the spoke tension corrected in an authorized KTM workshop.



Info

A loose spoke can cause wheel imbalance, which leads to more loose spokes in a short time.
If the spokes are too tight, they can break due to local overload.
Check the spoke tension regularly, especially on a new motorcycle.



- To check spoke tension, tap each spoke with a screwdriver.

Guideline

You should hear a high note.


Spoke nipple, front wheel	M5	4 Nm (3 lbf ft)
Spoke nipple, rear wheel	M5	4 Nm (3 lbf ft)

i

Info


If you hear different tone frequencies from different spokes, this is an indication of different spoke tensions.

Removing the seat



- Pull on strap ❶ and raise the rear of the seat at the same time.
- Pull back the seat and lift it off.

Mounting the seat



- Hook slot ❶ of the seat onto screw ❷, press the rear downward and at the same time push it forward.
- Push locking pin ❸ into lock housing ❹ and push the back of the seat down until the locking pin locks in place with an audible click.
- Finally, check that the seat is correctly mounted.

Removing the battery 🛠




Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well-ventilated rooms.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.

- Switch off all power consumers and switch off the engine.
- Remove the seat. (🔧 p. 100)




- Disconnect the negative (minus) cable of the battery.
- Pull off the plug connector ❶ upwards.
- Remove screws ❷.
- Pull the retaining bracket ❸ of the battery forward and remove it.
- Take off the positive pole cover ❹.
- Disconnect the positive (plus) cable of the battery.
- Push the wiring harness to the side and pull the battery out of the battery rack.

i
Info

Never operate the motorcycle with a discharged battery or without a battery. In both cases, electrical components and safety devices can be damaged. The vehicle is therefore no longer roadworthy.

Installing the battery



- Slide the battery into the battery rack.

i
Info

The battery terminals must be at the rear.

- Attach the positive cable and mount positive terminal cover ❶.
- Position retaining bracket ❷.
- Mount and tighten screws ❸.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

- Plug in connector ❹.
- Attach the minus cable .
- Mount the seat. (🔧 p. 101)

- Set the clock. (🔧 p. 27)

Recharging the battery 🔧



Warning

Risk of injury Battery acid and battery gases cause serious chemical burns.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well-ventilated rooms.
- In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.



Warning

Environmental hazard Components and battery acid are a danger to the environment.

- Do not dispose of batteries in normal household waste. Take defective or used batteries to a battery recycling operator.



Warning

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.



Info

Even if there is no load on the battery, it loses power every day.

The charge state and the type of charge are very important for the service life of the battery.

Fast recharging with a high charge current shortens the battery's service life.


If the charge current, the charge voltage and the charge time are exceeded, electrolyte escapes through the breathing holes. The battery capacity is then reduced.

If the battery is discharged from starting, it must be recharged immediately.

If it stands for a long time in a discharged state, the battery becomes over-discharged and sulfated, and then it is destroyed.

The battery is maintenance-free, i.e., the acid level does not have to be checked.

- Switch off all power consumers and switch off the engine.
- Remove the battery. 🛠️ (🔧 p. 101)



- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (58429074000)

You can also use the battery charger to test rest potential and start potential of the battery, and to test the generator. With this device, you cannot overcharge the battery.

i

Info
Never remove lid ❶.
Charge the battery with a maximum of 10% of the capacity specified on the battery housing ❷.

- Switch off and disconnect the charger after charging.

Guideline

The charge current, charge voltage and charge time must not be exceeded.	
Charging the battery regularly when the motorcycle is not in use	3 months

- Install the battery. ↗ (↖ p. 102)

Changing the main fuse

!

Warning
Fire hazard


The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

**Info**


The main fuse protects all power consumers on the vehicle. It is in the starter relay housing, next to the battery.

- Switch off all power consumers and switch off the engine.
- Remove the seat. (🔧 p. 100)
- Remove protection covers ❶.



- Use a needle nose plier to remove a defective main fuse ❷.
- Insert the new main fuse.

Fuse (58011109130) (🔧 p. 159)

**Info**


If the new fuse burns out, contact an authorized KTM workshop.
A reserve fuse ❸ is located in the starter relay.

- Check that the electrical equipment is functioning properly.
- Mount the protection covers.
- Mount the seat. (🔧 p. 101)
- Set the clock. (🔧 p. 27)


Changing the fuses of power consumers

i Info
The fuse box containing the fuses of the individual power consumers is located under the seat.

- Switch off all power consumers and switch off the engine.
- Remove the seat. (➡ p. 100)
- Open fuse box cover ❶.



600604-11



- Remove the defective fuse.

Guideline

Fuse 1 - 10A - ignition, combination instrument, alarm system (optional)
Fuse 2 - 10A - clock, ignition (EFI control unit)
Fuse 3 - 10A - throttle valve control unit
Fuse 4 - 10A - fuel pump
Fuse 5 - 10A - radiator fan
Fuse 6 - 10A - horn, brake light, flasher light, alarm system (optional)
Fuse 7 - 15A - high beam, low beam, parking light, tail light, license plate lamp
Fuse 8 - 10A - for accessories (in circuit with positive of ignition switch)
Fuse 9 - 10A - for accessories (permanent positive)
Fuse 10 - Not assigned
SPARE - 10A/15A - spare fuses

i

Info
You can recognize a defective fuse by the burned-out fuse wire **A**.



Warning

Fire hazard The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

- Replace with a spare fuse of the right rating.

Fuse (75011088010) (☛ p. 159)

Fuse (75011088015) (☛ p. 159)



Info

If the new fuse burns out, contact an authorized KTM workshop.




Tip

Put a new spare fuse in the fuse box for future use if needed.


- Checking the function of power consumers.
- Close the fuse box cover.
- Mount the seat. (☛ p. 101)

Adjusting the engine characteristic

- Switch off the ignition by turning the ignition key to position **OFF** ☒.
- Remove the seat. (☛ p. 100)



- Pull the **Map-Select** switch and holder ❶ upward off of the retaining bracket.
- Pull the **Map-Select** switch out of the holder.



- Turn the adjusting wheel until the desired digit is next to marking ❷.

Set the Map-Select switch to Soft.

- Set the adjusting wheel to position 1.
 - ✓ Soft – reduced homologated peak performance for better driveability.

Set the Map-Select switch to Advanced.

- Set the adjusting wheel to position 2.
 - ✓ Advanced – homologated performance with extremely direct responsiveness.

Set the Map-Select switch to Standard.

- Set the adjusting wheel to position 3, 4, 5, 6, 7, 8 or 9.
 - ✓ Standard – homologated performance with balanced responsiveness.

Set the Map-Select switch to poor fuel quality.

- Set the adjusting wheel to position 0.
 - ✓ Poor fuel quality – homologated performance is reduced in accordance with the fuel quality, use for no more than 1 tank of fuel


- Position the **Map-Select** switch in the holder.
- Slide the **Map-Select** switch with the holder downward onto the retaining bracket.
- Mount the seat. (🔧 p. 101)

Removing the headlight mask with the headlight


- Switch off all power consumers and switch off the engine.
- Cover the fender with a cloth to protect it from damage.
- Remove the screws ❶ on the left and right.
- Tip the headlight mask forward and pull it off upward.




- Disconnect the connectors of flashers ❷ and headlight ❸.
- Put down the headlight mask.




Refitting the headlight mask with the headlight



- Connect the connectors of headlight ❶ and flasher lights ❷.
- Check lighting function.



- Remove the cloth from the fender, attach the headlight mask to points ❸ on the fender and swing it up to the steering head.



- Position brake-hose guide ④. Mount and tighten screws ⑤.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Changing the headlight bulb


Note

Damage to reflector Keep the glass of the bulb free of grease.

- Clean the glass bulb with a clean cloth before mounting. Any grease on the glass will evaporate by the heat and be deposited on the reflector.



- Remove the headlight mask with the headlight. (🔧 p. 111)
- Pull off connector ①.
- Take off rubber cap ② of the headlight bulb.



- Detach spring bar ③.
- Remove headlight bulb ④.
- Insert a new headlight bulb into the headlight housing.

Headlight (H4/P43t) (☛ p. 159)

- Fit the headlight bulb in the headlight using the spring bar.
- Replace the rubber cap. Attach the connector.
- Refit the headlight mask with the headlight. (☛ p. 112)


Changing the parking light bulb


Note

Damage to reflector Keep the glass of the bulb free of grease.

- Clean the glass bulb with a clean cloth before mounting. Any grease on the glass will evaporate by the heat and be deposited on the reflector.

- Remove the headlight mask with the headlight. (☛ p. 111)
- Remove rubber cap ①.





- Pull bulb socket ② out of the reflector.
- Pull parking light bulb ③ out of the bulb socket.
- Fit a new parking light bulb in the bulb socket.

Parking light (W2,1x9,5d) (☛ p. 159)


- Insert the bulb socket in the reflector.
- Insert the rubber cap.
- Refit the headlight mask with the headlight. (☛ p. 112)

Changing the flasher bulb

Note

Damage to reflector Keep the glass of the bulb free of grease.

- Clean the glass bulb with a clean cloth before mounting. Any grease on the glass will evaporate by the heat and be deposited on the reflector.



- Remove the screw from the rear of the flasher housing.
- Tilt the headlamp diffuser ① carefully forward and take it off.
- Lightly squeeze the orange plug ② in the area of the holding lugs and take it off.
- Press the flasher bulb carefully into the socket, turn it about 30° anticlockwise, and take it out of the socket.

Info


Do not touch the reflector with your fingers, and keep it free from grease.

- Press the new flasher bulb carefully into the socket and turn it clockwise until it stops.

Flasher light (BA15s) (☛ p. 159)

- Mount the orange plug.
- Position the diffuser.
- Insert the screw and turn it first anticlockwise until it engages in the thread. Tighten the screw slightly.
- Check the flasher system function.

Checking headlamp setting



- On a light-colored wall with a horizontal area in front of it, make a mark as high as the center of the low beam headlight.
- Make another mark at a distance of B under the first mark.
Guideline

Distance B	5 cm (2 in)
------------	-------------
- Stand the motorcycle at a distance of A in front of the wall and switch on the low beam.
Guideline

Distance A	5 m (16 ft)
------------	-------------
- Check the headlamp setting.

The boundary between light and dark must be exactly on the lower mark for a motorcycle with driver.

 - » If the boundary between light and dark does not meet specifications:
 - Adjust the headlight range. (p. 117)

Adjusting the headlight range



- Check the headlamp setting. (☛ p. 116)
- Turn adjusting screw ❶ to adjust the headlight range.

Guideline

For a motorcycle with rider, the light/dark boundary must be exactly on the lower mark (made in: Checking headlight adjustment).




Info


Turn clockwise to increase headlight range, turn counterclockwise to reduce headlight range.

If you have a heavy payload, you will have to correct the headlight range.

Removing the air filter ☛



- Remove the seat. (☛ p. 100)
- Remove screws ❶. Remove filter box top ❷.




Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.
- Remove air filter ③.

Installing the air filter 🔧




- Clean the air filter box.
- Mount air filter ①.

i Info

The air filter must lie flush against the air filter box along the entire sealing surface A.


If the air filter is not correctly mounted, dust and dirt can penetrate into the engine and can cause damage.

- Hook filter box top ② into the front of the air filter box and swing down.



- Mount and tighten screws ③.
- Guideline
- | | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|
- Mount the seat. (🔧 p. 101)


Cooling system



The water pump ① in the engine forces the coolant to flow.

The pressure resulting from the warming of the cooling system is regulated by a valve in the radiator cap ②. Heat expansion causes excess coolant to flow into the compensating tank ③. If the temperature falls, the excess coolant is sucked back into the cooling system. The specified coolant temperature is therefore permissible without danger of function problems.

125 °C (257 °F)



The coolant is cooled by the air stream and a radiator fan ④, which is controlled by a thermostat.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

Checking the antifreeze and coolant level



Warning

Scalding hazard During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other components of the cooling system when the engine is hot. Allow the engine and radiator to cool down. If you are scalded, hold the affected part under cold water immediately.



Warning

Danger of poisoning Coolants are poisonous and a health hazard.

- Avoid contact between coolants and skin, eyes and clothing. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolants out of the reach of children.



Condition

Engine is cold.

- Stand the motorcycle on its side stand on a horizontal surface.
- Remove the cap of the compensating tank ❶.
- Check antifreeze of coolant.

-25... -45 °C (-13... -49 °F)

» If the antifreeze of the cooling liquid does not meet specifications:

- Correct antifreeze of coolant.

- Check the coolant level in the compensating tank.

The coolant level must be within the range shown in the figure.

» If the level of the cooling liquid does not meet specifications:

- Correct the coolant level.

Alternative 1

Coolant (☛ p. 167)

Alternative 2

Coolant (mixed ready to use) (☛ p. 167)

- Mount the cap of the compensating tank.



- Screw off the radiator cap ②.
- Check antifreeze of coolant.

-25... -45 °C (-13... -49 °F)

- » If the antifreeze of the cooling liquid does not meet specifications:
 - Correct antifreeze of coolant.
- Check the coolant level in the radiator.

The radiator must be completely full.

- » If the level of the cooling liquid does not meet specifications:
 - Correct the coolant level and find out the cause of the loss.

Alternative 1

Coolant (☛ p. 167)

Alternative 2

Coolant (mixed ready to use) (☛ p. 167)

- Refit the radiator cap.

Checking the coolant level



Warning

Scalding hazard During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other components of the cooling system when the engine is hot. Allow the engine and radiator to cool down. If you are scalded, hold the affected part under cold water immediately.

**Warning**

Danger of poisoning Coolants are poisonous and a health hazard.

- Avoid contact between coolants and skin, eyes and clothing. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolants out of the reach of children.

**Condition**

Engine is cold.

- Stand the motorcycle on its side stand on a horizontal surface.
- Check the coolant level in the compensating tank ❶.

The coolant level must be within the range shown in the figure.

- » If the level of the cooling liquid does not meet specifications:
 - Correct the coolant level.

Alternative 1

Coolant (☛ p. 167)

Alternative 2

Coolant (mixed ready to use) (☛ p. 167)



- Screw off the radiator cap ② and check the coolant level in the radiator.

The radiator must be completely full.

- » If the level of the cooling liquid does not meet specifications:
 - Correct the coolant level and find out the cause of the loss.

Alternative 1

Coolant (☛ p. 167)

Alternative 2

Coolant (mixed ready to use) (☛ p. 167)

- Refit the radiator cap.

Draining the coolant 🛠



Warning

Scalding hazard During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other components of the cooling system when the engine is hot. Allow the engine and radiator to cool down. If you are scalded, hold the affected part under cold water immediately.




Warning

Danger of poisoning Coolants are poisonous and a health hazard.

- Avoid contact between coolants and skin, eyes and clothing. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolants out of the reach of children.

- Remove the engine guard. (☛ p. 130)



- Stand the motorcycle upright.
- Place a suitable container under the engine.
- Remove screw ❶. Remove the radiator cap.
- Completely drain the coolant.
- Mount the screw ❶ with a new seal ring and tighten it.

Guideline

Plug, drain hole of water pump	M10x1	15 Nm (11.1 lbf ft)
--------------------------------	-------	------------------------

- Install the engine guard. (🔧 p. 130)

Filling the cooling system 🛠




Warning

Danger of poisoning Coolants are poisonous and a health hazard.

- Avoid contact between coolants and skin, eyes and clothing. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolants out of the reach of children.



- Stand the motorcycle on its side stand on a horizontal surface.
- Remove radiator cap ❶.



- Refill the coolant.


Alternative 1

Coolant (☛ p. 167)

Alternative 2

Coolant (mixed ready to use) (☛ p. 167)

- Fill the radiator completely with coolant. Mount radiator cap ❶.



- Remove the cap from compensating tank ❷ and add coolant to the level shown in the figure.
- Mount the cap of the compensating tank.



Danger

Danger of poisoning Exhaust gases are poisonous and can result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in a closed space without an effective exhaust extraction system.
- Start the engine and run it until the 5th bar of the temperature indicator lights up.
- Switch off the engine and allow it to cool down.
- After the engine has cooled down, check the coolant level in the radiator and in the compensating tank again and add more coolant if necessary.

Adjusting basic position of clutch lever



Info

Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar.
Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!



- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ❶.


Checking/rectifying the fluid level of the hydraulic clutch



Info

The fluid level rises with increasing wear of the clutch lining disc.
Do not use brake fluid.

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.



- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Check the fluid level.


Fluid level under top level of container	4 mm (0.16 in)
--	----------------

- » If the level of the coolant does not meet specifications:
 - Correct the fluid level of the hydraulic clutch.

Hydraulic fluid (15) (☛ p. 169)

- Position the cover with the membrane. Mount and tighten the screws.

Checking play in gas Bowden cable



- Move the handlebar to the straight-ahead position. Move the throttle grip backwards and forwards to ascertain the play in the gas Bowden cable.

Play in gas Bowden cable	3... 5 mm (0.12... 0.2 in)
--------------------------	----------------------------

- » If the gas Bowden cable play does not meet specifications:
 - Adjust the play in the gas Bowden cable. ☛ (☛ p. 129)



Danger
Danger of poisoning Exhaust gases are poisonous and can result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in a closed space without an effective exhaust extraction system.

- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
 - Adjust the play in the gas Bowden cable. 🛠️ (📖 p. 129)

Adjusting the play in the gas Bowden cable 🛠️




- Move the handlebar to the straight-ahead position.
- Use the KTM diagnostics tool to set the throttle stepper motor to the neutral position.
- Loosen counter nut ❶.
- Set the play in the gas Bowden cable by turning the adjusting screw ❷.

Guideline

Play in gas Bowden cable	3... 5 mm (0.12... 0.2 in)
--------------------------	----------------------------


- Tighten counter nut ❶.

Removing the engine guard



- Stand the motorcycle on its side stand on a horizontal surface.
- Remove screws ❶ on the left and right.
- Pull the engine guard forward out of the holders and set it down.

Installing the engine guard



- Slide the engine guard into holders ❶ at the rear.
- Position the engine guard. Mount and tighten screws.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Checking engine oil level



Info

The engine oil level must be checked when the engine is at operating temperature.

- Stand the motorcycle upright on a horizontal surface.

Condition

The engine is at operating temperature.

- Check the engine oil level.




Info

After switching off the engine, wait for one minute and then check.

The engine oil must be between the lower and upper edge of the oil level viewer.

- » If the engine oil level is not at the specified level:
 - Top up the engine oil. (🔧 p. 138)



Changing the engine oil and filter, cleaning the oil screens 🛠️

- Drain the engine oil. 🛠️ (🔧 p. 132)
- Remove the oil filter. 🛠️ (🔧 p. 133)
- Clean the oil screens. 🛠️ (🔧 p. 135)
- Install the oil filter. 🛠️ (🔧 p. 135)
- Fill up with engine oil. 🛠️ (🔧 p. 137)

Draining the engine oil



Warning

Danger of scalding Engine oil and gear oil get very hot when the motorcycle is driven.

- Wear suitable protective clothing and gloves. If you scald yourself, hold the affected area under cold water immediately.



Warning

Environmental hazard Problem materials cause environmental damage.


- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.




Info

Drain the engine oil only when the engine is warm.

- Remove the engine guard. ( p. 130)
- Place a suitable container under the engine.
- Remove the oil drain plug  with the magnet and seal ring.
- Completely drain the engine oil.






- Thoroughly clean the oil drain plug with a magnet.
- Mount the oil drain plug with the magnet and seal ring and tighten it.

Guideline

Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
----------------------------	---------	------------------------


Removing the oil filter

- Warning**
Danger of scalding Engine oil and gear oil get very hot when the motorcycle is driven.
 - Wear suitable protective clothing and gloves. If you scald yourself, hold the affected area under cold water immediately.
- Warning**
Environmental hazard Problem materials cause environmental damage.
 - Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.
- Place a suitable container under the engine.



- Remove screws ❶. Remove the oil filter cover ❷ with the O-ring.
- Pull oil filter ❸ out of the oil filter housing.

Circlip pliers reverse (51012011000)




- Remove screws ❹. Remove oil filter ❺ with the O-ring.
- Pull oil filter ❻ out of the oil filter housing.

Circlip pliers reverse (51012011000)

- Completely drain the engine oil.
- Thoroughly clean the parts and sealing area.

Installing the oil filter



- Insert oil filters ❶ and ❷.
- Oil the O-rings of the oil filter cover. Fit the oil filter covers ❸ and ❹.
- Mount and tighten the screws.

Guideline

Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)
-------------------------	----	-------------------

Cleaning the oil screens


- Warning**

Danger of scalding Engine oil and gear oil get very hot when the motorcycle is driven.


 - Wear suitable protective clothing and gloves. If you scald yourself, hold the affected area under cold water immediately.
- Warning**

Environmental hazard Problem materials cause environmental damage.


 - Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.
- Place a suitable container under the engine.



- Remove plug 1 with oil screen 2 and the O-rings.




- Remove plug 3 with oil screen 4 and the O-rings.
- Completely drain the remaining engine oil.
- Thoroughly clean the parts and sealing area.



- Position oil screen 2 with the O-rings.
- Mount and tighten plug 1 with the O-ring.

Guideline

Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------	---------	------------------------




- Position oil screen 4 with the O-rings.
- Mount and tighten plug 3 with the O-ring.

Guideline

Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------	---------	------------------------

Filling up with engine oil

i Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- Remove filler plug with O-ring 1 from the clutch cover and add engine oil.

Engine oil	1.70 l (1.8 qt.)	Engine oil (SAE 10W/60) (00062010035) (p. 168)	
		Alternative engine oil	Engine oil (SAE 10W/50) (p. 168)

- Refit plug with O-ring 1 and tighten it.



Danger
Danger of poisoning Exhaust gases are poisonous and can result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in a closed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.
- Install the engine guard. (🔧 p. 130)
- Check the engine oil level. (🔧 p. 131)

Topping up engine oil



Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- Remove the oil filler plug with O-ring ❶ from the clutch cover and fill up with engine oil.

Engine oil (SAE 10W/60) (00062010035) (🔧 p. 168)
Engine oil (SAE 10W/50) (🔧 p. 168)



Info
For optimal performance of the engine oil, do not mix different types of engine oil.
If appropriate, change the engine oil.

- Install and tighten the oil filler plug with O-ring ❶.



Danger

Danger of poisoning Exhaust gases are poisonous and can result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in a closed space without an effective exhaust extraction system.
-
- Start the engine and check that it is oil-tight.
 - Check the engine oil level. (🔧 p. 131)

TROUBLESHOOTING

140

Faults	Possible cause	Action
The engine does not turn when the starter button is pressed	Operating error	– Carry out work steps for the start procedure. (☛ p. 41)
	Battery discharged	– Recharge the battery. 🛡️ (☛ p. 103) – Check the cause of discharging.
	Fuse 1 , 2 , 3 , or 4 blown	– Change the fuses of power consumers. (☛ p. 107)
	Main fuse burned out	– Changing the main fuse. (☛ p. 105)
	Ignition/steering lock or emergency OFF switch defective	– Have ignition/steering lock or emergency OFF switch checked.
	Defect in safety start system	– Have the safety start system checked.
	No ground connection present.	– Check the ground connection.
Engine turns only if the clutch lever is drawn	The vehicle is in gear	– Shift gear to neutral.
	The vehicle is in gear and the side stand is folded out	– Shift gear to neutral.
	Defect in safety start system	– Have the safety start system checked.
Engine turns although a gear is engaged	Defect in safety start system	– Have the safety start system checked.
Engine turns but does not start.	Operating error	– Carry out work steps for the start procedure. (☛ p. 41)
	Fuse 4 blown	– Change the fuses of power consumers. (☛ p. 107)
	Coupling of fuel hose connection not connected	– Reconnect coupling of fuel hose connection.
	Socket connector of cable harness oxidized	– Clean socket connector and treat it with contact spray.

TROUBLESHOOTING

141

Faults	Possible cause	Action
Engine turns but does not start.	Defect in fuel injection system	– Read the error memory with the KTM diagnostics tool and correct the fault.
Engine has too little power.	Air filter very dirty	– Have the air filter changed.
	Fuel filter very dirty	– Have the fuel filter changed.
	Defect in fuel injection system	– Read the error memory with the KTM diagnostics tool and correct the fault.
Engine overheats.	Too little coolant in cooling system	– Check the cooling system for leakage. – Check the coolant level. (☛ p. 122)
	Radiator fins very dirty	– Clean radiator fins.
	Foam formation in cooling system	– Drain the coolant. ☛ (☛ p. 124) – Fill the cooling system. ☛ (☛ p. 125)
	Buckled or damaged radiator hose	– Have the radiator hose changed.
	Thermostat defective	– Have thermostat checked.
	Fuse 5 blown	– Change the fuses of power consumers. (☛ p. 107)
	Defect in radiator fan system	– Have the radiator fan system checked.
	Air in cooling system	– Fill the cooling system. ☛ (☛ p. 125)
FI warning lamp (MIL) lights/flashes	Defect in fuel injection system	– Read the error memory with the KTM diagnostics tool and correct the fault.
Engine dies during the journey	Lack of fuel	– Refuel. (☛ p. 49)
	Fuse 1 , 2 or 4 blown	– Change the fuses of power consumers. (☛ p. 107)
High oil consumption	Engine vent hose bent	– Route the vent hose without bends or change it if necessary.
	Engine oil level too high	– Check the engine oil level. (☛ p. 131)

TROUBLESHOOTING

142

Faults	Possible cause	Action
High oil consumption	Engine oil too thin (low viscosity)	– Change the engine oil and filter, clean the oil screens. 🛠️ (🔧 p. 131)
Headlight and parking light not functioning	Fuse 7 blown	– Change the fuses of power consumers. (🔧 p. 107)
Flasher light, brake light and horn not functioning	Fuse 6 blown	– Change the fuses of power consumers. (🔧 p. 107)
Time is not (correctly) displayed	Fuse 2 blown	– Change the fuses of power consumers. (🔧 p. 107) – Set the clock. (🔧 p. 27)
Battery discharged	Ignition not switched off when vehicle was parked	– Recharge the battery. 🛠️ (🔧 p. 103)
	Battery is not charged by generator	– Check charging voltage.
Combination instrument shows nothing in the display	Fuse 1 blown	– Change the fuses of power consumers. (🔧 p. 107)
Speedometer in combination instrument not functioning	Speedometer cable harness damaged or plug oxidized	– Have the cable harness and plug checked.

FLASHING CODE

143

Flashing code FI of warning lamp (MIL)	02 FI warning lamp (MIL) flashes briefly 2x
Possible cause	Malfunction in ignition pulse generator circuit
Flashing code FI of warning lamp (MIL)	06 FI warning lamp (MIL) flashes briefly 6x
Possible cause	Input signal of throttle valve sensor circuit A too low
	Input signal of throttle valve sensor circuit A too high
Flashing code FI of warning lamp (MIL)	08 FI warning lamp (MIL) flashes briefly 8x
Possible cause	Input signal from throttle grip sensor too low
	Input signal from throttle grip sensor too high
Flashing code FI of warning lamp (MIL)	09 FI warning lamp (MIL) flashes briefly 9x
Possible cause	Input signal from pressure sensor, induction manifold (cylinder 1) too low
	Input signal from pressure sensor, induction manifold (cylinder 1) too high
Flashing code FI of warning lamp (MIL)	12 FI warning lamp (MIL) flashes 1x long, 2x short
Possible cause	Input signal from coolant temperature sensor too low
	Input signal from coolant temperature sensor too high

FLASHING CODE

144

Flashing code FI of warning lamp (MIL)	13 FI warning lamp (MIL) flashes 1x long, 3x short
Possible cause	Input signal from intake air temperature sensor too low
	Input signal from intake air temperature sensor too high
Flashing code FI of warning lamp (MIL)	14 FI warning lamp (MIL) flashes 1x long, 4x short
Possible cause	Input signal of pressure sensor ambient air too low
	Input signal of pressure sensor ambient air too high
Flashing code FI of warning lamp (MIL)	15 FI warning lamp (MIL) flashes 1x long, 5x short
Possible cause	Input signal from rollover sensor too low
	Input signal from rollover sensor too high
Flashing code FI of warning lamp (MIL)	17 FI warning lamp (MIL) flashes 1x long, 7x short
Possible cause	Malfunction in lambda probe circuit (cylinder 1)
Flashing code FI of warning lamp (MIL)	24 FI warning lamp (MIL) flashes 2x long, 4x short
Possible cause	Malfunction in circuit of EFI control unit or EPT control unit voltage supply
Flashing code FI of warning lamp (MIL)	25 FI warning lamp (MIL) flashes 2x long, 5x short
Possible cause	Malfunction in sidestand switch circuit

FLASHING CODE

145

Flashing code FI of warning lamp (MIL)	26 FI warning lamp (MIL) flashes 2x long, 6x short
Possible cause	Malfunction in circuit of Hall sensor throttle valve control
Flashing code FI of warning lamp (MIL)	27 FI warning lamp (MIL) flashes 2x long, 7x short
Possible cause	Malfunction in the EPT control unit power supply circuit
Flashing code FI of warning lamp (MIL)	33 FI warning lamp (MIL) flashes 3x long, 3x short
Possible cause	Malfunction in injection valve circuit (cylinder 1)
Flashing code FI of warning lamp (MIL)	37 FI warning lamp (MIL) flashes 3x long, 7x short
Possible cause	Malfunction in ignition coil circuit (cylinder 1)
Flashing code FI of warning lamp (MIL)	41 FI warning lamp (MIL) flashes 4x long, 1x short
Possible cause	Interruption/short-circuit to ground in fuel pump control circuit
Flashing code FI of warning lamp (MIL)	45 FI warning lamp (MIL) flashes 4x long, 5x short
Possible cause	Malfunction or short circuit to ground in lambda probe heating circuit (cylinder 1)

FLASHING CODE

146

Flashing code FI of warning lamp (MIL)	54 FI warning lamp (MIL) flashes 5x long, 4x short
Possible cause	Interruption/short-circuit to ground in secondary air valve circuit
Flashing code FI of warning lamp (MIL)	58 FI warning lamp (MIL) flashes 5x long, 8x short
Possible cause	Malfunction of release of throttle stepper motor in EPT mode
Flashing code FI of warning lamp (MIL)	60 FI warning lamp (MIL) flashes 6x long
Possible cause	Malfunction in throttle stepper motor circuit
Flashing code FI of warning lamp (MIL)	68 FI warning lamp (MIL) flashes 6x long, 8x short
Possible cause	The connection of the manifold absolute pressure sensor (cylinder 1) is not airtight
Flashing code FI of warning lamp (MIL)	90 FI warning lamp (MIL) flashes 9x long
Possible cause	Throttle value position not plausible
Flashing code FI of warning lamp (MIL)	91 FI warning lamp (MIL) flashes 9x long, 1x short
Possible cause	Malfunction in CAN bus communication

FLASHING CODE

147

Flashing code FI of warning lamp (MIL)	92 FI warning lamp (MIL) flashes 9x long, 2x short
Possible cause	Malfunction in voltage supply circuit of EPT control unit (internal)

Cleaning motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

- Never clean the vehicle with high-pressure cleaning equipment or a strong water-jet. The excessive pressure can penetrate electrical components, plug connectors, Bowden cables and bearings, etc., and can damage or destroy these parts.



Warning

Environmental hazard Problem materials cause environmental damage.

- Dispose of oil, grease, filters, fuel, cleaning substances, brake fluid, batteries, etc., according to regulations.



Info

If you clean the motorcycle regularly, its value and appearance are maintained over a long period.
Avoid direct sunshine on the motorcycle during cleaning.

- Before you clean the motorcycle, seal the exhaust system to prevent penetration by water.
- First remove coarse dirt particles with a gentle water spray.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a paintbrush.

Motorcycle cleaner (🔧 p. 172)



Info

Use warm water containing normal motorcycle cleaner and a soft sponge.
If you have ridden the vehicle on salted roads, clean it with cold water. Warm water would reinforce the effect of the salt.

- After rinsing the motorcycle thoroughly with a soft jet of water, dry it with compressed air and a cloth.

**Warning**

Danger of accidents Reduced braking due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.

- After cleaning, ride the vehicle a short distance until the engine warms up, and then apply the brakes.

**Info**

The heat produced causes water at inaccessible positions in the engine and the brakes to evaporate.

- Push back the protection covers on the handlebar instruments to allow water to evaporate.
- After the motorcycle has cooled off, oil or grease all moving parts and bearings.
- Clean the chain. (🔧 p. 68)
- Treat bare metal parts (except for brake discs and exhaust system) with anti-corrosion materials.

Cleaning and polishing materials for metal, rubber and plastic (🔧 p. 171)

- Treat all painted parts with a mild paint polish.

High-luster polish for paint (🔧 p. 171)

- To prevent electrical problems, treat electric contacts and switches with contact spray.

Contact spray (🔧 p. 171)

- Oil the ignition/steering lock.

Universal oil spray (🔧 p. 172)

Conservation for winter operation



Info

If you use the motorcycle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.

If you have ridden the vehicle on salted roads, clean it with cold water. Warm water would reinforce the effect of the salt.

-
- Clean the motorcycle. (🔧 p. 148)
 - Treat the engine, the swingarm, and all other bare or galvanized parts (except brake discs) with a wax-based anti-corrosion substance.



Info

To prevent serious reduction of the braking efficiency, make sure no anti-corrosion substance gets on to the brake discs. After use on salted roads, clean the motorcycle thoroughly with cold water and dry it properly.

-
- Clean the chain. (🔧 p. 68)

Storage**i Info**

If you want to garage the motorcycle for a longer period, take the following actions. Before storing the motorcycle, check all parts for function and wear. If service, repairs or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.

- Make sure the tank is as empty as possible so that you can fill up with fresh fuel when you put the motorcycle back into operation.
- Clean the motorcycle. (🔧 p. 148)
- Change the engine oil and filter, clean the oil screens. 🛢️ (🔧 p. 131)
- Check the antifreeze and coolant level. (🔧 p. 120)
- Check the tire air pressure. (🔧 p. 98)
- Remove the battery. 🛢️ (🔧 p. 101)
- Recharge the battery. 🛢️ (🔧 p. 103)

Guideline

Storage temperature of battery without direct sunshine.	0... 35 °C (32... 95 °F)
---	--------------------------

- The storage place should be dry and not subject to large temperature differences.

i Info

KTM recommends jacking up the motorcycle.

- Jack up the motorcycle. (🔧 p. 55)

- Cover the motorcycle with a porous sheet or blanket.

**Info**

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion. Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and exhaust system to rust.

Putting into operation after storage

- Remove the motorcycle from the work stand. (🔧 p. 55)
- Recharge the battery. 🔌 (🔧 p. 103)
- Install the battery. 🔌 (🔧 p. 102)
- Set the clock. (🔧 p. 27)
- Refuel. (🔧 p. 49)
- Carry out checks before putting into operation. (🔧 p. 40)
- Make a test ride.

TECHNICAL DATA - ENGINE

153

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	654 cm ³ (39.91 cu in)
Stroke	80 mm (3.15 in)
Bore	102 mm (4.02 in)
Compression ratio	11.8:1
Control	OHC, 4 valves controlled via rocker arm, chain drive
Valve diameter, intake	40 mm (1.57 in)
Valve diameter, exhaust	34 mm (1.34 in)
Valve play, cold	0.07... 0.13 mm (0.0028... 0.0051 in)
Crankshaft bearing	2 roller bearings
Conrod bearing	Needle bearing
Piston pin bearing	Bronze bush
Pistons	Forged light alloy
Piston rings	1 L-ring, 1 tapered compression piston ring, 1 oil scraper ring
Engine lubrication	Semi-dry sump lubrication with two rotor pumps
Primary transmission	36:79
Clutch	APTCTM Antihopping clutch in oil bath / hydraulically operated
Gearbox	6-gears, claw-shifted
Transmission ratio	
1st gear	14:35
2nd gear	16:28
3rd gear	21:28
4th gear	21:23
5th gear	23:22
6th gear	23:20

TECHNICAL DATA - ENGINE

154

Mixture preparation	Electronic fuel injection
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment
Generator	12 V, 224 W
Spark plug	NGK LKAR 8AI - 9
Spark plug electrode gap	0.9 mm (0.035 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Starting aid	Electric starter, automatic decompressor

Capacity- engine oil

Engine oil	1.70 l (1.8 qt.)	Engine oil (SAE 10W/60) (00062010035) (☛ p. 168)	
		Alternative engine oil	Engine oil (SAE 10W/50) (☛ p. 168)

Capacity - coolant

Coolant	1.20 l (1.27 qt.)	Coolant (☛ p. 167)	
		Coolant (mixed ready to use) (☛ p. 167)	

TECHNICAL DATA - ENGINE TIGHTENING TORQUES

155

Oil hole plug	self-tapping	9 Nm (6.6 lbf ft)	Loctite® 243™
Screw, membrane fixation	M3	2.5 Nm (1.84 lbf ft)	Loctite® 243™
Hose clamp, intake flange	M4	1.5 Nm (1.11 lbf ft)	–
Oil jet, conrod lubrication	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Locking screw for bearing	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, breather cover on valve cover	M5	3 Nm (2.2 lbf ft)	Loctite® 243™
Screw, clutch spring	M5	6 Nm (4.4 lbf ft)	–
Screw, cover plate for oil return line	M5	6 Nm (4.4 lbf ft)	–
Screw, gear sensor	M5	5 Nm (3.7 lbf ft)	Loctite® 243™
Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)	–
Screw, oil pump cover	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Plug, vacuum connection	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, Autodecompression	M6	3... 4 Nm (2.2... 3 lbf ft)	Loctite® 243™
Screw, axial lock of camshaft	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch slave cylinder	M6x20	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch slave cylinder	M6x35	10 Nm (7.4 lbf ft)	–
Screw, cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, cylinder head	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, engine housing	M6	10 Nm (7.4 lbf ft)	–
Screw, generator cover	M6	10 Nm (7.4 lbf ft)	–
Screw, generator cover (chain shaft through-hole)	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, ignition pulse generator	M6	10 Nm (7.4 lbf ft)	Loctite® 243™

TECHNICAL DATA - ENGINE TIGHTENING TORQUES

156

Screw, locking lever	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, rocker arm shaft	M6	12 Nm (8.9 lbf ft)	–
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	10 Nm (7.4 lbf ft)	Loctite® 222
Screw, starter motor	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, stator bracket	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, thermostat housing	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, timing chain guide rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, timing chain tensioning rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, valve cover	M6	10 Nm (7.4 lbf ft)	–
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Screw, water pump wheel	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Oil jet, piston cooling	M6x0.75	4 Nm (3 lbf ft)	Loctite® 243™
Plug, crankshaft location	M8	20 Nm (14.8 lbf ft)	–
Stud, exhaust flange	M8	10 Nm (7.4 lbf ft)	Loctite® 243™
Cylinder head screw	M10	Tightening sequence: Tighten diagonally, beginning with the rear screw on the chain shaft. Step 1 15 Nm (11.1 lbf ft) Step 2 30 Nm (22.1 lbf ft) Step 3 45 Nm (33.2 lbf ft) Step 4 60 Nm (44.3 lbf ft)	lubricated with engine oil

TECHNICAL DATA - ENGINE TIGHTENING TORQUES

157

Oil hole plug	M10x1	15 Nm (11.1 lbf ft)	Loctite® 243™
Plug, drain hole of water pump	M10x1	15 Nm (11.1 lbf ft)	–
Plug, oil bore for oil radiator	M10x1	15 Nm (11.1 lbf ft)	–
Screw, unlocking of timing chain tensioner	M10x1	10 Nm (7.4 lbf ft)	–
Spark plug	M12x1.25	17 Nm (12.5 lbf ft)	–
Coolant temperature sensor on cylinder head	M12x1.5	12 Nm (8.9 lbf ft)	–
Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Oil pressure regulator valve plug	M12x1.5	20 Nm (14.8 lbf ft)	–
Plug, oil bore	M14x1.5	15 Nm (11.1 lbf ft)	Loctite® 243™
Engine case stud	M16x1.5	25 Nm (18.4 lbf ft)	Loctite® 243™
Rotor nut	M18x1.5	100 Nm (73.8 lbf ft)	–
Nut, engine sprocket	M20x1.5	60 Nm (44.3 lbf ft)	Loctite® 243™
Nut, inner clutch hub	M20x1.5	100 Nm (73.8 lbf ft)	Loctite® 243™
Nut, primary gear	M20LHx1.5	90 Nm (66.4 lbf ft)	Loctite® 243™
Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)	–
Plug, timing chain tensioner	M20x1.5	25 Nm (18.4 lbf ft)	–
Plug, oil thermostat	M24x1.5	15 Nm (11.1 lbf ft)	–
Screw in generator cover	M24x1.5	8 Nm (5.9 lbf ft)	–

TECHNICAL DATA - CHASSIS

158

Frame	Lattice frame made of chrome molybdenum steel tubing, powder-coated
Fork	WP Suspension 4860 MXMA
Shock absorber	WP Suspension 4618 with Pro-Lever deflector
Suspension travel	
Front	250 mm (9.84 in)
Rear	250 mm (9.84 in)
Brake system	
Front	Disc brake with dual-piston brake caliper, floating
Rear	Disc brake with single-piston brake caliper, floating
Brake discs - diameter	
Front	300 mm (11.81 in)
Rear	240 mm (9.45 in)
Brake discs - wear limit	
Front	4.5 mm (0.177 in)
Rear	3.5 mm (0.138 in)
Tire air pressure, road, solo	
Front	1.8 bar (26 psi)
Rear	1.8 bar (26 psi)
Tire air pressure with passenger / fully loaded	
front	2.0 bar (29 psi)
Rear	2.2 bar (32 psi)
Tire air pressure, offroad, single rider	
Front	1.5 bar (22 psi)
Rear	1.5 bar (22 psi)

TECHNICAL DATA - CHASSIS

159

Secondary drive ratio	15:45
Chain	5/8 x 1/4" X-ring
Steering head angle	63°
Wheelbase	1,498±15 mm (58.98±0.59 in)
Seat height unloaded	910 mm (35.83 in)
Ground clearance unloaded	300 mm (11.81 in)
Weight without fuel approx.	138.5 kg (305.3 lb.)
Maximum permissible front axle load	150 kg (331 lb.)
Maximum permissible rear axle load	200 kg (441 lb.)
Maximum permissible overall weight	350 kg (772 lb.)

Battery	YTZ10S	Battery voltage: 12 V Nominal capacity: 8.6 Ah maintenance-free
Fuse	58011109130	30 A
Fuse	75011088015	15 A
Fuse	75011088010	10 A

Lighting equipment

Headlight	H4/P43t	12 V 60/55 W
Parking light	W2,1x9,5d	12 V 5 W
Instrument lights and indicator lamps	LED	
Flasher light	BA15s	12 V 10 W

TECHNICAL DATA - CHASSIS

160

Brake/tail light	LED	
License plate lamp	W2,1x9,5d	12 V 5 W

Front tire	Rear tire
90/90 - 21 M/C 54H TL Metzeler Enduro 3 Sahara	140/80 - 18 M/C 70H TL Metzeler Enduro 3 Sahara
Additional information is available in the Service section under: http://www.ktm.com	

Capacity - fuel

Total fuel tank capacity, approx.	12 l (3.2 US gal)	Super unleaded (ROZ 95 / RON 95 / PON 91) (🔧 p. 170)
Fuel reserve, approx.	2.5 l (2.6 qt.)	

TECHNICAL DATA - FORK

161

Fork part number	14.18.7E.11
Fork	WP Suspension 4860 MXMA
Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Spring length with preload spacer(s)	472 mm (18.58 in)
Spring rate	
Weight of rider: 75... 85 kg (165... 187 lb.)	5.4 N/mm (30.8 lb/in)
Air chamber length	120±20 mm (4.72±0.79 in)
Fork length	890 mm (35.04 in)
Fork oil	620 ml (20.96 fl. oz.)
Fork oil (SAE 5) (☛ p. 169)	

TECHNICAL DATA - SHOCK ABSORBER

162

Shock absorber part number	15.18.7E.11
Shock absorber	WP Suspension 4618 with Pro-Lever deflector
Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn
Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Spring preload	20 mm (0.79 in)
Spring rate	
Weight of rider: 75... 85 kg (165... 187 lb.)	80 N/mm (457 lb/in)
Spring length	220 mm (8.66 in)
Gas pressure	10 bar (145 psi)
Static sag	25 mm (0.98 in)
Riding sag	70... 80 mm (2.76... 3.15 in)
Fitted length	395 mm (15.55 in)

TECHNICAL DATA - SHOCK ABSORBER

Shock absorber oil (🔧 p. 169)	SAE 2.5
-------------------------------	---------

TECHNICAL DATA - CHASSIS TIGHTENING TORQUES

164

Remaining screws, chassis	M5	4 Nm (3 lbf ft)	–
Screw, electrical holder	M5	3 Nm (2.2 lbf ft)	–
Screw, exhaust heat shield	M5	8 Nm (5.9 lbf ft)	–
Screw, footbrake pedal foothold	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, fuel level indicator	M5	3 Nm (2.2 lbf ft)	–
Screw, fuel pump	M5	6 Nm (4.4 lbf ft)	–
Screw, headlight mask	M5	5 Nm (3.7 lbf ft)	–
Screw, seat lock	M5	3 Nm (2.2 lbf ft)	Loctite® 222
Screw, side cover	M5	2 Nm (1.5 lbf ft)	–
Screw, side stand switch	M5	3 Nm (2.2 lbf ft)	–
Screw, starter cable on starter	M5	3 Nm (2.2 lbf ft)	–
Spoke nipple, front wheel	M5	4 Nm (3 lbf ft)	–
Spoke nipple, rear wheel	M5	4 Nm (3 lbf ft)	–
Nut, foot brake cylinder screw	M6	10 Nm (7.4 lbf ft)	–
Remaining nuts, chassis	M6	15 Nm (11.1 lbf ft)	–
Remaining screws on fuel tank	M6	6 Nm (4.4 lbf ft)	–
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)	–
Screw, ball joint of push rod on foot-brake cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, brake fluid reservoir of rear brake	M6	5 Nm (3.7 lbf ft)	–
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, ignition lock	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, license plate holder, bottom	M6	8 Nm (5.9 lbf ft)	–
Screw, magnetic holder on side stand	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, radiator bracket	M6	5 Nm (3.7 lbf ft)	–

TECHNICAL DATA - CHASSIS TIGHTENING TORQUES

165

Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, SLS valve	M6	4 Nm (3 lbf ft)	–
Screw, voltage regulator/rectifier	M6	8 Nm (5.9 lbf ft)	–
Nut, manifold on cylinder head	M8	25 Nm (18.4 lbf ft)	Copper paste
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)	Loctite® 243™
Remaining nuts, chassis	M8	30 Nm (22.1 lbf ft)	–
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	–
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)	–
Screw, connection lever on frame	M8	30 Nm (22.1 lbf ft)	–
Screw, exhaust clamp on main silencer	M8	25 Nm (18.4 lbf ft)	–
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	–
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, front footrest bracket	M8	25 Nm (18.4 lbf ft)	–
Screw, fuel tank, bottom	M8	25 Nm (18.4 lbf ft)	–
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
Screw, handrail	M8	20 Nm (14.8 lbf ft)	–
Screw, license plate holder, top	M8	20 Nm (14.8 lbf ft)	–
Screw, main silencer holder	M8	25 Nm (18.4 lbf ft)	–
Screw, main silencer holder on fuel tank	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, rear footrest bracket	M8x16	25 Nm (18.4 lbf ft)	–
Screw, side stand bracket	M8	25 Nm (18.4 lbf ft)	–
Screw, spring holder on side stand bracket	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)	–

TECHNICAL DATA - CHASSIS TIGHTENING TORQUES

166

Upper fuel tank screw	M8	20 Nm (14.8 lbf ft)	–
Engine carrying screw	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
Remaining nuts, chassis	M10	50 Nm (36.9 lbf ft)	–
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)	–
Screw, bottom shock absorber	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
Screw, engine bearer on frame	M10	45 Nm (33.2 lbf ft)	–
Screw, foot brake pedal	M10LH	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	–
Screw, side stand	M10	35 Nm (25.8 lbf ft)	Loctite® 243™
Screw, top shock absorber	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
Lambda probe	M12x1.25	24.5 Nm (18.07 lbf ft)	–
Screw, swingarm pivot	M12x1.75	80 Nm (59 lbf ft)	–
Nut, linkage lever on swingarm	M14x1.5	100 Nm (73.8 lbf ft)	–
Nut, linkage lever to rocker arm	M14x1.5	100 Nm (73.8 lbf ft)	–
Screw, bottom steering head	M20x1.5	60 Nm (44.3 lbf ft)	Loctite® 243™
Screw, top steering head	M20x1.5	10 Nm (7.4 lbf ft)	–
Screw, front wheel spindle	M24x1.5	40 Nm (29.5 lbf ft)	–
Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)	–

Brake fluid DOT 4 / DOT 5.1

According to

- DOT

Guideline

- Use only brake fluid that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Castrol** and **Motorex®** products.

Supplier

Castrol

- **RESPONSE BRAKE FLUID SUPER DOT 4**

Motorex®

- **Brake Fluid DOT 5.1**

Coolant

Guideline

- Use only suitable coolant (in countries with high temperatures also). Use of low-quality antifreeze can lead to corrosion and foaming. KTM recommends **Motorex®** products.

Mixture ratio

Antifreeze protection: -25... -45 °C (-13... -49 °F)	50 % Corrosion/antifreeze 50 % Distilled water
--	---

Coolant (mixed ready to use)

Antifreeze	-40 °C (-40 °F)
------------	-----------------

Supplier

Motorex®

- **Anti Freeze**

Engine oil (SAE 10W/60) (00062010035)

According to

- JASO T903 MA (☛ p. 173)
- SAE (☛ p. 173) (SAE 10W/60)
- KTM LC4 2007+

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Synthetic engine oil

Supplier

Motorex®

- **Motorex® KTM Cross Power 4T**

Engine oil (SAE 10W/50)

According to

- JASO T903 MA (☛ p. 173)
- SAE (☛ p. 173) (SAE 10W/50)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Fully synthetic engine oil

Supplier

Motorex®

- **Power Synt 4T**

Fork oil (SAE 5)

According to

- SAE (☛ p. 173) (SAE 5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Racing Fork Oil**

Hydraulic fluid (15)

According to

- ISO VG (15)

Guideline

- Use only hydraulic fluid that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Hydraulic Fluid 75**

Shock absorber oil (SAE 2.5) (50180342S1)

According to

- SAE (☛ p. 173) (SAE 2.5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Super unleaded (ROZ 95 / RON 95 / PON 91)

According to

- DIN EN 228 (ROZ 95 / RON 95 / PON 91)

AUXILIARY SUBSTANCES

171

Chain cleaner

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Chain Clean 611**

Cleaning and polishing materials for metal, rubber and plastic

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Protect & Shine 645**

Contact spray

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Accu Contact**

High-luster polish for paint

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Moto Polish**

Long-life grease

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Fett 2000**

Motorcycle cleaner

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Moto Clean 900**

Offroad chain spray

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Chain Lube 622**

Universal oil spray

Specification

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Joker 440 Universal**

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. With most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

INDEX

174

A		Brakes46
Accessories8		Braking46
Air filter		C
installing118		Chain
removing117		checking dirt68
Antifreeze		checking for wear73
checking120		cleaning68
B		Chain guide
Baggage38		adjusting74
Battery		Chain tension
fitting102		adjusting70
recharging103		checking69
removing101		Chassis number16
Brake discs		Checking headlamp setting116
checking74		Cleaning148-149
Brake fluid		Clutch
front brake, adding77		fluid level, checking/rectifying127
rear brake, adding85		Clutch lever19
Brake fluid level		adjusting basic position127
front brake, checking77		Combination instrument23
of rear brake, checking85		ODO display28, 30
Brake linings		display25
front brake, changing80		function buttons23
of front brake, checking79		indicator lights24
of rear brake, checking87		setting clock27
rear brake, changing87		setting kilometers or miles26
		setting/resetting TRIP 128-29

INDEX

175

speedometer	26
tachometer	24
temperature indicator of coolant	30
time	27
Conservation for winter operation	150
Conserving for winter operation	150
Coolant	
draining	124
Coolant level	
checking	120, 122
Cooling system	119
filling	125
D	
Display	25
E	
Electric starter button	22
Emergency OFF switch	21
Engine	
running in	37
Engine characteristic	
adjusting	109
Engine guard	
installing	130
removing	130
Engine number	17

Engine oil	
changing	131
draining	132
refilling	137
topping up	138
Engine oil level	
checking	131
Environment	9
F	
Filler cap	
closing	31
opening	31
Filling up	
fuel	49
Flasher bulb	
changing	115
Flasher switch	20
Flashing code	143-147
Foot brake pedal	34
adjusting basic position	84
checking free play	83
Fork	56
compression damping, adjusting	56
dust boots, cleaning	63
fork legs, bleeding	62
rebound, adjusting	57

INDEX

176

Fork part number	18
Fork protector	
positioning	64
remove	64
Front wheel	
installing	92
removing	90
Fuel, oils, etc.	7
Fuse	
power consumers, changing	107
H	
Hand brake lever	19
adjusting free travel	76
checking free play	75
Handlebar position	67
adjusting	67
Handrails	32
Headlight	
light range, adjusting	117
Headlight bulb, changing	113
Headlight mask with headlight	
fitting	112
removing	111
Horn button	21

I	
Ignition lock	22
Indicator lights	24
K	
Key number	17
L	
Light switch	20
Loading the vehicle	38
M	
Main fuse	
changing	105
Maintenance	7
Motorcycle	
cleaning	148
jacking up	55
removing from the work stand	55
O	
Oil filter	
changing	131
installing	135
removing	133
Oil screens	
cleaning	131, 135
Owner's manual	
basics	10

INDEX

177

P

Parking	47
Parking light bulb	
changing	114
Passenger footrests	33
Play in gas Bowden cable	
adjusting	129
checking	128
Putting into operation	
advice on first use	36
after storage	152
checks before putting into operation	40

R

Rear hub rubber dampers	
checking	95
Rear sprocket / engine sprocket	
checking for wear	72
Rear wheel	
installing	94
removing	93
Riding	43
starting up	43

S

Seat	
mounting	101
removing	100

Seat release	32
Service schedule	51-54
Shift lever	33
Shifting	43
Shock absorber	56
compression damping, general	58
high-speed compression damping, adjusting	60
low-speed compression damping, adjusting	58
rebound damping, adjusting	61
Shock absorber part number	18
Side stand	35
Spare parts	8
Spoke tension	
checking	99
Starting	41
Steering head bearing play	
adjusting	66
checking	65
Steering lock	22
Stopping	47
Storage	151

T

Tachometer	24
Technical data	
chassis	158-160
chassis tightening torques	164-166
engine	153-154

INDEX

engine tightening torques	155-157
fork	161
shock absorber	162-163
Tire air pressure	
checking	98
Tire condition	
checking	96
Transport	8
Troubleshooting	140-142
Type label	16
U	
Use definition	7
V	
View of vehicle	
front left	12
rear right	14
W	
Warranty	7
Work rules	8



3211357en



10/2008 Photo: Mitterbauer



KTM-Sportmotorcycle AG
5230 Mattighofen/Austria
<http://www.ktm.com>